

April 2002


www.nasatech.com

Vol. 26 No. 4



TECH BRIEFS

ENGINEERING SOLUTIONS FOR DESIGN & MANUFACTURING



Sensors Expo
Preview

Product
of the Year
Winners

Photonics
Tech Briefs

Motion Control
Tech Briefs

REFERENCE

COPY APR 10 2002

KSC LIBRARY

*****CAR-RT LQT**C-000

00003764545 NB 0102


LOU UFFNER

LIBRARIAN

IDI

LIBRARY C

KENNEDY SPACE CENTER FL 32899-0001




44

0001

3974-15



Your **ni.com**TMplete Resource



Reduce Your Development Time with National Instruments

No matter the industry, quickly bringing new, higher quality products to market demands reliable, accurate measurement systems to validate designs and test products. Build these systems quickly with National Instruments software and hardware. To get started, visit ni.com/info and enter an info code below.

- Read a white paper on managing and analyzing technical data (info code: nast00)
- Review the fundamentals of fast Fourier transform with an interactive, multimedia tutorial (info code: naqr00)
- See a demonstration on developing a customizable test system for fuel cells (info code: nawv00)

ni.com



(800) 433-3488


Fax: (512) 683-9300 • info@ni.com

These Books Are Not For Sale®

They're **FREE** to people like yourself, who need to know!

**Reserve Your New,
Hardbound
Made In The USA
Handbook
and Encyclopedia™
Today!**

- ✓ Temperature
- ✓ Pressure
- ✓ Load Cells
- ✓ Data Acquisition
- ✓ Humidity
- ✓ pH & Conductivity
- ✓ Panel Meters
- ✓ Controllers
- ✓ Recorders
- ✓ Flow
- ✓ Thermocouples
- ✓ RTD's
- ✓ Thermistors
- ✓ Connectors
- ✓ Level
- ✓ 2 Volumes, Over 3,000 Pages
- ✓ Full-Color, Hardbound Handbooks With Prices



From OMEGA's 96-page New Horizons®

13 Collection Series

To Request Your DILBERT™ Deck Card Pack, Dial: 1-(203)-329-1266

Get Your Dilbert Card Deck **Circle** No. 501

DILBERT™ by Scott Adams

MY INVENTION WILL LET ME SEARCH THE SERVICE INDUSTRY'S SPACE-TIME CONTINUUM.

PLUMBER, ROOFER, CARPENTER, ELECTRICIAN.

WEREN'T YOU SUPPOSED TO FIX MY FURNACE IN 1991?

YOU'RE MY NEXT HOUSE.

Dilbert Decks No. 13 & 14 Available

Online Info at: omega.com/dilbert

ORDER ONLINE!

**Overnight Delivery!
Over 100,000 Process
Control Products Online!**

omega.com®
— OMEGA —

1-888-82-66342®
1-888-TC-OMEGA®



e-mail: info@omega.com

©COPYRIGHT 2002 OMEGA ENGINEERING, INC. ALL RIGHTS RESERVED.


OMEGAfax™ 24-Hour-a-Day On-Demand Publishing System — Call 1-800-848-4271
to request product information. Simply enter the document number associated with the item.



CO₂ Laser Applications of the Month



▲ Drilling Plastic Nozzles with CO₂ Lasers



250 & 100 micron hole sizes drilled with a Synrad 48-2 CO₂ laser with 20 watts of power.

Lasers excel at drilling small holes (<0.01" in diameter). In fact, in most cases, the smaller the diameter, the better, down to a minimum size of about 50 microns. These holes can be directly drilled in a range of materials without the need for trepanning, resulting in shorter drilling times and highlighting one of the unique characteristics of the laser - one laser and one focused spot diameter can produce a range of hole sizes.

By using a burst or train of pulses, a precise amount of energy is delivered to the material. The final hole diameter will depend on the plastic's inherent heating and wavelength absorption characteristics, as well as the gas pres-

sure used, and size of the focused beam. The number of pulses, duration of the pulse, and pulse frequency also enter into the equation. Small diameter increases can be made by altering the pulse numbers, larger ones by changing pulse duration and/or frequency. Changing the power is optional, and in many cases, the power input can be held at a constant value.


The plastic nozzles in the photo to the left were drilled with a Synrad sealed CO₂ laser. The focused spot size of the laser was around 200 microns, but hole diameters ranged from 75 to over 300 microns. The use of additional pulse power can be used to enlarge the hole by conduction effects.

▲ Laser Welding Stainless Steel Battery Contacts

The fine control of the laser is once again highlighted in this welding application. The 0.01"-thick contact was welded to the main body with two spot welds. The spot welds provide excellent strength, while ensuring that the battery's internal components are not overheated during the process. In addition, the weld only partially penetrates the underlying thickness, so that the battery casing remains sealed.




Contacts welded with Synrad's 200W sealed CO₂ laser.



Close-up of two spot welds.

▲ Laser Marking Quartz

This piece of 0.01"-thick quartz needed to be marked with small alphanumeric characters. Because of the thin size of the test sample, problems with heat build-up and cracking could have potentially affected the results of the application. However, by careful selection of laser parameters - not only speed and power, but resolution, font and character spacing - a highly readable mark was produced.




This quartz was marked with only 5 watts of power at 15" per second. Actual character height is 0.04".

Discover more CO₂ laser applications!
Sign up for our monthly online
Applications Newsletter at
www.synrad.com/signup1

All applications on this page were processed at Synrad's Applications Laboratory. Synrad, the world's leading manufacturer of sealed CO₂ lasers, offers free process evaluations to companies with qualified applications. Call 1-800-SYNRAD1 for more information.

A DECADE OF DOMINANCE



**#1 OVERALL PERFORMANCE
10 YEARS IN A ROW!**

DISTRIBUTOR EVALUATION STUDY, 1992-2001

**www.
Digi-Key[®]
.com**

**1-800-DIGI-KEY
www.digikey.com**



FEATURES

- 22 Application Briefs
- 27 A Sneak Preview of Sensors Expo

SOLUTIONS



- 20 Books and Reports
 - 20 The Complexity of the Diagnosis Problem
 - 20 Design Concepts for the ISS TransHab Module
 - 20 Characteristics of Supercritical Transitional Mixing Layers



- 32 Technology Focus: Sensors
 - 32 Electrometer for Triboelectric Evaluation of Materials
 - 34 Infrared CO₂ Sensor With Built-In Calibration Chambers
 - 34 Solid-State Potentiometric CO Sensor
 - 35 Planetary Rover Absolute Heading Detection Using a Sun Sensor
 - 36 Concept for Utilizing Full Areas of STJ Photodetector Arrays
 - 38 Development of Cognitive Sensors



- 39 Electronic Components and Systems
 - 39 Enabling Higher-Voltage Operation of SOI CMOS Transistors
 - 40 Estimating Antenna-Pointing Errors From Beam Squints



- 43 Software
 - 43 Advanced-Fatigue-Crack-Growth and Fracture-Mechanics Program
 - 44 Software for Sequencing Spacecraft Actions
 - 44 Program Distributes and Tracks Organizational Memoranda



- 45 Materials
 - 45 Flat Membrane Device for Dehumidification of Air




- 47 Mechanics
 - 47 Inverted Hindle Mount Reduces Sag of a Large, Precise Mirror
 - 48 Heart-Pump-Outlet/Cannula Coupling



- 50 Bio-Medical
 - 50 Externally Triggered Microcapsules Release Drugs *In Situ*
 - 52 Combinatorial Drug Design Augmented by Information Theory



- 54 Physical Sciences
 - 54 Multiple-Path-Length Optical Absorbance Cell
 - 56 Model of a Fluidized Bed Containing a Mixture of Particles



22



27



77


DEPARTMENTS

- 12 Commercial Technology Team
- 14 UpFront
- 16 Reader Forum
- 18 Who's Who at NASA
- 24 Technologies of the Month
- 82 Advertisers Index

NEW FOR DESIGN ENGINEERS


- 77 Products/Software
- 78 Literature

SPECIAL SUPPLEMENT




1a - 14a Photonics Tech Briefs

Follows page 42 in selected editions only.



"Multiphysics and CAD support capabilities make ALGOR a very important player in the MEMS simulation industry."

-Walied Moussa, Ph.D.,
University of Alberta, Edmonton,
Alberta, Canada



Leading MEMS Researcher Collaborated with ALGOR to Advance Automotive MEMS Research


The University of Alberta is a leader in the field of Micro Electro Mechanical Systems (MEMS) and future home of the Canadian National Institute for Nanotechnology (NINT), a \$120 million, 180,000-sq. ft. research facility. NINT will support MEMS research with internship programs and by making its laboratory and production facilities accessible to other organizations.

University faculty and students are using ALGOR FEA software in their studies of MEMS devices. In one recent experiment, university faculty collaborated with ALGOR on an experimental automotive gas sensor. Through research like this, the NINT helps develop MEMS for industry use.

THE CHALLENGE: To design a MEMS micro-heater for an automotive gas sensor array that can withstand high temperatures. Automotive gas sensor arrays make engines burn more efficiently by sampling and adjusting combustion gasses. Each sensor functions at a unique temperature, which is controlled by a micro-heater. Simulating the thermal stresses for the MEMS device is critical to ensuring its performance.

THE SOLUTION: A finite element heat transfer analysis was performed on the micro-heater and the resulting maximum temperature agreed with experimental results published in *Sensors and Actuators* by Yaowu Mo, et. al. A linear stress analysis was then performed using the heat transfer analysis results to calculate the thermal expansion and stresses, which were high on the top surface near the center where the micro-heater attaches to the sensor. These results, which could not be easily obtained experimentally, indicate the need to optimize the sensor geometry to reduce the thermal stresses. Thus, engineers could optimize the design without creating expensive prototypes.

For this complete story and others, visit memsresearch.ALGOR.com



USA/Canada
1.800.48.ALGOR

France
0.800.918.917

Italy
800.783.132

Singapore
800.120.3775

United Kingdom
0.800.731.0399

ALGOR®

ALGOR, Inc.
150 Beta Drive
Pittsburgh, PA 15238-2932 USA
Phone 1.412.967.2700
Fax 1.412.967.2781

memsresearch@algor.com
memsresearch.ALGOR.com

autodesk
authorized developer

PTC
Enterprise
Software
Partner

Autodesk
Partner

CADKEY
KEY PARTNER

SOLID EDGE
VERSION 10.0.123

All trademarks may be trademarks or registered trademarks of their respective owners.

- 60 Refractive Secondary Concentrators for Solar Thermal Systems
- 61 Cold Flow Calorimeter
- 62 Information Sciences**
 - 62 Methodology for Tracking Hazards and Predicting Failures
 - 64 Estimating Heterodyne-Interferometer Polarization Leakage
 - 65 An Efficient Algorithm for Propagation of Temporal-Constraint Networks
 - 67 Software for Continuous Replanning During Execution




- 69 Motion Control Tech Briefs**
 - 69 Surface-Launched Explorers for Reconnaissance/Scouting
 - 70 Firmware for a Small Motion-Control Processor
 - 72 Gear Bearings and Gear-Bearing Transmissions
 - 74 Linear Dynamometer With Variable Stroke and Frequency

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

PRODUCT OF THE MONTH

The Toro analog I/O digital signal processing (DSP) card from Innovative Integration (Simi Valley, CA) controls 16 simultaneous channels of independent A/D and D/A conversion.



14

ON THE COVER



This full mold design was completed using SolidWorks and IMOLD for SolidWorks, a mold engineering solution from Manusoft Corp., Waconia, MN, that lets SolidWorks users design plastic injection molds. IMOLD for SolidWorks creates 3D, solids-based, parametric mold bases from vendor standards, and provides automatic pocketing for screws, pins, and bushings. For more information on this and other new products, see New on the Market on page 77.

(Image courtesy of Manusoft Corp.)


Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (222 Rose Wood Dr., Danvers, MA 01923). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+.00.

The Measurement System of the Future has Arrived!



Digital Transducers on a Network Bus

- Network Configuration Reduces Cabling
- Distributed Data Acquisition Increases Reliability
- Real-Time Data Correction Achieves Higher Accuracy



Integrated Transducer, Signal Conditioning, and Data Acquisition

- Simplifies System Calibration
- Reduces Size and Weight
- Shortens Setup and Tear-Down Time

Network Sensors - Endevco is an established world leader in the development of innovative sensor technology. Our new network bus packages miniature electronics with sensors to provide high-speed, networked digital output. This technology will replace large bundles of cables in existing flight test and structural test applications. Installations will no longer be cumbersome and expensive. Call or email us today!



WHAT CAN WE DO FOR YOU TODAY?

applications@endevco.com
800/982-6732 • 949/661-7231fax

MEGGITT

www.endevco.com

ENDEVCO

©2002 EDS. EDS and Solid Edge are registered marks and EDS & Design and EDS Solved & Design are trademarks of Electronic Data Systems Corporation or its subsidiaries.



With Solid Edge, you design with insight.

- Just think what Edison could have done with Solid Edge® Insight. Intuitive, powerful design tools with built-in knowledge sharing, right out of the box. Solid Edge's visionary technology adds engineering data extensions to Microsoft® document management to ensure first-time fit, cut costs and reduce time-to-market. Solid Edge offers specialized toolsets for your industry. And it's backed by EDS for support and stability. So get the edge. You'll electrify your competition. Visit www.solidedge.com or call 877-342-5847.





Feeling pressured?
We can help.

Announcing MSC.Professional Services—
from the experts in engineering analysis.

Let us take the weight off. We realize how important it is for you to get results. So we work hard to help you streamline your product development process. Call now, we'll show you what we know. We'll listen. We'll ask. And we'll propose the right solution.

Put MSC.Professional Services on your team today and we'll start taking the pressure off, fast.

FOR MORE INFORMATION:

www.engineering-e.com
1.888.817.ECOM

SOFTWARE

World's leading simulation software.

SYSTEMS

High performance computing for complex analysis.

SERVICES

Expert solutions for the most challenging problems.

engineering-e.com



For Free Info Circle No. 539 or
Enter No. 539 at www.nasatech.com/rs

Published by **Associated Business Publications**
Publisher **Joseph T. Pramberger**
Editor/Associate Publisher **Linda L. Bell**
Editor, Market Focus Editions **Ashli K. Riggs**
Associate Editor/Internet Editor **Laura Raduta**
Production Manager **Joanne Gaccione**
Assistant Production Manager **John Iwanciw**
Art Director **Lois Erlacher**
Senior Designer **Christopher Coleman**
Circulation Manager **Hugh J. Dowling**

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Hauppauge, NY 11788

Technical/Managing Editor **Ted Selinsky**
Sr. Technical Analyst **Dr. Larry Grunberger**
Art Manager **Eric Starstrom**
Staff Writers/Editors **Dr. Theron Cole, George Watson**
Graphics **Robert Simons**
Editorial & Production **Joan Schmiemann, Becky D. Bentley**

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:
Administrator **Sean O'Keefe**
Director, Commercial Technology **Dr. Robert Norwood**
Publications Director **Carl Ray**

*For a complete list of staff e-mail addresses,
visit www.abpi.net*

ASSOCIATED BUSINESS PUBLICATIONS INTERNATIONAL
317 Madison Avenue, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

Chairman/Chief Executive Officer **Bill Schnirring (bill@abpi.net)**
Vice Chairman/Chief Operating Officer **Domenic A. Mucchetti**
MIS Manager **Ted Morawski**
Webmaster **Albert Sunseri**
Director of Electronic Products **Luke Schnirring**
eStrategy Director **Andrew Runk**
Credit/Collection **Felecia Lahey**
Human Resources Manager **Lourdes Del Valle**
Accounting Manager **Sylvia Ruiz**
Office Manager **Alfredo Vasquez**

NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES

Headquarters (212) 490-3999
CT, MA, NH, ME, VT, RI, Eastern Canada **Ed Marecki**
at (401) 351-0274
NJ, NY, PA, DE **Jim Oot**
at (973) 983-2757
VA, MD, DC, NC, SC, GA, FL, AL, TN, MS, LA, AR, OK, TX **Bill Manning**
at (770) 971-0677
MN, ND, SD, WI, IL **Bob Casey**
at (847) 223-5225
IN, KY, MI, OH, MO, KS, IA, NE, Western PA & NY, Central Canada **Chris Casey**
at (847) 223-5225
N. Calif., CO **Bill Hague**
at (800) 830-4351
WA, OR, ID, MT, WY, UT, NV, Western Canada **David Chew**
at (650) 726-2128
S. Calif., AZ, NM **Tom Boris**
at (949) 642-2785
Internet Advertising **Luke Schnirring**
at (212) 490-3999
Postcard/Literature Advertising **John Waddell**
at (212) 490-3999
Reprints **Jeannie Martin**
at (866) 879-9144

Portable Workstations

**ruggedized
multi-slot
multi-drive bay
sunlight readable LCD**



For more than a decade, BSI has provided custom solutions for field service and mobile computer applications with our multi-slot portables. BSI's portables pack the full power of a desktop workstation into a ruggedized, compact aluminum chassis. They are optimized for single or dual-processor and support industry standard add-on cards and components.

Visit our web site or call us to see why major defense contractors and the National Guard choose BSI portables for their field applications.



Broadax Systems, Inc.

17539 E. Rowland Street . City of Industry, CA 91748 . tel: 626-964-2600 . fax: 626-964-2665

1-800-872-4547
GSA# GS-35F-0496K
www.bsicomputer.com

Every engineer knew what was wrong with product development.
Then suddenly, it was theirs to change.



Product First™

The Adventure Begins

From the producers of Pro/ENGINEER® comes an exciting new tale of product development. Starring engineering in the leading role.

WARNING: CONTAINS
STRONG PRODUCT
DEVELOPMENT CONTENT



PTC®
Shaping Innovation

COMING JUNE 18 TO ENGINEERS EVERYWHERE
RESERVE YOUR FREE TICKET AT WWW.PTC.COM/GO/ENGINEERING

A PRODUCTION OF PTC. ALL CHARACTERS AND EVENTS ARE INTENDED TO PUT ENGINEERS AT THE CENTER OF PRODUCT DEVELOPMENT. ©2002 PARAMETRIC TECHNOLOGY CORPORATION, PTC AND ITS LOGO, SHAPING INNOVATION, PRO/ENGINEER, AND PRODUCT FIRST ARE TRADEMARKS OR REGISTERED TRADEMARKS OF PARAMETRIC TECHNOLOGY CORPORATION OR ITS SUBSIDIARIES IN THE UNITED STATES AND IN OTHER COUNTRIES.

NASA Commercial Technology Team

NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC) for Technology Transfer. Call (609) 667-7737 for the FLC coordinator in your area.

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center

Selected technological strengths: Information Technology; Biotechnology; Nanotechnology; Aerospace Operations Systems; Rotorcraft; Thermal Protection Systems.
Carolina Blake
(650) 604-1754
cblake@mail.arc.nasa.gov

Dryden Flight Research Center

Selected technological strengths: Aerodynamics; Aeronautics Flight Testing; Aeropropulsion; Flight Systems; Thermal Testing; Integrated Systems Test and Validation.
Jenny Baer-Riedhart
(661) 276-3689
jenny.baer-riedhart@dfrc.nasa.gov

Goddard Space Flight Center

Selected technological strengths: Earth and Planetary Science Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Remote Sensing; Command.
George Alcorn
(301) 286-5810
galcorn@gsfc.nasa.gov

Jet Propulsion Laboratory

Selected technological strengths: Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.
Merle McKenzie
(818) 354-2577
merle.mckenzie@jpl.nasa.gov

Johnson Space Center

Selected technological strengths: Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.
Charlene E. Gilbert
(281) 483-3809
commercialization@jsc.nasa.gov

Kennedy Space Center

Selected technological strengths: Fluids and Fluid Systems; Materials Evaluation; Process Engineering; Command, Control and Monitor Systems; Range Systems; Environmental Engineering and Management.
Jim Aliberti
(321) 867-6224
Jim.Aliberti-1@ksc.nasa.gov

Langley Research Center

Selected technological strengths: Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Sam Morello
(757) 864-6005
s.a.morello@larc.nasa.gov

John H. Glenn Research Center at Lewis Field

Selected technological strengths: Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Larry Viterna
(216) 433-3484
cto@grc.nasa.gov

Marshall Space Flight Center

Selected technological strengths: Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Vernotto McMillan
(256) 544-2615
vernotto.mcmillan@msfc.nasa.gov

Stennis Space Center

Selected technological strengths: Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Kirk Sharp
(228) 688-1929
kirk.sharp@ssc.nasa.gov

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

Carl Ray
Small Business Innovation Research Program (SBIR) & Small Business Technology Transfer Program (STTR)
(202) 358-4652
cray@mail.hq.nasa.gov

Dr. Robert Norwood
Office of Commercial Technology (Code RW)
(202) 358-2320
rnorwood@mail.hq.nasa.gov

John Mankins
Office of Space Flight (Code MP)
(202) 358-4659
jmankins@mail.hq.nasa.gov

Terry Hertz
Office of Aero-Space Technology (Code RS)
(202) 358-4636
thertz@mail.hq.nasa.gov

Glen Mucklow
Office of Space Sciences (Code SM)
(202) 358-2235
gmucklow@mail.hq.nasa.gov

Roger Crouch
Office of Microgravity Science Applications (Code U)
(202) 358-0689
rcrouch@hq.nasa.gov

Granville Paules
Office of Mission to Planet Earth (Code Y)
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

Wayne P. Zeman
Lewis Incubator for Technology
Cleveland, OH
(216) 586-3888

B. Greg Hinkebein
Mississippi Enterprise for Technology
Stennis Space Center, MS
(800) 746-4699

Julie Holland
NASA Commercialization Center
Pomona, CA
(909) 869-4477

Bridgette Smalley
UH-NASA Technology Commercialization Incubator
Houston, TX
(713) 743-9155

John Fini
Goddard Space Flight Center Incubator
Baltimore, MD
(410) 327-9150 x1034

Thomas G. Rainey
NASA KSC Business Incubation Center
Titusville, FL
(407) 383-5200

Joanne W. Randolph
BizTech
Huntsville, AL
(256) 704-6000

Joe Becker
Ames Technology Commercialization Center
San Jose, CA
(408) 557-6700

Marty Kaszubowski
Hampton Roads Technology Incubator (Langley Research Center)
Hampton, VA
(757) 865-2140

Paul Myrda
NASA Illinois Commercialization Center
West Chicago, IL
(630) 845-6510

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

Joseph Allen
National Technology Transfer Center
(800) 678-6882

Ken Dozier
Far-West Technology Transfer Center
University of Southern California
(213) 743-2353

James P. Dunn
Center for Technology Commercialization
Westborough, MA
(508) 870-0042

B. David Bridges
Southeast Technology Transfer Center
Georgia Institute of Technology
(404) 894-6786


Gary Sera
Mid-Continent Technology Transfer Center
Texas A&M University
(409) 845-8762

Charles Blankenship
Technology Commercialization Center
Newport News, VA
(757) 269-0025

Pierrette Woodford
Great Lakes Industrial Technology Transfer Center
Battelle Memorial Institute
(216) 898-6400

NASA ON-LINE: Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622.



© David Corio

"Engineering and technology development are quickly moving towards a more global outlook and IEEE is clearly international.

Being a member of a worldwide professional organization will greatly enhance your career."

Dr. Ronald M. Sega, IEEE Fellow
Director, Defense Research and
Engineering, U.S. Department of Defense




IEEE: 377,000 members in 150 countries. Join us.
www.ieee.org/apply

PRODUCT OF THE MONTH

The Toro analog I/O DSP card from Innovative Integration, Simi Valley, CA, is designed for servo control and data acquisition applications. Its 150-MHz, 32-bit, floating-point DSP controls 16 simultaneous channels of independent A/D and D/A conversion. The unit's 32/64-bit PCI bus is capable of up to 264 Mbytes/second data bursts. On-chip resources include two 32-bit counter/timers, 16 DMA channels, 64 kbytes of dual-access SRAM, and a prioritized interrupt controller. The Toro features a choice of triggering modes that allows the user to select start/stop trigger events from on-chip timers, external trigger, and analog threshold on synchro signals from other cards. A built-in real-time event log in the firmware provides the user with a record of trigger times and user-defined events.

For Free Info Circle No. 703 or Enter No. 703 at www.nasatech.com/rs



2001 Product of the Year Winners

On March 18, the winners of *NASA Tech Briefs'* Readers' Choice Product of the Year Awards were announced in Chicago at a special reception held during National Manufacturing Week. Here are the winners, as chosen by the readers of *NASA Tech Briefs*:

Gold Winner & Product of the Year

Version 5 VX CAD/CAM Software from VX Corporation (Palm Bay, FL)

The design-through-manufacturing software eliminates the gap between CAD and CAM packages, and features manual




and automatic healing of imported solid models, and direct import/translation of Pro/E, Catia, and Parasolid files. (www.vx.com)



Silver Winner

Mathcad® Client Software from MathSoft Engineering & Education (Cambridge, MA)


The software allows sharing and collaborating on Mathcad-created content across the Internet, and via corporate extranets and intranets. Users can interact with technical documents and applications, including Mathcad worksheets, electronic books, and MathML documents. (www.mathsoft.com)



Bronze Winner

Measurement Studio™ 6.0 Measurement Software from National Instruments (Austin, TX)


Engineers use these tools to create test, measurement, and control applications in various programming languages such as LabWindows/CVI, Visual Basic, and Visual C++. Data is displayed in real-time 2D and 3D graphs and charts. (www.ni.com)



Next Month in NTB

The May issue will include highlights of the Product of the Year Awards reception, including photos and comments from our winners. Also, our feature on engineering on the Internet will include insights from leading vendors on which Web-based tools manufacturers are really using, and why e-engineering is still not a clearly defined market.





Sooner or later, every design becomes 3D.
This is an argument for sooner.



LASER WELDER BY INCISION LASERTEC

Introducing **Autodesk Inventor™ Series**. We've paired the groundbreaking Autodesk Inventor 3D technology with the AutoCAD®-based Autodesk® Mechanical Desktop®, creating a flexible design solution that helps you move from 2D to 3D without giving up your current system. For Dr. Markus Bohrer, General Manager of Incision Lasertec, the breakthrough adaptive technology and industry-leading DWG compatibility has helped increase productivity: "With Inventor we finished our latest, highly complex machine in only 8 months. Without Inventor it would have taken us twice the time." Are you ready for 3D made easy? Experience the freedom to design without limits. Visit www.autodesk.com/inventorseries to find out more.

autodesk®

©2002 Autodesk, Inc. Autodesk, the Autodesk logo, AutoCAD, Autodesk Inventor, and Mechanical Desktop are either registered trademarks or trademarks of Autodesk, Inc., in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders.

For Free Info Circle No. 507 or Enter No. 507 at www.nasatech.com/rs

The solution you're looking for may be right at

your fingertips.

The solution is **Inastomer**, an exquisitely fine, elastic material for precise pressure sensing.

Choose the PX series for high density, high capacity analysis. Over 16,000 points of measurement, 0.5mm of resolution, and only 0.621mm thick. These pressure distribution sheets offer 3-dimensional, 7 color displays, with rotatable views (64x64mm to 640x640mm).

For the same great qualities in a smaller size, choose flexible adhesive pressure sensors. They are perfect for soft touch products and contact pressure applications such as robotics and mechanical equipment. Standard sizes are 2.9mm to 5.9mm square and 10mm round, but custom shapes and sizes are welcome.

IESF-X

SF-X

Also offering
the SS-13
stroke
sensor
with
4.0kgf
max
load!

PX

Call us to find *your* solution!

1-800-275-4899

www.cuistack.com CUI STACK

Reader Forum

Reader Forum is dedicated to the thoughts, concerns, questions, and comments of our readers. If you have a comment, a question regarding a technical problem, or an answer to a previously published question, post your letter to Reader Forum on-line at www.nasatech.com, or send to: Editor, *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017; Fax: 212-986-7864. Please include your name, company (if applicable), address, and e-mail address or phone number.

I'm looking for a device that can read the position of a laser beam on a screen or panel where the laser beam is pointing. The matrix has to be about 12" x 12" with a resolution of at least 0.1" or better. Thanks for any information.

George May
host@hsweb.net

Does anyone know who manufactures the silica tiles used on the Space Shuttle? Thanks.

Oddvar Dahle
oddvard@online.no

(Editor's Note: Oddvar, there are actually three types of tiles that have been used on the Space Shuttle orbiters — the chief manufacturer of many of these is Lockheed Missiles & Space Division in Sunnyvale, CA. In addition, there is insulation blanket material, a quilted composite fabric, that has replaced most of the original low-temperature reusable surface insulation (LRSI) tiles. You can get complete information on all of the Thermal Protection System (TPS) components of the shuttle orbiters — including the protective tiles — by visiting the Shuttle Reference Manual Web site at: www.spaceflight.nasa.gov/shuttle/reference/shutref/orbiter/tps/.)

We are developing a device that will be used to detect high pressure and low pressure in the range of 10 to 40 mmHg. We are using a plastic tube 2.5 mm thick filled with water — infrared optosensors detect the upper and lower limits. It is working fine, except for the water drops that moisten the internal surface of the tube, and for the meniscus that comes presumably from surface tension and adhesive forces. These give us false readings. Any ideas on how to fix this problem would be appreciated.

Julian L. Ortuondo
julianor@att.net

I need to find a drive belt, compound-based o-ring as a redundant safety strap in case of mechanical fastener failure. Can anyone direct me to a resource for such information or statistics? Thank you.

Ken McMahon
ken@pivotgroup.com

Digital Solid State Recorder



Compact • Ruggedized 50 GB Airborne Data Recorder

80% less weight*

90% less power*

75% less space*

30% less cost*

*Compared to AMPEX DCRsi™ 240

Low power, 50 watts: 28VDC

Compact - 8 lbs; 8.7" x 6" x 3.75"

High Speed: 480Mbits/sec total transfer rate

Modular storage, easy upgrade - 32 PCMCIA cards

For airborne flight test digital data recording

Digital imagery recording for tactical weapons pods such as LANTIRN and TARPS

Integration into high resolution sensor packages for direct digital recording

If it's worth a mission, it's worth a

TEAC®

www.teac-recorders.com

Tel. 323-727-4866 • Fax: 323-727-4877

e-mail: airborne@teac.com

© 2002 TEAC America, Inc. All trademarks are property of their respective companies.

For Free Info Circle No. 506 or Enter No. 506 at www.nasatech.com/rs

SMALLEST STABLE CABLE™ EVER

High Performance Microwave Cable Assemblies

- Phase & IL stable over temperature
- 4°K to 900°C temperature range
- Reliable under extreme shock, vibration and radiation
- Premium SiO₂ dielectric
- Stainless steel jacket

ENGINEERING EXPERTISE FOR
DIVERGENT APPLICATIONS



KAMAN
www.stablecable.com
719-635-6954

For Free Info Circle No. 404 or
Enter No. 404 at www.nasatech.com/rs

Who's Who at NASA

Sharon K. Miller, Senior Research Engineer, Glenn Research Center

Sharon K. Miller is the senior research engineer in the Electrophysics Branch of the Power and Onboard Propulsion Division at NASA's Glenn Research Center, Cleveland, OH. She has used atomic oxygen to restore damaged artwork and is currently working on a project that extends the life of the solar array blanket on the space station.



NASA Tech Briefs: How did you first get involved with the use of atomic oxygen to restore art?

Sharon K. Miller: We were actually approached by the Cleveland Museum of Art through our commercial technology office. They were looking for ways to remove some varnishes that couldn't be removed by conventional solvents. Because of some space work that we had done using atomic oxygen to test the durability of some materials, we found that there was a reaction between atomic oxygen and carbon, which is contained in some of the varnishes and solvents they were using. Fire damage to art was also a large problem and we found it could be removed using atomic oxygen.

NTB: What is atomic oxygen and how is it applied?

Miller: Atomic oxygen is made in space by the ultraviolet radiation from the Sun breaking up the oxygen atoms that are in the atmosphere and which are very chemical reactant. We wanted to combine them with something so that they would react with the surfaces that contained carbon and convert them to carbon monoxide and carbon dioxide, which is left as a gas. We can generate atomic oxygen here on Earth in vacuum chambers using electric discharge, and we also have a technique

by which we can create atomic oxygen in the air; it uses helium as a surrounding gas to prevent it from recombining.

NTB: Are there any other uses for the application of atomic oxygen?

Miller: There are a lot of things that it could be used for. It's good for sterilization. It could remove mold, and also the nutrients that molds need to grow, so it can affect the sterilized surface we use for medical implants. We are also looking at it as a way to provide a fine texture on surfaces for light scattering. For plastic surgery, you can make a surface that is rough for cells to attach to so you can foster cell growth. Cleveland Clinic is doing some studies to see whether it's a good surface for growing bone cells.

NTB: Can you explain more about the solar array blanket project?

Miller: A solar array blanket is the surface that the solar cells are bound to; it's sort of the structural member. It's a blanket because it's flexible. The solar array is huge — it's like a football field in length — and to get it up in the space shuttle, it has to be folded up. The solar array blanket is actually just a big sheet of polyamide, which is a plastic. The cells are mounted onto the surface of the plastic, and the whole sheet is folded up like a blanket and taken up and hurled while in orbit. It makes for a flexible surface and has the right kind of structural properties for what they want, but atomic oxygen does react with the polymer so you would lose the structural stability in less than a year if it weren't protected. We received a Space Act Award for finding a protective coating that would allow that surface to stay durable for the 15 years that it's supposed to last for the International Space Station.

A full transcript of this interview appears on-line at www.nasatech.com/whoswho. Ms. Miller can be reached at sharon.k.miller@grc.nasa.gov.

Six-axis Force/Torque Sensors

Strong Transducers With Low-Noise Outputs Measuring F_x , F_y , F_z , T_x , T_y , T_z .

**NEW PCI, cPCI
& PCMCIA Interfaces**



Shown are ATI six-axis transducers from 17mm dia. to 330 mm dia.

ATI manufactures a variety of extremely robust six-axis Force/Torque (F/T) sensors that provide low-noise, high-resolution signals with output speeds of up to 10kHz and factors of safety up to 27 times measurement range. Since 1983, ATI has provided thousands of customers with F/T's ranging from the smallest six-axis sensor in the world (17 mm diameter) to sensors measuring thousands of pounds. The F/T can provide data via voltage outputs, RS-232 serial or interface with either ISA, PCI, PCMCIA or cPCI buses. ATI is developing interfaces to Firewire, VXI, USB, DeviceNet and Ethernet. The F/T can also interface with analog data acquisition systems (seven channels required).

For more information, contact Milton Gore at mgore@ati-ia.com or extension 132.

Our Products Also Include:

- | | |
|---------------------|-------------------------------------|
| Quick-Change | Robotic Tool Changer |
| Protector | Robotic Crash Protection Device |
| Speedeburr | Robotic Deburring Tool |
| Compensator | Automated Assembly Alignment Device |

**ATI INDUSTRIAL
AUTOMATION**
ISO 9001 Registered

Engineered Products for Manufacturing Productivity

Pinnacle Park, 1031 Goodworth Drive, Apex, North Carolina 27502 USA

Tel: +1.919.772.0115 • Fax: +1.919.772.8259

Email: info@ati-ia.com • www.ati-ia.com

World's Fastest CompactPCI Digitizers

CompactPCI Digitizers



Product of the Month

CompuScope 85GC

5 GS/s, 8 Bit
CompactPCI Digitizer



- 5 GS/s A/D Sampling on two Simultaneous Channels
- 500 MHz Bandwidth
- 8 Bit Resolution
- 100 Hz Repetitive Acquisition Rate
- Based on Advanced Tektronix Technology
- TV Triggering Capability
- CompactPCI Form Factor
- Software Development Kits for C/C++, MATLAB and LabVIEW

GaGe
A Tektronix Technology Company

1-800-567-GAGE ext:3405
www.gage-applied.com/ad/nasa302.htm

Outside the U.S. contact: Gage Applied, Inc.
Tel: +1-514-633-7447 Fax: +1-514-633-0770
e-mail: prodinfo@gage-applied.com

For Free Info Circle No. 403 or
Enter No. 403 at www.nasatech.com/rs



Books & Reports

Σ The Complexity of the Diagnosis Problem

A report presents a study of the complexity of an algorithm that performs model-based diagnosis of a complex hardware system. [In model-based diagnosis, an algorithm detects logical inconsistencies between observational data and a description (mathematical model) of the system.] In the study, the problem of detecting logical inconsistencies is transformed into the problem of finding prime implicants of a monotone Boolean function. This transformation enables utilization of the well-developed machinery of Boolean function theory, not directly accessible in the logical approach: one can work with monotone Boolean functions described by polynomial-size monotone circuits instead of attempting to deal with logical objects and performing exhaustive searches in order to extract all desired information. One especially notable result achieved in this study through the Boolean-function approach is the first analytical proof that the diagnosis problem is NP-complete. The report asserts that the discovery of the connection between diagnosis and the Boolean functions may afford new means to solve the diagnosis problem — in particular, to develop diagnostic algorithms that take super-polynomial amounts of time, in contrast to the exponential amounts of time heretofore needed to solve NP-complete problems.

This work was done by Farrokh Vatan of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "The Complexity of the Diagnosis Problem," access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Information Sciences category.
NPO-30315

⚙ Design Concepts for the ISS TransHab Module

Twelve reports present concepts for the design of structural and functional systems, subsystems, and components of the proposed TransHab module — an inflatable, lightweight habitation module that would be used by crewmembers of the International Space Station and would serve as a prototype of habitation modules for future spacecraft on long

missions (e.g., missions to Mars). The TransHab module would be a unique hybrid structure that would combine the packaging and mass efficiencies of an inflatable structure with the advantages of a load-bearing hard structure. The governing design concept is one of a high degree of integration and multifunctionality of all parts of the TransHab system. The reports include sketches (some containing estimated dimensions) and discussions of engineering requirements. There are also numerous discussions of human factors (psychological, social, and physiological) that affect many aspects of design. Although the reports address issues specific to the TransHab module, some of the concepts discussed may be applicable to the design of temporary or transportable housing for use on Earth.

This work was done by Kriss J. Kennedy and Jasen L. Raboin of Johnson Space Center and Constance M. Adams, Kurt Bush, and Jose Christian of Lockheed Martin. To obtain copies of the reports, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Machinery/Automation category.
MSC-23090/91/181-187/189-191


⚙ Characteristics of Supercritical Transitional Mixing Layers

This report describes a study of three-dimensional, temporal mixing layers between different fluids initially flowing at different velocities under supercritical conditions. The study involved direct numerical simulations by use of a validated mathematical model of high-pressure-fluid behavior that has been described in a number of prior NASA Tech Briefs articles. In some cases, the fluids were heptane and nitrogen; in other cases, they were hydrogen and oxygen. In all these simulations, the mixing layers underwent transition to turbulence.

This work was done by Josette Bellan and Nora Okong'o of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Characteristics of Supercritical Transitional Temporal Mixing Layers," access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category.
NPO-30292



Our
corrosion-resistant alloy
will keep you and the planet
happy.



Carpenter Custom 465® stainless. Strength, toughness and corrosion resistance without a harmful coating. Choosing the best material for your design doesn't have to mean hurting the environment. Carpenter Custom 465 stainless is a new steel alloy that delivers a unique combination of strength, fracture toughness and corrosion resistance. All without using environmentally-damaging cadmium or chromium coatings. Custom 465 stainless is available in fine wire, strip, billet, as well as finished bar, making it perfect for dozens of applications. And just right for the planet. For more details, call 1-800-654-6543. Or visit www.cartech.com



CARPENTER
Specialty Alloys

Engineered Materials for a Changing World


©2001 Carpenter Technology Corporation. All rights reserved.
Custom 465 is a registered trademark of Carpenter Technology Corporation.

For Free Info Circle No. 542 or Enter No. 542 at www.nasatech.com/rs

Web-Based Reporting System Monitors Shuttle Launch Preparations

WebFOCUS Web-based reporting system
Information Builders
 New York, NY
 212-736-4433
www.informationbuilders.com

The Shuttle Processing Directorate (PH) at NASA's Kennedy Space Center is responsible for preparing the shuttle for a safe and successful mission. Before each flight, all of the systems and components must be checked, tested, adjusted,



and, if necessary, repaired or replaced. To help manage the refurbishment process, PH integrated technology from Information Builders to develop the Insight System, a Web-driven reporting system that monitors contractor performance and reports on the status of the launch preparation effort.

Created as a final checkpoint to gauge mission readiness, "The Insight System reduces NASA's daily involvement in missions and increases the time engineers spend on analysis — a capability we did not possess before," according to Ron Phelps, project manager at Kennedy.

Insight had to complement NASA's existing mainframe-based Shuttle Processing Data Management System (SPDMS), accessing data in several different database formats, and tying together various NASA and contractor databases on different platforms. The WebFOCUS data publishing and reporting system provides users with reports via any standard Web browser, so Phelps used the system to construct an environment that allowed NASA to embed a link between its Web pages and data in the SPDMS.

The Insight System is being constructed in three phases. During Phase I, NASA developed a prototype to familiarize users with the basic capabilities and define data warehouse architecture. Phase II refined what was learned in the first phase by creating more reports and training users. Currently, Insight is entering Phase III, an ongoing process of creating final, production-ready reports and ensuring the warehouse contains all necessary data.

"At the end of Phase III, we'll have a production system in place serving several hundred users," said Phelps. "When it comes to the final countdown of a shuttle mission, Insight gives us confidence that we're ready for launch."


**For Free Info Circle No. 701 or
Enter No. 701 at www.nasatech.com/rs**

Global Positioning System Helps Pilots Fly Safer

Synthetic Vision Information System (SVIS)
Rockwell Collins
Cedar Rapids, IA
319-295-1000
www.rockwellcollins.com

In a partnership with NASA's Aviation Safety Program, Rockwell Collins has developed the Synthetic Vision Information System (SVIS), a visually based system designed to increase safety and terrain awareness during approach and departure operations. With SVIS, the typical view from the cockpit is augmented with a computer-generated display to give pilots artificial visibility in poor weather conditions. The synthetic views can be displayed head-up or head-down. "With global positioning system signals, pilots now know exactly where they are," said Michael Lewis, director of NASA's Aviation Safety Program. "Add super-accurate terrain databases and graphical displays, and we can draw three-dimensional moving scenes that will show pilots exactly what's outside."

Tunnel guidance is part of the display that creates a visual cue for pilots to relate to the intended flight path. This is then



overlaid with synthetic terrain images, which are generic and producible in current-generation avionics architectures. With the tunnel guidance system, pilots can fly complex procedures without creating additional pilot workload.

Pilots from the US Federal Aviation Administration (FAA), Boeing, Delta Air Lines, United Air Lines, and American Airlines participated in flight tests of the system. The pilots found the system to be controllable, comfortable, and easy to fly.

**For Free Info Circle No. 700 or
Enter No. 700 at www.nasatech.com/rs**



No Matter What You Test, Do It With Dewetron!



Our customers are testing everything from train cars to the Space Shuttle, from automobile airbags to oilwells...and the list keeps growing. Why? Maybe it's our plug-in signal conditioners that allow connection of *any signal, any sensor*. Or perhaps it's the fact that Dewetron systems are built on an open-architecture, COTS* computer platform, allowing easy upgrades and compatibility with all Windows® software and hardware.


Or it could be our software—so easy to use and yet so powerful—with brilliant on-line displays, full-color printing and one-click export to Excel®, MatLab®, ASCII, and several other popular formats. Of course, Dewetron machines are perfect platforms for LabVIEW® development, and they already include a National Instruments® A/D card connected to our high-isolation plug-in signal conditioners!

Above left to right – the DEWE-4000, DEWE-2010, and DEWE-3010 portable PC Instruments

Our basic models are also highly popular as portable industrial computers built to MIL-STD-810C for shock and vibration.

It could be any of these things - or maybe it's all of them. The bottom line is, if you're doing data acquisition any other way, you're missing a lot. Please take a look at Dewetron today. Start with our website, or give us a call and arrange a no-obligation demonstration at your facility.

Contact us today toll-free at **877-431-5166** (+1 401-364-9464 outside the USA), or visit us on-line at www.dewamerica.com/ntb



Plug-in signal
conditioners for
every signal,
every sensor



Just need a front-end? Check out our DEWE-RACK and DEWE-BOOK solutions for your notebook computer!

*COTS = Commercial, off-the-shelf.

For Free Info Circle No. 544 or Enter No. 544 at www.nasatech.com/rs

Technologies of the Month

Sponsored by **yet2.com**

For more information on these and other new, licensable inventions,
visit www.nasatech.com/techsearch

Minimizing Catalyst While Maximizing Electrode Performance

Pragmatic Vision International LLC

Platinum and other platinum group elements are used as catalysts in electrodes. Unfortunately, the high cost of platinum creates a large obstacle in the production of technologies such as proton-exchange-membrane (PEM) and direct methanol fuel cells, where the platinum is as much as 20% of the system cost. A fabrication process for catalytic electrodes can precisely place and form the catalyst on the electrode substrate, reducing the amount of expensive catalyst needed.

PVI's electrodes consist of conducting carbon fiber substrate and particles of catalyst. The technology is similar to electroplating, but rather than plating the entire substrate, the catalyst is targeted only to sites that have access to the channels in the gas diffusion layer. The catalyst can be deposited in any amount or concentration, in layers as thin as a single atom. As a result, there is virtually no wasted material.

Get the complete technology on this technology at:
www.nasatech.com/techsearch/tow/pragmatic.html
Email: nasatech@yet2.com
Phone: 617-557-3837

Low-Cost, High-Volume Ether Compound Production

Kao

Cosmetics, lubricants, solvents, emulsifiers, and detergents contain ether compounds, which are not easy to manufacture on a cost-to-volume basis. Kao has developed a manufacturing method that yields an ether compound at a high production rate in a single step. Central to the process is a reaction using a hydroxy compound with a carbonyl compound, or carbonyl compounds by themselves. The materials are reacted under a hydrogen gas atmosphere in the presence of a catalyst such as palladium or a palladium compound. Iridium, osmium, and rhenium can also be used, supported on a carrier such as carbon, silica-alumina, zeolite, alumina, or silica.

The process does not require solvents, but the reaction can be diluted with a solvent. This single-step manufacturing process enables ether compounds having large molecular weight or asymmetric structures to be produced in large volumes at low cost, making it suitable for use in high-volume applications.

Get the complete technology on this technology at:
www.nasatech.com/techsearch/tow/kao3.html
Email: nasatech@yet2.com
Phone: 617-557-3837

Thickening Agent Improves Paint Stability, Processing, and Clean-up

The Procter & Gamble Company



Non-aqueous suspensions such as inks, paints, and coatings have been thickened with clays, silica, and polymers. These thickeners, called *structurants*, rely upon interactions with formula components, which results in non-aqueous structures that can separate easily, be unstable, and be highly sensitive to any formula variation. A thickening agent called CLASS (Crystalline LAS Structurant) builds structure by interacting with itself, forming stable, non-aqueous compositions that are insensitive to pH and electrolytes.

The structuring particle is delivered as dry flake or pre-dispersed gel in a compatible solvent. Because it is water-soluble, the structure breaks down upon contact with water or surface moisture, which could enable faster, easier clean-up in applications with paint or ink.

Get the complete technology on this technology at:
www.nasatech.com/techsearch/tow/procterandgamble.html
Email: nasatech@yet2.com
Phone: 617-557-3837

Supercharger Improves Engine Performance

Bill Berlinger, Caterpillar



One method of improving engine performance compresses inlet air in the combustion chamber, "supercharging" the combustion process and increasing power output without increasing engine size. A new technology called the COM-


PREX Pressure Wave Supercharger provides compressed intake air without the delay of a turbocharger or the blower of a conventional supercharger.

COMPREX consists of a simple rotor with axially arranged cells, separate gas and air casings, a mantle, and bearing unit. Exhaust gas flows through the gas casing into the rotor. The quick opening of the rotor cells toward the high-energy exhaust gas creates a sonic pressure wave that compresses the fresh intake air allowing engine response to be improved even at lower engine speeds. The vehicle can now be driven in higher gears and at lower engine speeds with excellent acceleration.

Get the complete technology on this technology at:
www.nasatech.com/techsearch/tow/berlinger.html
Email: nasatech@yet2.com
Phone: 617-557-3837

FEMLAB[®]

— multiphysics in MATLAB[®]




FEMLAB[®] supplies highly sought-after new technology for the modeling and simulation of physics in all science and engineering fields. Its main attribute is the ease with which modeling can be performed and its unlimited multiphysics capabilities, in 1D, 2D and 3D — the perfect way to apply state-of-the-art numerical analysis to your expertise in modeling.

Order your free literature kit!



Visit www.comsol.com/ient or
call +1-781-273-3322





◀ The most common reactor for environmental protection, which we encounter or use everyday, is the catalytic converter in automobiles. In these monolithic catalysts, carbon monoxide and nitrous oxides are converted into relatively harmless species like carbon dioxide and nitrogen. To optimize the utilization of the expensive catalyst, it is important to be able to model the reactor at different operational conditions. In this FEMLAB model, mass and heat balances are coupled to compute temperature distribution and flowlines in the reactor.

◀ This square-shaped spiral inductor is used for bandpass filters in micro electro-mechanical systems (MEMS). The FEMLAB simulation takes the nonuniform current density in the coils into account to compute an accurate magnetic flux around the coils. The inductance of this inductor is 2.1 nH, which is obtained by integrating the magnetic energy. Using the programming language of FEMLAB for parametric analysis, you can find the correlation between the induction and the input parameters of the model.

◀ In the design of electrodes for water electrolysis, it is important to minimize the voltage losses at a given total current. FEMLAB modeling helps the engineer in the design of the electrode geometry and the current collector. The model gives the current density distribution and the potential distribution in the system. These results make it possible to avoid excessive degradation of the active electrode surface and overheating of the welds at the position of the current collector.

◀ When designing an electric motor it is important to design the rotor shaft so that no eigenfrequencies exist in the working range of the rotational speed. It is also important to study the shape of the eigenmode and not just the eigenfrequencies. In the eigenfrequency analysis, one end of the shaft is fixed and the other end is free to rotate and axially deform. The image shows deformation and rotation angle in the second eigenmode, using different visualization options like colormaps and scaling.

FEMLAB is a registered trademark of COMSOL AB.

FEMLAB KEY FEATURES

- Flexible and powerful graphical user interface
- Built-in user-friendly CAD tool for solid modeling in 1D, 2D and 3D
- Automatic mesh generation, adaptive mesh and multigrid
- Powerful solvers for linear, nonlinear and time-dependent systems of partial differential equations (PDEs)
- Extensive postprocessing capabilities
- Model Libraries with over fifty models fully documented from various engineering fields
- Ready-to-use application modes for different engineering fields
- Equation-based modeling for arbitrary systems of PDEs

FEMLAB PUTS YOU IN THE FRONTLINE

FEMLAB employs sophisticated numerical techniques developed by our staff of leading scientists in collaboration with industry experts from around the world. These professionals had a goal of making modeling available to every engineer and scientist. FEMLAB is the result of our commitment to putting engineering mathematics in a box.

Order your free literature kit!



Visit www.comsol.com/ient or call +1-781-273-3322



www.comsol.com

A Sneak Preview of Sensors Expo


The Spring 2002 Sensors Expo brings together a wide range of innovations shaping the sensing, MEMS, data acquisition, control, and communications industries. Held at the San Jose Convention Center from May 21-23, Sensors Expo will feature the latest advances in biosensors and bio-MEMS, intelligent systems and smart sensors, and nanotechnology, and will give visitors the chance to speak one-on-one with innovators.

Look for the following new products that will be on display. For more information on the show, visit www.sensorsexpo.com.


Airpax Thermal Sensing Products, Frederick, MD, will exhibit the VeriSense™ 3500 thermal sensors that offer typical accuracies of $\pm 1/4^\circ\text{C}$ at room temperatures and $\pm 3/4^\circ\text{C}$ over the 0°C to 100°C temperature range.

Housed in a TO-220 package, the sensors provide a voltage output and are suitable for a variety of applications requiring linear output. They eliminate the need for compensating electronics to correct for the non-linearity of thermistor-based sensors. **For Free Info Circle No. 761 or Enter No. 761 at www.nasatech.com/rs**

BOOTH 426



The INTELLEK® low-g accelerometer from Delphi Automotive Systems, Troy, MI, measures linear changes in acceleration with programmable scale factors from .75 g to 3 g. The micro-sized module combines a sensor and an integrated circuit in a 20-pin package. Features include a self-test diagnostic that



simulates actual acceleration when power is first applied, and operation from a single 5-volt power supply. **For Free Info Circle No. 765 or Enter No. 765 at www.nasatech.com/rs**

BOOTH 513

The RT12-4204™ seamless wireless sensor transceiver from Advanced Embedded Systems, Tucson, AZ, is a controller that converts a wired system into a wireless connection. It allows connection between any 4-20 mA, 0-5 VDC or 0-10 VDC sensor and a data logger, controller, or SCADA equipment, eliminating up to 20 miles of wiring. The transceiver accepts up to four analog inputs and two optically isolated inputs/open collector outputs. It also has the ability to act as a signal converter by allowing independent configuration between the INPUT and OUTPUT modules. **For Free Info Circle No. 760 or Enter No. 760 at www.nasatech.com/rs**

BOOTH 713

The MT2A miniature position transducer from Celesco Transducer Products, Chatsworth, CA, features a tensioned measuring cable designed for acceleration encountered in flight testing and automotive crash tests. Available in measuring ranges of 0-9", 0-15", and 0-30", the transducer is designed with 2-axis 360° rotation in its

BOOTH 318


mounting bracket. Also displayed in the booth will be the Jumo Midas pressure transmitters from JUMO Process Control, Coatesville, PA. The transmitters use a ceramic thick-film transducer that converts the pressure into a standardized voltage or current signal. They can be used in liquid and gaseous media. **For Free Info Circle No. 763 or Enter No. 763 at www.nasatech.com/rs**



Oceana Sensor, Virginia Beach, VA, introduces the TX3APN, tri-axial accelerometer, a transistor-packaged, hermetically sealed device that utilizes ceramic, shear structured sensing elements to measure vibration in three orthogonal directions. It features low input power requirements, and a 100-mV/g sensitivity of a frequency range of 1-10K on the z-axis, and 1-4K on the x and y-axis. Applications include machinery health monitoring, impact detection, structural acoustics, and pipe leak detection. **For Free Info Circle No. 775 or Enter No. 775 at www.nasatech.com/rs**

BOOTH 411

NEW Model 211 Temperature Monitor



The single channel Model 211 Temperature Monitor provides the accuracy, resolution, and interface features of a benchtop temperature monitor in an easy to use, compact instrument.

- One Sensor Input
- 0-10 V or 4-20 mA analog output
- Large 5-digit LED display
- RS-232C interface
- Supports diode and RTD sensors

Check out our 8-channel temperature monitor at www.lakeshore.com



Model 218
Temperature Monitor

LakeShore
1-800-394-2243
sales@lakeshore.com

For Free Info Circle No. 545 or Enter No. 545 at www.nasatech.com/rs


Sensors Expo Preview

Version 6.0 electromagnetic design and simulation software is available from Integrated Engineering Software, Winnipeg, Canada. Enhancements to the software's geometric modeler, CAD interoperability, and design optimization include a 2D mode that allows users to switch from 2D mode to 3D mode. Surfaces on the upgrade exist as NURBS and the segments define the boundary of the surface. Users also have

BOOTH 325

the ability to generate high-resolution 3D shaded geometry. The new version enables connection directly to five

leading CAD programs, enabling users to import models from SolidWorks, SDRC, Solid Edge, Pro/ENGINEER, and Autodesk products. For Free Info Circle No. 767 or Enter No. 767 at www.nasatech.com/rs



Kistler Instrument Corp., Amherst, NY, offers the ServoK-BEAM accelerometer, an analog force feedback sensor that utilizes a silicon micromachined variable capacitance sensing element. The sensor features 1,500 mV/g sensitivity and a resolution of 1 μ g. It is a calibrated unit that combines the sensing element and integrated electronics in a sealed aluminum housing. Four through-

BOOTH 519

holes enable the unit to be mounted to the

test structure with screws. The accelerometer operates from a single power supply between ± 6 and ± 15 VDC with 8 mA typical current consumption. For Free Info Circle No. 769 or Enter No. 769 at www.nasatech.com/rs

Fluorescence-based optical sensors from Ocean Optics, Dunedin, FL, include optrodes for analyzing pH in aqueous solutions and for use in *in vivo* procedures. The pH sensors operate using a fluorescein derivative, with pH measurement directly related to the magnitude of the fluorescein's fluorescing peaks. The optical sensor series includes chemical sensors that utilize sol-gel thin-film coatings. They connect to



BOOTH 1020

miniature fiber-optic spectrometers and a 470-nm Blue LED


light source for real-time sample analysis. For Free Info Circle No. 776 or Enter No. 776 at www.nasatech.com/rs

MicroStrain, Burlington, VT, will display the FAS-G inertial tracking device that leverages two solid-state MEMS accelerometers, an angular rate sensor, and embedded software tracking algorithms for performance over a 360° measuring range. Applications include robotics positioning, biomechanics joint angle tracking, dynamic and static tilt sensing, vehicle roll detection, compass tilt compensation, and heavy equipment stabilization. The device relies on a gyro to track fast angular movements, and on the DC response of the accelerometers to track static angular position. For Free Info Circle No. 773 or Enter No. 773 at www.nasatech.com/rs

BOOTH 406

BOOTH 821

The MXA2500U and MXD2020UW low-noise, dual-axis accelerometers from MEMSIC, Andover, MA, are fabricated on a standard, submicron CMOS process that measures acceleration with a full-scale range of ± 1 g and a sensitivity of 500 mV/g. The MXA2500U provides an absolute analog output and the MXD2020UW provides a ratio of pulse width to position digital output. Both measure dynamic acceleration and static acceleration, are hermetically sealed, and are operational over a -40°C to 105°C temperature range. For Free Info Circle No. 772 or Enter No. 772 at www.nasatech.com/rs



Get to analysis faster. Take live measurements in MATLAB.

Data Acquisition
Instrument Control
Signal Processing
Statistics
Training
Consulting

New test and measurement tools for MATLAB combine data acquisition, instrument



New test and measurement tools allow you to communicate with data acquisition devices and instruments directly from MATLAB.

control, and data analysis in a single, interactive environment. Now you can acquire live data from popular data acquisition devices and control your test

equipment directly from MATLAB. Use proven tools for signal processing, statistical analysis, graphics, and reporting to analyze your data as it streams into MATLAB.


Get your free 30-day trial today.

Call 508-647-7040 to request your trial. Or get a free technical information kit at www.mathworks.com/nttm.


MATLAB®
& **SIMULINK®**

MATLAB
training
offered in
15 locations.

These new MATLAB tools provide a complete solution for test, measurement, analysis, graphics, and reporting.



Visit www.mathworks.com/nttm
or call 508-647-7040




© 2001 The MathWorks, Inc.

National Instruments, Austin, TX, will exhibit the 12-bit NI PCI-6115 simultaneous-sampling, multifunction I/O device that delivers digital, analog, and mixed-signal capabilities for high-frequency data acquisition applications. It features simultaneous analog input and output,

BOOTH 801


two on-board memory options, and samples at a maximum of 10 MS/s on each of four input channels. The device also features two 12-bit output channels capable of 4 MS/s, eight digital I/O lines, two 24-bit counter/timers, and a RTSI™ bus for board synchronization. The unit comes with NI-DAQ™ 6.9 driver software for use with numerous programming languages. **For Free Info Circle No. 774 or Enter No. 774 at www.nasatech.com/rs**



The MathWorks, Natick, MA, will feature its MATLAB® 6 environment for applications in engineering and science that includes tools for mathematical computation, analysis, visualization, and algorithm development. The Data Acquisition

BOOTH 728

Toolbox 2.1 enables control and communication with a variety of PC-compatible data acquisition hardware. With the toolbox, users can configure external hardware devices, read data into MATLAB for analysis, or send data out. Also exhibited will be the Instrument Control Toolbox 1.1 that lets MATLAB communicate with instruments such as oscilloscopes and function generators. Data can be generated in MATLAB to send to an instrument, or can be read into MATLAB for analysis and visualization. **For Free Info Circle No. 771 or Enter No. 771 at www.nasatech.com/rs**




From Data To Solutions, Get There Faster With IDL

Visit our Web site and receive an "Image Processing With IDL" White Paper free.

Go to
www.rsinc.com/wp
or call 303.786.9900

IDL



- Create custom applications with far fewer lines of code than traditional languages.
- Get more from your data faster with IDL's powerful interactive visualizations.
- Develop cross platform applications in a single environment.

IDL

info@rsinc.com www.rsinc.com/wp 303.786.9900
United States United Kingdom France Italy
IDL is a registered trademark of Research Systems, Inc.



RESEARCH
SYSTEMS
A Kodak Company

Druck, New Fairfield, CT, will display the PTX 7200 Series pressure transmitters that use piezoresistive silicon technology packaged in a welded stainless steel housing. The 316L SS housing and Hastelloy C276 diaphragm are NACE MR-01-75 compatible. All ranges from 1 to 10,000 PSI are available in gauge or absolute pressure with a 2-wire, 4-20 mA output. Operating temperature range is -40°F to 210°F. **For Free Info Circle No. 766 or Enter No. 766 at www.nasatech.com/rs**


BOOTH 809



Differential pressure transducers from Kavlico, Moorpark, CA, can be specified with pressure ranges of 1" of water to 0-50 PSID, and operate on a 5 VDC power supply, providing a 0.5 to 4.5 VDC output. The transducers are suitable for ventilation, water flow, gas flow, air intake flow, exhaust gas flow, coolant flow, oil flow, fuel flow, product mixing, and blending applications. The transducers have no moving parts, and provide flow measurement options when coupled with venturi tubes, flow nozzles, orifice plates, or pitot tubes. **For Free Info Circle No. 768 or Enter No. 768 at www.nasatech.com/rs**

BOOTH 719





The F3C-AL laser sensor from OMRON Electronics, Schaumburg, IL, can detect a 1-mm target from a distance of 700 mm. Its black/white error eliminates the need to reset parameters or change sensors when changing colors, materials, or inclination. The sensor features background suppression, and contains a red laser light spot that facilitates alignment with the target. It is suitable for semiconductor, assembly automation, material handling, automotive, electronics, machine tool, and packaging applications, and incorporates an auto power control function. **For Free Info Circle No. 777 or Enter No. 777 at www.nasatech.com/rs**

BOOTH 1013

Crossbow Technology, San Jose, CA, will display its MICA sensors and tools that enable development of wireless sensor networks for monitoring and detecting a variety of targets. The MICA architecture consists of MPR and MTS sensors and wireless communication processor modules. The sensors can detect ultra-small vibrations, acoustic noise, magnetic disturbances, conventional light, temperature, and proximity. A sensor interface port enables incorporation of chemical and biological sensor technology. **For Free Info Circle No. 764 or Enter No. 764 at www.nasatech.com/rs**

BOOTH 512

YSI Temperature, Yellow Springs, OH, offers the 4-20 mA loop-powered 4800 DX-1 thermistor transmitter for process monitoring applications. The transmitter has an accuracy of $\pm 0.1^\circ\text{C}$ and is available in two temperature ranges: -10°C to 50°C for biomedical applications; and 0°C to 100°C , which is compatible with YSI configure-to-order probes. **For Free Info Circle No. 781 or Enter No. 781 at www.nasatech.com/rs**

BOOTH 524



The DCSTM Smarteye[®] RS-232 compatible, digitally controlled, photoelectric sensors from Tri-Tronics, Tampa, FL, can be set up, monitored, and controlled directly from a computer screen. The sensors are compatible with computers, PLCs, embedded controllers, or any control device equipped with an RS-232 serial port. They provide an on-screen oscilloscope style contrast deviation analyzer that allows the operator to tweak the adjustment for the most reliable setting.

BOOTH 313

Benefits of computer screen control include set-up by use of icons, graphical performance monitor, configurable performance options, performance memory settings, and timer options. **For Free Info Circle No. 779 or Enter No. 779 at www.nasatech.com/rs**



Yokagawa Corporation of America, Newnan, GA, offers the MV100 and MV200 MobileCorders that provide data logging capability over a range of measurement applications. The MV100 is available with up to 12 universal inputs and features a 5.5" color TFT LCD display. The MV200 is available with up to 30 universal inputs and features a 10.4" color TFT LCD display. Both models offer a choice of removable storage media, standard 1.44-MB floppy disk, or an optional 100-MB Zip or 160-MB PCMCIA ATA flash memory card. The units can be used as portable test instruments, or on a bench-top. **For Free Info Circle No. 780 or Enter No. 780 at www.nasatech.com/rs**

BOOTH 1120

RDP Electrosense, Pottstown, PA, offers the MCL range tension and compression amplified load cells that couple a capacitive sensor the miniaturized conditioning electronics in a compact housing. The internal electronics provide a level



BOOTH 1008

± 10 VDC output. The units come in two compact models, with the smaller measuring 1.22 x 1.75". Also featured will be the DCTH series displacement transducers for interface with control systems and AD converters. **For Free Info Circle No. 778 or Enter No. 778 at www.nasatech.com/rs**

SONIC-MILL[®]
MACHINING THE UNMACHINABLE

Silicon
Quartz
Glass
Sapphire
Alumina

Fiber Optic
Materials
Alumina Nitride
Silicon Carbide
Various
Composites

Boron Carbide
Ferrite
Graphite
Ruby
Boron Nitride
Zirconia

*Specializing in the
Precision Machining of
Technical Ceramics and Glass.
Machined to
Your Specifications*

Albuquerque, New Mexico, USA
phone: 505.839.3535
fax: 505.839.3525
charlie.wilhite@tbgiogrande.com
www.sonicmill.com

See us at American Ceramic Society Expo (ACerS)
in St. Louis, MO, April 28-30, Booth #235

source code: A9332



Electrometer for Triboelectric Evaluation of Materials

Some materials should be distinguishable by their triboelectric responses.

NASA's Jet Propulsion Laboratory, Pasadena, California

An electrometer developed for measuring the triboelectric responses of soils on Mars is also potentially useful on Earth for identifying some materials via their triboelectric responses. In operation, an array of triboelectric sensors is rubbed against the material of interest

one seeks to identify or to distinguish from each other exhibit unique, known triboelectric responses that have been catalogued, then a sample of unknown material can be identified by seeking a match between its triboelectric response and one of the catalogued responses.

thereby constraining the electrometer input and output voltages to be zero. At a designated point during rubbing, the switch is opened, allowing C_1 to charge and the electrometer output voltage to depart from zero.

The triboelectric response — that is, the electrometer output voltage as a function of time — depends on several factors, including the following:

- The triboelectrically induced charge (Q_i) present at the instant of liftoff following rubbing;
- C_1 , C_2 , and amplifier-circuit resistances;
- The speed of withdrawal;
- The time-varying capacitance C_3 between the rubbed insulator and sample surfaces; and
- The electrical resistivities of the insulator and sample materials.

Figure 2 shows triboelectric responses from an experiment in which five sensors made with five different insulating materials were rubbed against wool felt.

Electrometers based on this concept might be useful in industrial settings for inspecting and identifying incoming materials; for example, to identify fabrics coming into a clothing factory. Another potential use could be distinguishing between contaminated and uncontaminated soils. Another application might be evaluating moisture contents of soils; this should be possible because the rate of decay of triboelectric charge depends on humidity.

This work was done by Martin Buehler and Raymond Gompf of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Intellectual Property group

JPL

Mail Stop 202-233
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-20684, volume and number of this NASA Tech Briefs issue, and the page number.




Figure 1. The Insulator Is Rubbed along the surface of the sample, then withdrawn. The rise and decay of the triboelectric charge induced by the rubbing is indicated by the time-varying output voltage of the amplifier.

for a predetermined distance, then withdrawn from the material of interest at a predetermined speed. During this operation, the electrometer circuitry measures the time-varying sensor output voltages, which are proportional to the electric charges induced on the sensors by the rubbing. The resulting voltage-vs.-time data constitute the desired triboelectric-response data. If materials that

Figure 1 is a simplified schematic depiction of one of the triboelectric sensors connected to a charge-sensing circuit (charge-to-voltage converter). This converter is a conventional electrometer circuit that includes a capacitor (C_1) and an operational amplifier in a follower configuration. The triboelectric sensor is an electrode covered with a layer of insulating material. The outer surface of the insulating material is what is rubbed against the material of interest.

The capacitance between the outer surface of the insulator and the electrode is C_2 . The voltage associated with the triboelectric charge that accumulates on the rubbed insulator surface is coupled, via this capacitance, to the C_1 /amplifier node.

Initially during rubbing, the switch shown in Figure 1 is kept closed to prevent C_1 from charging,




Figure 2. These Five Triboelectric Responses were obtained from rubbing five triboelectric sensors against wool felt. The insulators on the sensors were made from the noted materials.

In the world of CAD/CAM, we're changing the rules.

**NO
LIMITS**

VX Overdrive™. Premium-performance CAD/CAM that's fun to drive.


***Design through
manufacturing
with no stops***



VX® blows the doors off of CAD/CAM with a value-priced, design-through-manufacturing system so superior it leaves everything else in the dust. New VX Overdrive is so feature-rich, so fun to drive, what used to be roadblocks at every phase now become thrilling curves you can negotiate with ease.

So easy to use

VX Overdrive is loaded with flexibility



to help you fly through even the toughest jobs. Unique surface creation tools let you blast through challenges at high speed. And its full integration from design through manufacturing means engineers can bring projects to market faster using a single, seamless system. With VX Overdrive, if you can imagine it, you can build it.

***Premium performance
without the premium price***

VX Overdrive comes fully loaded so you'll get the most bang for

your buck of any system, plus the ability to import legacy data and the highest level of interoperability on the market (STEP, IGES and direct CAD translators).



Take a test spin

See for yourself how VX Overdrive is changing the rules. Contact us for a demo today.



VX® Shaping the future of CAD/CAM™

VX.COM 321-676-3222

Infrared CO₂ Sensor With Built-In Calibration Chambers

John F. Kennedy Space Center, Florida


A proposed infrared CO₂ sensor, operated in conjunction with suitable read-out, data-processing, and control circuitry, could be calibrated repeatedly during operation to compensate for changes in sensor response induced by such phenomena as aging and changes in temperature. The sensor would include an infrared source, an infrared detector, and four chambers containing CO₂ at various concentrations. Three of

the chambers would be calibration chambers: they would be sealed and would contain CO₂ at known low, intermediate, and high concentrations, respectively. The fourth chamber would be filled with the gas under test containing CO₂ at a concentration to be determined. There would be optics for multiplexing infrared radiation from the source through the four chambers and demultiplexing the radiation from the

chambers to the infrared detector. During an operation/calibration cycle, radiation would be directed through each chamber in turn, and the response of the detector recorded for each chamber. A three-point calibration for that cycle would be computed from the responses for the three calibration chambers. Then the concentration of CO₂ in the fourth chamber would be computed by simply multiplying the detector response for that chamber by a factor calculated as part of the calibration.

This work was done by Jose M. Perotti and Gregory A. Hall of Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category.
KSC-12177

Need Better Control of Your Motions?



Harness Them With the CLD Linear Motor


Insufficient manufacturing throughput and compromised product quality can make your customers justifiably upset.

With tubular linear motors from California Linear Devices, you won't have to worry about your production system's performance.

The compact CLD motor incorporates:

- Single moving part, integral bearing system
- Pinpoint control of position and force
- Forces from 50 to 1,200 lb.
- Velocity to 100 in./sec.
- Strokes from 2 to 20 in.

So specify the CLD motor, and rest assured that your linear motion is under control.



CLD

California Linear Devices, Inc.

2236 Rutherford Road, Suite 119
Carlsbad, CA 92008
Phone: (760) 603-8026
Fax: (760) 603-0049
Toll Free: (877) 474-2854
E-mail: sales@calinear.com
www.clinear.com

Call us today at (877) 474-2854 or visit www.clinear.com.

Solid-State Potentiometric CO Sensor

John F. Kennedy Space Center, Florida

A solid-state sensor was developed that measures the concentrations of one or more gases of interest in a mixture of gases. This simple solid-state sensor produces a voltage signal that is sensitive to CO concentration from percent to ppm (parts per million) levels. It was intended originally for use in measuring concentrations of carbon monoxide in fuel and oxidizer gases generated on Mars in a process that would include the decomposition of atmospheric CO₂ into CO and O₂. In that application, the sensor would be capable of measuring high concentrations of CO expected to occur on the fuel side of the process, yet would be selective and sensitive enough to measure the low concentrations of CO in O₂ expected on the oxidizer side of the process. On Earth, sensors like this one could be used to detect toxic concentrations of CO emitted in diverse processes, including refining of petroleum and combustion of hydrocarbon fuels in furnaces and automobiles.

This work was done by Eric D. Wachsmann and Abdul-Majeed Azad of the University of Florida for Kennedy Space Center. For further information contact the Kennedy Commercial Technology Office at 321-867-6224.
KSC-12256



Planetary Rover Absolute Heading Detection Using a Sun Sensor

Headings are accurate to within a few degrees.

NASA's Jet Propulsion Laboratory, Pasadena, California

A relatively inexpensive Sun sensor for determining the absolute heading of planetary rovers to within $\pm 3^\circ$ using a monochrome charge-coupled device (CCD) camera is presented. The Sun sensor was developed for the Field Integrated, Design and Operations (FIDO) rover. This rover is an advance technology rover that is a terrestrial prototype of the rovers that NASA/JPL plans to send to Mars in 2003. The goal of the FIDO team was to develop a Sun sensor that fills the current cost/performance gap, uses the power of sub-pixel interpolation, makes use of current hardware on the rover, and demands very little computational overhead. In addition, a great deal of emphasis was placed on robustness to calibration errors and the flexibility to make a transition to a flight rover with very little modification.

The resulting Sun sensor, which is shown in Figure 1, consists of a CCD monochrome camera, two neutral-density filters, a wide-angle lens, and housing. The neutral-density filters reduce incident light to capture only the Sun's disk. The Sun sensor camera is modeled as a fish-eye camera/lens system with 21 parameters; the parameters are computed in the calibration procedure that can be performed easily and even "on the fly." The Sun sensor captures images of the Sun using an onboard frame grabber mounted on the rover-computing stack. The centroid of the Sun in the image is the main feature needed for determination of the rover heading. Centroid extraction follows a three-step process: thresholding, artifact removal, and center of mass/circularity determination. From the Sun centroid a 3-D unit ray vector is computed from the sensor frame to the Sun using the camera model. The 3-D vector is then transformed into a gravity-down rover reference frame by use of the roll- and pitch-angle outputs of an inertial sensor that is part of the onboard rover navigation system. The azimuth and elevation of the Sun with respect to the rover reference frame are then determined. By use of solar ephemeris data and the equation of time from the Astronomical Almanac, the azimuth and elevation of the Sun are determined for the applicable longitude, latitude, and universal time (UT). The UT is obtained from the rover computer clock and corrected to the nearest second. Finally, the heading




Figure 1. Sun Sensor mounted on the FIDO rover is used for determining the absolute heading within $\pm 3^\circ$.




Figure 2. Plots of Rover Heading From Compass and Sun Sensor are illustrated. Unlike in an odometry-based heading estimation, in a Sun-sensor-based heading estimation the relative rover heading error is a constant.

with respect to true north is computed by use of the known relationship between (1) the azimuth and elevation of the Sun as computed from the ephemeris data and (2) the azimuth and elevation of the Sun as determined from the Sun-sensor data.

In a test of the Sun sensor mounted on the FIDO rover, the rover was placed on a flat surface and turned in place at angular increments of about 20°. Figure 2 depicts the headings as measured by the Sun sensor and by a magnetic compass, as well as the dif-

ferences between them. The Sun sensor confidence for each reading is also indicated on the plot. The accuracy of the magnetic compass used is $\pm 2^\circ$. The differences between the readings can be attributed to several factors, including mechanical alignment errors of the Sun sensor, rover attitude errors, and atmospheric conditions (cloud cover).

Results of a recent FIDO field trial at Black Rock Summit in Central Nevada, in May of 2000 and several Operations Readiness Tests (ORTs) at the JPL Mars

Yard using the Sun sensor have demonstrated three- to four-fold improvement in the heading estimation of the rover compared to incremental odometry. These test results helped shape the mission specifications outlined by NASA for the 2003 mission to Mars.

This work was done by Ashitey Trebi-Olennu, Terry Huntsberger, Brett Kennedy, and Eric Baumgartner of Caltech for NASA's Jet Propulsion Laboratory. For a full report on the Sun sensor visit <http://fido.jpl.nasa.gov/publications>. NPO-21182

THE ONLY WAY TO SEAL IT SHUT IS TO PNEUMA-SEAL IT


Pneuma-Seal® inflatable gaskets are pressurized with air to fill the uneven gaps between surfaces. When deflated, they quickly retract preventing interference when opening and closing a door or cover. Pneuma-Seal is an effective barrier against pressure differentials, and seals out water, dust, gas, chemicals, noise and other contaminants. Typical applications include:

- Processing Equipment: chemical, food, textile, pharmaceuticals, dryers, ovens and where rapid sealing and unsealing are required.
- Semiconductor Fabrication
- Pollution Control
- Laboratory Facilities
- Transportation
- Construction

Pneuma-Seal is particularly suitable in:

- Large enclosures where it is uneconomical to machine the entire sealing surface.
- Uneven fabrications where traditional compression gaskets or latches are ineffective.
- Horizontal or vertical sliding doors or covers that tend to drag on and abrade conventional seals.
- Hinged doors where flush thresholds are required.

For complete details on profiles, configurations, and applications, visit our website at: **WWW.PRESRAY.COM**



PNEUMA-SEAL®
manufactured by
PRESRAY

Presray Corporation

159 Charles Colman Blvd. • Pawling, NY 12564 USA

(845) 855-1220 • Fax: (845) 855-1139

West Coast: (949) 475-9842 • e-mail: info@presray.com

Concept for Utilizing Full Areas of STJ Photodetector Arrays

Also, cross-talk among pixels and the number of contacts would be reduced.

NASA's Jet Propulsion Laboratory, Pasadena, California

A method of designing improved monolithic planar arrays of superconducting tunnel junctions (STJs) for use as photodetectors has been conceived. These arrays would be suitable for detecting images at low light levels. They are for operation in the individual-photon-counting regime; they are used not only to detect the arrival of individual photons but also to measure the individual photon energies. As such, the STJ arrays would be compact sensors that would perform the functions now performed by bulkier equipment in the form of photomultipliers and spectrometers. Eventually, it should be possible to use STJ arrays for such demanding applications as simultaneous imaging and spectroscopy of faint astronomical objects.

Usually, an STJ photodetector contains three superconductors with different superconducting energy gaps. Photons in the energy range of interest are absorbed in the superconductor with the intermediate energy gap; this superconductor and the one with the lowest energy gap are separated by a layer of electrical insulation thin enough that photoexcited quasi-particles can tunnel (in the quantum-mechanical sense) through it. Together, the

intermediate- and lowest-energy-gap superconductors and the insulating layer between them constitute the detector junction. The superconductor with the highest energy gap is used for wiring to the other two superconductors. In a typical previously developed STJ array, separate electrical connections are made to each photodetector (see Figure 1).

Even an abbreviated explanation of the present method and the ways in which it differs from older STJ-array-design methods would greatly exceed the scope of this article because it would unavoidably include complex and interdependent details of the physics and the fabrication of STJ devices in general. For the purpose of this article, it must suffice




Figure 1. A **Typical STJ Photodetector** contains a tunnel junction between an intermediate- and a low-energy-gap superconductor. The electrical connections to the device are made via the base and top leads, which are made of a higher-energy-gap superconductor.




Figure 2. **Two Adjacent Pixels** of an STJ photodetector array according to the present method could be fabricated in either of two basic alternative configurations. In both configurations, the structure would behave like a solid ground plane for incident radiation at frequencies from dc up through hundreds of gigahertz, yet would present all (in the second configuration) or nearly all (in the first configuration) of its area for absorption of photons in the energy range of interest.

Measurement Ready 16-Bit DAQ from \$595



NI offers cost-effective 16-bit data acquisition (DAQ) for multiple bus technologies – PCI, PXI, and portable DAQ for IEEE 1394 – including:

16-Bit Device	Sample Rate	Analog Inputs	Analog Outputs
PCI-6034E	200 kS/s	16 SE/8 Diff	—
PCI-6036E*	200 kS/s	16 SE/8 Diff	2, 16-bit
PCI-6052E	333 kS/s	16 SE/8 Diff	2, 16-bit
PXI-6052E	333 kS/s	16 SE/8 Diff	2, 16-bit
DAQPad™-6052E ^{1,2}	333 kS/s	16 SE/8 Diff	2, 16-bit

*New products, *Portable, IEEE 1394
Each device also includes two, 24-bit counter/timers and 8 digital I/O lines. SE= Single Ended

ni.com/info

Download the proof – an interactive white paper on the benefits of Measurement Ready DAQ, and receive a FREE configuration advisor CD. Visit ni.com/info and enter namm21.

NATIONAL INSTRUMENTS™

(800) 327-9894

Fax: (512) 683-9300 • info@ni.com

© 2002 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

For Free Info Circle No. 551 or Enter No. 551 at www.nasatech.com/rs

to summarize the major distinguishing features:

- In the previously developed STJ photodetector arrays, pixels are separated by small gaps, through which photons can pass undetected. These gaps can amount to significant fractions of total detector areas; in other words, overall quantum efficiencies are lower than they would be if full detector areas were utilized. In STJ arrays according to the present method (see Figure 2), the gaps between pixels would be either negligibly small or entirely absent; in other words, full detector areas would be utilized, thereby maximizing quantum efficiencies.

- In a typical previously developed STJ array of m rows and n columns, the number of electrical contacts necessary for individual biasing and readout of all pixels is $2mn$ because two contacts are needed for each pixel. In an STJ according to the present method, the number of contacts needed would be $mn + 1$ (slightly more than half the number previously needed) because the photon-absorbing (intermediate-energy-gap) superconductors of all the pixels would be electrically tied together by the largest-energy-gap superconductor.
- Even though the full detector area would be utilized in the present method, the pixels would be electrically isolated from each other with re-

spect to diffusion of photoexcited quasi-particles between superconductors, so that cross-talk among pixels would be suppressed.

- Unlike at least one prior method, the present method does not call for small superconducting bridges among neighboring pixels. This is an advantage in that such bridges could, potentially, constitute undesired superconductive magnetic-flux-trapping loops.

This work was done by Michael Burns of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category. NPO-20768

Development of Cognitive Sensors

NASA's Jet Propulsion Laboratory, Pasadena, California

A technical report enunciates the concept of a hierarchy of sensor classes (meaning transducers, associated circuitry, and embedded software) that have different levels of intelligence, and discusses issues pertaining to the development of sensors of the highest level of intelligence, called cognitive. The other levels, in order of decreasing in-

telligence, belong to the class of intelligent or smart sensors. A design process and an intelligence hierarchy which enables construction of intelligence-based sensors has been developed based on five main qualities:

1. self-knowledge — the sensor must identify its purpose and understand its operational functions;

2. communication — the sensor must be capable of transmitting/receiving information (versus raw data) to/from other devices;
3. perception — the sensor must have the ability to recognize, interpret, and understand sensory stimuli;
4. reasoning — the sensor must be capable of making decisions based on perception of sensory stimuli; and
5. cognition — the sensor's intellectual process must subscribe to the process of knowing, which includes aspects such as awareness, perception, reasoning, and judgement.

The report discusses hardware and software of a cognitive sensor in general and, more specifically, of sensors for use in planetary exploration. A generic process for designing the hardware and software of a cognitive sensor is described. Specific instances are described for the examples of (1) an optoelectronic sensor that recognizes a moving object and includes a camera that tracks the object and (2) a similar optoelectronic sensor that recognizes rocky terrain, determines the safest path across the terrain on the basis of the sizes and distribution of rocks, and aims the camera along this path.

This work was done by Ayanna Howard and Edward Tunstet of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the paper, "Cognitive Sensor Technology," access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category. NPO-30283

Crossbow
Technology, Inc.

Leader in Silicon Sensing Solutions

Accelerometers



- 1G - 100G
- DC - 10 KHz
- 1 - 3 Axis

Analog & Digital Tilt Sensors



- $\pm 75^\circ$ Range
- Linearized
- Compensated

Inertial Systems



- IMUs, Vertical Gyros, AHRs
- MEMS & FOG Technology
- Industrial and Aerospace Applications

Wireless Dataloggers



- 4-Channel
- Turnkey System
- 1 KHz
- PC Radio and Software

www.xbow.com

To order a catalog: call 408.965.3300 or email info@xbow.com

41 Daggett Drive, San Jose CA 95134 Fax 408.324.4840



Enabling Higher-Voltage Operation of SOI CMOS Transistors

An integrated-circuit substrate would be biased against turn-on of parasitic transistors.

NASA's Jet Propulsion Laboratory, Pasadena, California

A "smart" back-gate driver circuit has been proposed to enable the operation, at voltages higher than were previously possible, of a silicon-on-insulator (SOI) complementary metal oxide/semiconductor (CMOS) integrated circuit that contains both low- and high-voltage transistors energized by corresponding low- and high-voltage power supplies. As used here, "low voltage" signifies potentials ≤ 3.3 V, while "high voltage" signifies potentials ≥ 40 V. The purpose of the back-gate driver circuit is to raise the threshold (turn-on) voltages of parasitic back-channel transistors (BCTs) that unavoidably exist in such an integrated circuit (see Figure 1). Turn-on of the parasitic transistors is unacceptable because it

causes short circuits that render the integrated circuit inoperative.

In a mixed-voltage (high-voltage/low-voltage) SOI CMOS integrated circuit, the turn-on threshold voltages of para-

sitic BCTs are usually less than the voltage that the high-voltage transistors can withstand; heretofore, this fact has made it necessary to limit voltage ratings accordingly. The problem is com-




Figure 1. A Parasitic Back-Channel Transistor (BCT) exists under a typical low-voltage field-effect transistor (FET). If a high voltage is impressed on the source or drain of this FET, an inversion layer can form just above the buried oxide, allowing current to flow.

Mass Flowmeters


Now It's Time to Reduce Costs!

Series 4200 Mass Flowmeters for Gas Monitoring

- Under \$100 in production quantities
- UL 913 recognized to measure air, natural gas, methane and propane
- 20 millisecond response time
- Very low pressure drop

Make TSI your Strategic Partner
and bring your product to market faster.

TSI Incorporated
500 Cardigan Road, Shoreview, MN 55126 USA
Tel: 1 651 490 3849 E-mail: flowmeters@tsi.com Web: www.tsi.com






Figure 2. The "Smart" Back-Gate Driver Circuit would sense the turn-on voltage of one parasitic BCT and respond by biasing the substrate at a voltage that would keep all the other parasitic BCTs turned off. (Note: TCT = top-channel transistor.)

plified by the fact that ionizing radiation causes the accumulation of positive charges in the buried oxide layer of the integrated circuit, and these charges lower the threshold voltages of the parasitic BCT.

The proposed back-gate driver circuit would apply, to the integrated-circuit substrate, a bias voltage that would ensure that the parasitic BCTs remain in the "off" state at voltages beyond

those that would otherwise cause the parasitic transistors to turn on. The proposed back-gate driver circuit is characterized as "smart" because it would sense the effect of ionizing radiation on the threshold voltages and would respond by adjusting the bias voltage that it applies so as to maximize the margin of turn-off of the parasitic transistors.

Figure 2 is a simplified schematic diagram of the proposed circuit. A current of 1 μA would be forced through one n-type back-channel transistor (BCT). The source of this BCT would be biased to -5 V to ensure that its gate-to-source voltage (V_{GS}) was 5 V greater than that of any other n-type BCT on the integrated-circuit chip. Feedback would force this V_{GS} to a level that would cause a current of 1 μA to flow in this one BCT. This V_{GS} would slightly exceed the turn-on voltage of this BCT, forcing the substrate voltage to be approximately 5 V less than the turn-on voltages of all other n-channel BCTs on the chip. Exposure of the integrated circuit to aging would cause the turn-on voltages of the both the p- and n-type BCTs to shift in the same direction by about the same amount. Thus, by shifting the substrate-bias voltage in response to the sensed turn-on of one n-type BCT, the proposed circuit would maintain voltage margins against turn-on of both the remaining n-type BCTs and all the p-type BCTs.

This work was done by Mohammad Mojarradi of Caltech, Benjamin Blalock of Mississippi State University, and Harry Li of the University of Idaho for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category. NPO-20910



Reliable...
Anytime. Anywhere.

3 full-length ISA/PCI slots
(6 half-length)

Flightline technicians around the world rely on the FieldWorks 8000 for:

- Telemetry/Communications
- Data Acquisition
- Test and Measurement
- Mission Critical Communications

Also Available:
Power Lite

- One PCI/ISA Slot
- Rugged System

FieldWorks 8000

- Rugged, Portable Computer
- ISA/PCI Expansion Card Slots

We Go Where You Go.

For more information call:

North America:
1-800-343-5396

Asia: +886-2-2910-3532

Europe, Middle East,
Africa: +49-81-65-770

or visit our website at

www.kontronmobile.com



Kontron and logo are registered trademarks of Kontron Embedded Computers AG. FieldWorks is a registered trademark of Kontron Mobile Computing, Inc. All other trademarks are the property of their respective owners.

Estimating Antenna-Pointing Errors From Beam Squints

RCP and LCP beams are received at different levels when aim is not perfect.

NASA's Jet Propulsion Laboratory,
Pasadena, California

A method of estimating the pointing error of an offset-conic-section reflector antenna equipped to receive in both right circular polarization (RCP)


What threatens your high speed PCB design?

As clock speeds approach 1 GHz even the simplest passive elements cause propagation delay, cross talk, and ground bounce. Eliminate glitches, resets, and logic errors by simulating entire signal paths.

Rely on Ansoft's high performance EDA solutions for your signal integrity and EMI needs.

Contact us for a free evaluation at
412-261-3200 or info@ansoft.com.

**For Free Info Circle No. 566 or
Visit www.nasatech.com/566**




Unmatched speed and accuracy in parasitic extraction and signal integrity simulation.

Eradicate



www.ansoft.com



These Curves Were Calculated for Gaussian RCP and LCP beams 3° wide, with 0.3° squint between beams.

and left circular polarization (LCP) exploits a phenomenon that, heretofore, has been regarded as a minor nuisance. The phenomenon in question is a misalignment between RCP and LCP beams and manifests itself as opposing squints of the beams. The method enables the generation of pointing-error estimates at high rates for use as feedback in high-bandwidth antenna tracking-control systems, without need for the complex radio-frequency circuitry of monopulse or traditional se-

quential-lobing antenna tracking-control systems. The method was conceived especially to be used at terrestrial stations to track LCP and RCP signals transmitted by satellites.

When an antenna is mispointed in one direction, the RCP signal normalized by its peak value is stronger than the corresponding normalized value of the LCP signal. When the antenna is mispointed in the opposite direction, the normalized LCP signal is the stronger one. Zero pointing error in this context is defined as the antenna-aiming direction for which the normalized RCP and LCP signal levels are equal. The difference between normalized signal levels can be characterized as an S-curve function of the pointing error; this curve is given by

$$S(\phi) = 2\{[R(\phi)/R_p] + [L(\phi)/L_p]\} / \{[R(\phi)/R_p] - [L(\phi)/L_p]\},$$

where ϕ is the angular pointing error; $R(\phi)$ and $L(\phi)$ denote the levels of the RCP and LCP signals, respectively, at ϕ ; and R_p and L_p denote the peak levels of these signals. The figure presents an example of the normalized signal levels and of the S-curve function for small pointing-error angles. The S-curve function can be inverted so that the pointing error can be estimated from the normalized signal levels.

In the present method, one obtains the normalized signal levels from measurements of levels and differences between levels of satellite signals received through the antenna while switching rapidly (electronically) between the reception in RCP and LCP. "Satellite dish" antennas equipped with circuitry to receive both RCP and LCP and capable of rapid switching between RCP and LCP are commercially available. This method of reception amounts, in effect, to a method of electronic sequential lobing. The faster the electronic switching between RCP and LCP, the greater the bandwidth of the pointing-error signal.

This work was done by Arthur Densmore of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA Management Office-JPL; 818-354-7770. Refer to NPO-19938.

HOW TO GET SILICONE THAT'S OFF THE RADAR SCREEN . . .

When Stealth project engineers needed a specific silicone that hadn't been invented yet, they called Nusil Technology. Why? They knew they had to . . . **FIND THE RIGHT PARTNER TO CREATE IT . . .**

Working with you, Nusil creates silicone with the properties specific to your individual application. Just the way it was done for the Stealth bomber. The result can decrease the cost and increase the ease of manufacture. Of course you need to . . . **BE SURE THEY HAVE THE FACILITIES TO PRODUCE IT . . .** Nusil's facilities in North America and in Europe are spacious, state-of-the-art labs and processing plants. NuSil Technology is ISO-9001 certified. From small highly specialized orders, to large, off-the shelf 'standard' purchases, every batch is tested for quality and consistency. Nusil has . . . **THE EXPERTISE TO PRICE IT RIGHT . . .**

As masters of silicone technology, Nusil has over 400 fully characterized silicone formulations. Customizing these 'standards' to provide or impart specific properties affords tremendous economies. Nusil makes it happen with . . . **THE GLOBAL REPUTATION TO BACK IT UP . . .** Nusil's people are known for being hands-on, can-do professionals. Nusil's reputation is second to none. At Nusil, we look forward to being your . . . **Creative partners in a material world.**



Nusil Technology
1050 Cindy Lane
Carpinteria, CA 93013
Telephone: (805) 684-8780
Fax: (805) 566-9905

**Nusil Technology - Europe
Technical Services Center**
2740 Route des crêtes
BP325 06906
SOPHIA ANTIPOLIS cedex, FRANCE
Telephone +33 (0)4 92 96 93 31
Fax +33 (0)4 92 96 06 37




**SILICONE
TECHNOLOGY**

www.nusil.com/ntb

PHOTONICS Tech Briefs

PHOTONICS SOLUTIONS FOR THE DESIGN ENGINEER




LED Modeling: Pros and Cons of Common Methods	11a
CLEO Preview	2a
Product Guide: Optical Design Software	4a
Technologies of the Month	6a
Adaptive Multiplexing for Free-Space Optical Communication	8a
Magnetically Suspended Optical Chopper Wheel	10a
Fiber-Optic Rotary Joint for Passing High-Definition Video	10a
Mesosopic Steerable Mirror	11a
Making Three-Dimensional Holograms Visible From All Sides	13a
New Products	14a

Cover photo courtesy of Hamamatsu Corporation

www.ptbmagazine.com

LED Modeling: Pros and Cons of Common Methods



The three key opto-mechanical elements of most LEDs.

Light Emitting Diodes (LEDs) offer several advantages over incandescent, fluorescent, and discharge light sources, including longer lifetime, smaller size, and greater mechanical ruggedness. Continuing developments in LED technology are producing sources with increased output power and electrical efficiency as well as a wider range of colors, including so-called "white light" LEDs. Consequently, LEDs are replacing traditional light sources in numerous illumination applications, from traffic signals to instrumentation. As with any light source, effectively utilizing LEDs in an optical system requires the ability to accurately model their output characteristics with software.

There are three key opto-mechanical elements of most LEDs. The first is the LED die itself. The second is a metal cup in which the die sits. This cup provides one of the electrical contacts to the die, acts as a heatsink, and also works as a reflector to redirect light exiting the sides of the LED die. The final part is any integral lens or encapsulation. LEDs range from bare, cuboid emitters, to more complex designs that may include multiple emitters, integral lenses, and phosphor layers to alter their spectral output (color).

Modeling Tradeoffs

In designing optical systems containing LEDs, the goal at any stage is to use the simplest model that adequately predicts the behavior of the system. A sim-

ple model is desirable because LEDs present considerable optical complexity and it is not uncommon to trace millions of rays in each iteration of an illumination system design and analysis. Of course, what constitutes an "adequate prediction" of performance can vary. A simpler model might suffice for a feasibility study, while a more rigorous approach may be needed for the actual design and optimization of the final optical system.

The most elementary way to effectively model an LED is as a point source whose output is apodized (varied in a systematic way) as a function of angle. The apodization is usually derived from manufacturer-supplied data. This simple model is straightforward to construct and ray trace in most optical or illumination design programs.

The point source model is most useful for doing first-order system design. This includes roughly determining values for the focal lengths, f-numbers, element sizes, and component locations. The point source model also enables first-order calculation of the optical system's collection efficiency. However, the point source model is inadequate for performing any analysis in the near field of the LED, where effects due to the finite source size are most pronounced.

A significant increase in accuracy can be obtained by modeling an LED as an extended source, where the angular output distribution and any spatial nonuniformities are independently specified. At Optical Research Associates (ORA), a


model of this type, in which the angular distribution is constrained to be the same from every point on the surface, is called an "apodized emitter."

The apodized emitter model is easy to construct and still simple enough to enable rapid ray tracing. For example, it can be specified in several different ways in ORA's illumination design and analysis software package, LightTools. These include applying apodization files directly to a source, creating a superposition of several sources, or even illuminating a scattering surface with collimated rays.

While still generic, the apodized emitter approach is sufficiently accurate for many uses, and is probably the most popular LED software model. Typical systems applications include light pipes, mixing rods, large core, plastic optical fibers, instrumentation lighting, tail lamps, and pillow optics.

The angular distribution of an apodized emitter model can be matched to manufacturer's data, and thus usually specified with good accuracy. However, determining source size, spatial variation, and position within the package is not always so straightforward; this makes it difficult to know the precise accuracy of the model. Errors in specifying these parameters have the most pronounced impact when analyzing systems with limiting apertures.

The next step in model complexity is to explicitly include representations of the LED's various component parts (e.g. die, cup, and lens). ORA terms a model



The secret's out.
And it fits in your pocket.



The incredible new Omega is the smallest, lightest infrared camera ever made. And now it's within your grasp. With more features and performance than cameras ten times its size.

Heavy-weight features are packed into this 3.5-cubic inch marvel. At just 100 grams, this tiny, low power camera lets you put thermal imaging where it has never fit before. For miniature robotics, helmet-mounted vision systems, in-situ industrial monitors and countless other applications that haven't even been dreamed up yet. Wherever space, weight or low power consumption is essential.

But small size doesn't mean any reduction in performance or features. In fact, Omega produces uncompromising image quality in standard RS170 (or PAL) and 14-bit digital outputs - ideal for both imaging and thermal data acquisition applications. Plus its modular design and a wide variety of options and accessories make integration into your project a snap. No other infrared camera opens the door to new applications and enhances others like Omega.



Omega's uncompromising
image quality

And it doesn't end there. To get the big picture of how tiny Omega can fit into your project, call 805-964-9797 or visit www.indigosystems.com.

Omega equals change. The revolution has begun.

indigo 
brighter.

Indigo Systems 5385 Hollister Ave., Santa Barbara, CA 93111 / 805-964-9797 / Fax 805-964-7708 / sales@indigosystems.com / www.indigosystems.com

For Free Info Circle No. 485 or Visit www.nasatech.com/485

composed of angularly and spatially apodized point sources, surface sources, and volume sources — together with optomechanical constructs — a “geometry + emitters” model.

This approach enables several source-specific characteristics to be examined in some detail. Examples include the reflective characteristics of the cup, and the refractive, reflective, and scattering properties of the lens and/or encapsulation. Incorporating “second order” effects, such as spurious reflections from parts of the LED package, is important because these can sometimes determine the real-world success or failure of a system.

Modeling the source as a series of discrete elements also facilitates answering “what if” questions about the system. For example, the reflection from a specific surface might be turned on or off to determine its significance, or the position of a particular LED component might be altered to assess the impact of part-to-part dimensional variations on system performance.

Unfortunately, the “geometry + emitters” model is time-consuming to create, and may require numerous iterations to get the model output to closely match the real LED output at all angles. This time can be mitigated through the use of optimization, but the level of detail adequate for one application may be insufficiently accurate for another, so the time investment to develop the model may not be preserved.


Measurement-Based Models

An accurate empirical approach to source modeling has been developed by Radiant Imaging. Their system utilizes a CCD camera, mounted on a computer-controlled, two-axis goniometer. This system scans an emitting source from all angles, and records the actual luminance distribution at each source view. The files created by the Radiant Imaging system can then be used in most illumination design programs to generate random ray sets that precisely match the angular and spatial output distributions of the source.

Radiant Imaging source models provide two primary advantages. First, they require very little or no time to create

(if they are purchased directly from Radiant Imaging, which has a library of many different sources on file). Second, they are completely accurate, automatically taking into account all source characteristics, such as the effects of defects in the plastic lens.

The drawback of the Radiant Imaging approach is that each model is of only one source sample. If the scanned source is not a “typical” representative of that source type, then neither is the model. Also, these source models cannot be altered, so



LED modeling and illumination design software — in this case, ORA's LightTools — enables ray tracing of complex optical systems. This condensing system consists of tandem lenses and two 7 × 7 lenslet arrays.

there is no capability for adjusting source parameters or isolating the impact of specific source characteristics (e.g. scattering by the cup). Furthermore, the Radiant Imaging approach provides just a ray source to the program, not an optomechanical construct with which a program can interact. Thus, there is no ability to analyze rays that re-enter the source after hitting other parts of the optical system.

In conclusion, developments in LED and other source technologies, together with the rapid proliferation of displays, have created an increasing market for more complex and sophisticated illumination systems. A new generation of more powerful illumination system design programs has been created to meet this demand. However, using these programs successfully and cost effectively still requires an ability to identify and accurately model the most significant source characteristics.

This article was written by William Cas-sarly, Ph.D., Optical Research Associates, 3601 Green Road, Suite 104, Beachwood, OH 44122-5719. Contact the author at: 216-831-0780; Fax 216-831-0790; or email: billc@opticalres.com. Visit ORA at www.opticalres.com.

CLEO 2002 Provides Education and Cutting Edge Technology

Interested in the latest advances in lasers and electro-optics? Then you probably already know about CLEO 2002 (Conference on Lasers and Electro-Optics) taking place May 19-24, 2002 at the Long Beach Convention Center in Long Beach, California. Again this year, the 10th Annual Quantum Electronics and Laser Science Conference (QELS) will run in conjunction with CLEO. QELS addresses research in lasers, nonlinear optics, and the fundamental laser spectroscopy of atoms and condensed matter. Together CLEO/QELS 2001 attracted 6,500 attendees to the Baltimore Convention Center in Baltimore, Maryland. Attendees include representatives from a wide range of industries including communications, medical, optical components, analytical instrumentation, aerospace, imaging, and precision manufacturing.

Exhibition and Conference


Over 350 companies will be showcasing the latest technologies from May 21-23rd at the CLEO exhibition. Hands-on workshops and demonstrations at exhibitor booths allow attendees to gain a better understanding of fiber-optic technologies, applications, and research while making valuable contacts in the industry.

Running from May 19-24th, the technical conference offers a joint plenary session, special symposia, tutorials, invited papers, selected papers and short courses covering a wide range of topics. CLEO's technical program emphasizes applied physics, engineering, and lasers and electro-optics usage while QELS highlights fundamental science and the use of lasers and electro-optics in scientific research.

Registration

Want to attend CLEO 2002? You can register for either the full technical program or only short courses. Both registration types include admission to the exhibition. Complete your advance registration online, by fax, or via regular mail. Payments must be submitted with the registration form — available online in PDF format. For additional information visit www.cleoconference.org.

In outer space no one can hear you scream.
That's why you'll find our optical coatings
on the space station.



Specialized coatings for aerospace.

Optical Coatings. When major aerospace companies need innovative solutions to critical applications, they call ZC&R. We've been called upon to create coatings to extend the life of existing shuttle windows, conduct electricity, even eliminate cleaning problems on coated plastic. Some of the biggest organizations in the world rely on us to provide coated lenses up to 29" in diameter, with unparalleled performance. To discover more about all we can do for you, call 800-426-2864 or visit our web site. ZC&R. When you can't afford to be lost in space, or anywhere else.

zcrcoatings.com

ZC&R
COATINGS FOR OPTICS

ISO 9002 • AS 9000
Registered

1401 Abalone Ave. / Torrance, CA 90501 / 310-381-3060 / 800-426-2864 / FAX: 310-782-9951
e-mail: info@zcrcoatings.com / www.zcrcoatings.com

For Free Info Circle No. 469 or Visit www.nasatech.com/469

Product Guide: Optical Design Software

Software continues to be a pioneering field and one of the fastest growing sectors of the international economy. Over \$150 billion a year in revenue is generated by software with approximately one quarter stemming from development tools, according to Hoovers.com.

Optical design software enables innovation by providing a medium for improving existing technologies and discovering new ones while frequently speeding up time-to-market and reducing overall costs. Engineers use these programs to design, model, and analyze optical devices and systems.

This month's Product Guide features software offerings segmented into three general categories: optimization, ray-trace, and computer-aided design (CAD). Optimization — the process

of taking an initial design and altering it to minimize errors — is considered to be the focus of optical design packages. This list extends beyond the traditional definition to include ray-tracing (evaluation) programs and CAD packages (drawing). Combining software packages from these three categories can create a broader range of integrated capabilities. Source companies should be contacted for detailed compatibility information.

This list is representative of the many companies and software offerings available to meet the needs of the optical industry. Along with the product name and a brief description, we have provided primary system requirements. Readers can obtain detailed pricing and capability information by visiting the web site shown in the chart or contacting the source company directly.

Company	Product	Summary	Processors	Operating Systems
Optimization				
Acme Optics www.acmeoptics.com	Roadrunner	Command driven design and analysis program. Available versions: Standard & LT.	Pentium II or higher	Windows 95/98/ME/NT4/00
Diginaut www.diginaut.com	ADOS	Defines new optical systems, displays and performs analysis of data, and optimization.	Pentium (II or higher recommended)	Windows 95/98/ME/NT4/00
Focus Software www.focus-software.com	ZEMAX	System conceptualization, design, optimization, analysis, tolerance, and documentation of sequential & non-sequential imaging and non-imaging systems. Available versions: SE, XE, & EE.	Pentium III (300MHz or higher)	Windows 95/98/ME/XP/NT4/00
Grating Solver Development Co. www.gsolver.com	GSOLVER® V4.20	Performs diffraction for arbitrary periodic grating structures including all polarizations.	Pentium and higher	Windows 95/98/NT4/00
Lambda Research www.lambdaresearch.com	OSLO®	Primary use: Determination of the optimum sizes & shapes of the elements in optical systems, simulation of optical system performance, and and to development of specialized software tools for optical design, testing, and manufacturing. Available versions: Premium, Standard, & Light.	Pentium or higher	Windows 95/98/NT/00, HP-UX, or Solaris
Linos Photonics GmbH http://www.linos-photonics.de/en/homefr2.html	WinLens	Design and analysis of optical systems. Creates systems with LINOS Photonics and custom components.	Pentium (100 MHz minimum)	Windows 95/98/NT
O++ www.oplusplus.com	APILUX	Design software dedicated to photometric applications, optical design and multi-channel systems.	Pentium 90	Windows 95/98/NT/00
Optical Research Associates www.opticalres.com	CODE V®	Analysis, optimization, illumination calculations, and fabrication support.	Celeron, Pentium, Pentium PRO, Pentium II, III, or IV	Windows 98/ME/NT4/00
Optiwave Corp. www.optiwave.com	OptiSystem	Simulation package for the design, testing and optimization of virtually any type of optical link in the physical layer of a broad spectrum of optical networks.	Pentium or higher	Windows 98/ME/XP/NT4/00
Photon Design www.photond.com	FIMMWAVE	A generic, fully vectorial mode finder for 2D waveguide structures as well as single and multicore fibers.	PC: Pentium II 300MHz or better recommended	PC: Windows 95/98/NT/00 or UNIX: SUN-solaris2.5.1 or later
Photon Design www.photond.com	FIMMPROP-3D	Bidirectional 3D propagation tool for component design.	Pentium II (300 MHz or higher)	PC: Windows 95/98/NT/00 or UNIX: SUN-solaris 2.5.1 or later
Radiant Imaging www.radiantimg.com	ZELUM	Illumination System Design Software for ZEMAX. Models, designs, and analyzes optical systems such as projectors, LED's, or other light sources.	Pentium or higher	Current version of Windows or Windows NT, also requires current version of ZEMAX

Company	Product	Summary	Processors	Operating Systems
Rsoft Design Group, Inc. www.rsoftinc.com	LinkSIM™	Simulation software tool. Design and analyze links in optical telecommunication and broadband fiber optic systems using sources, components, and fiber effects.	Pentium or higher	Windows 95/98/ME/NT/00, UNIX: requires Motif and X11R6.
Sky Scientific www.skyscientific.com	dbOptic	Design Database Program. Creates and analyzes systems with up to 99 surfaces including spherical and aspherical surfaces, flats and irises.	80486 processor (Pentium recommended)	Windows 95/98/ME/XP/NT/00

Ray-Trace

Breault Research Organization www.breault.com	ASAP™	Non-sequential ray tracing program for modeling physical optics, imaging, and illumination systems. Available versions: Basic, Pro, CAD, ELTM, & Optical.	Pentium (200 MHz)	Windows 98/ME/XP/NT4/00
Lambda Research www.lambdaresearch.com	TracePro® 2.4	Ray tracing for illumination analysis, optical analysis, radiometry analysis, and photometry analysis. Available versions: RC, LC, Standard, & Expert.	Pentium II 400 MHz	Windows 95/98/NT/00
OptiCAD Corp. www.opticad.com	OptiCAD®	Models non-sequential, stray light, and illumination optical systems. Includes capability to do unconstrained ray tracing considering reflection, refraction, surface & bulk scattering & polarization.	Pentium, Pentium Pro/II/III	Windows 95/98/NT or later
RayCAD, Inc. www.raycad.com	RayCAD	Opto/mechanical design tool. Performs analysis on arbitrarily placed optical components, with the capability to do unconstrained ray tracing considering, reflection/refraction, surface & bulk scattering & polarization. Requires AutoCAD®.	486DX or greater	Windows 95 or later
Science Lab Software www.optics-lab.com	Optics Lab	Non-sequential ray tracing program that provides models for optics, includes automatic optimization and allows simulation of opto-mechanical devices with control signals developed from simulated detector outputs.	Pentium II or higher	Windows 95/98/ME/NT4/00
SCIOPT Enterprises www.sciopt.com	Optec-IV	General optical systems design (lens design / raytrace) program.	Pentium or higher	Windows 95/98/ME/XP/NT/00

CAD

Autodesk Corp http://usa.autodesk.com	AutoCAD®	2D and 3D design and drafting platform that automates design tasks and provides digital tools. Serves as foundation for programs such as RayCAD.	Pentium II or AMD K6-II 450 MHz	Windows 98/ME/XP/NT4/00
Optical Research Associates www.opticalres.com	LightTools®	Modeling of optical components, light sources, and mechanical parts. Packaging studies and stray light analysis. Available versions: Core, Illumination, & Data Exchange.	Celeron, Pentium II, III, or IV (450 MHz or higher) *Intel PCs not supported	Windows 98/ME/NT4/00
Optikwerk www.optiwork.com	OptiKwerks®	Optics and laser CAD package for designing laser systems & resonators, illumination & non-imaging systems, and conventional optical assemblies. Available in Standard & Pro.	80486 or Pentium	Windows 95/98/ME/NT/00
Optiwave Corp. www.optiwave.com	OptiFDTD	CAD package for advanced passive and active photonics components.	Pentium (900 MHz or higher)	Windows 98/ME/NT4 or later
Rsoft Design Group, Inc. www.rsoftinc.com	BeamProp™	CAD and simulation program used to design integrated and fiber optic waveguide devices and circuits based on the beam propagation method (BPM).	Pentium II or higher	Windows 95/98/NT4 or later, UNIX versions require Motif and X11R6
Rsoft Design Group, Inc. www.rsoftinc.com	FullWAVE™	Integrated CAD and simulation program for design of photonic devices.	Pentium II or higher	Windows 95/98/NT4.0 or later, UNIX versions require Motif and X11R6

FIND-R-SCOPE

Infrared Viewer



- Lightweight
- UL approved
- High Resolution
- Simple to operate
- Custom F: 1.0, 25mm Lens

800-854-4FJW

F J W OPTICAL SYSTEMS, INC.

322 Woodwork Lane ■ Palatine, IL 60067 ■ (847) 358-2500 ■ FAX (847) 358-2588

www.findrscope.com ■ Email: fjwopt@concentric.net

For Free Info Circle No. 452 or Visit www.nasatech.com/452

From the publishers of NASA Tech Briefs New in the NTB Store

Kid's Aviator Flight Jacket



Made to military specifications, this MA-1 flight jacket looks and feels like the real thing, with high-quality authentic aviation patches. \$49.95

Astronaut Flight Jacket

Authentic polycotton twill jacket features U.S. flag and NASA logo patches, aviator collar, and protective inner lining. \$99.95



Space Shuttle Thermal Tile



A unique educational item and a must for collectors! Actual piece of protective tile made for Columbia — the first space shuttle. Packaged in a clear display box, with certificate of authenticity. \$15.95

Order online at

www.nasatech.com/store

Technologies of the Month

Sponsored by yet2.com

For more information on these and other new, licensable inventions, visit www.nasatech.com/techsearch

Projection Display Apparatus Offers More Brightness and Higher Contrast

A new projection-type display apparatus comprises a light source optical system with an anisotropic luminance distribution, a transparent-scattering display element for controlling light emitted from the light source optical system, and a projection optical system with an aperture that projects the transmitted light. The aperture has a non-circular opening in the vicinity of the focal point of the transmitted light of the transparent-scattering type display element. This provides a brighter projection image, and less optical loss than using a twisted nematic (TN)-type liquid crystal display (LCD) element.

The new projection-type display can be used in large-screen and projection televisions, for large-screen computer monitors and simulators, and for monitors in industrial control rooms.

Get the complete report on this technology at:
www.nasatech.com/techsearch/tow/display.html

Email: nasatech@yet2.com

Phone: 617-557-3837

Laser System Measures Curvature of Smooth Surface

AMROC! (Automatic Measurement of Radius Of Curvature) is a new measurement system that determines the curvatures of smooth surfaces such as contact or spectacle lenses, all the way up to astronomical mirrors. Like other optical instruments, AMROC uses lasers to avoid having to place a hard test surface against the surface under test. The advantage of the new system over previously available non-contact systems using simple reflective measurements is that it can measure both spherical and aspheric surfaces.

The process involves placing the test object under a scanning laser system, or allowing the object to move past the laser system. The reflections from the surface are then measured and the curvature of the surface is determined. AMROC is capable of calculating the curvature of several surfaces in the same object, as long as the refractive indices of the materials are known.

The twin-beam unit consists of a handheld optical front end with a separate computer and power supply. The instrument consists of two diode laser sources that emit in the visible range of red wavelengths, and provides an indication to the operator of where the measurements are being made. Each laser is switched on and off in anti-phase; when one is on, the other is off. For transparent items such as lenses, discrete element detectors such as Charge Coupled Devices (CCDs) can be used.

Get the complete report on this technology at:
www.nasatech.com/techsearch/tow/amroc.html

Email: nasatech@yet2.com

Phone: 617-557-3837



hot.

www.yamacraw.com

"Georgia is poised to be as hot as Silicon Valley or Boston. My job here in Atlanta is just as exciting as any I've had anywhere in the country, if not more so. Georgia's not only been good for my resume, it's also been good for my life."

— James Berry, Senior Staff Engineer, RF Solutions


yamacraw
BROADBAND
TECHNOLOGY


GEORGIA

Adaptive Multiplexing for Free-Space Optical Communication

Wavelength- and code-division multiplexing would be utilized for security and improved performance.

NASA's Jet Propulsion Laboratory, Pasadena, California

"Laser-based adaptive wavelength division multiplexing and code division multiplexing" (LAWDM-CDM) is the name of a method that has been proposed to increase security, signal-to-noise ratios (SNRs), redundancy, and adaptability in free-space optical communications. The need for this or a similar method arises as follows:

- In free-space optical communications, various phenomena can affect the propagation and reception of laser beams; these phenomena include jitter of transmitter and receiver platforms and atmospheric attenuation and distortion of laser beams. In a conventional free-space optical communication system, data are transmitted at a constant rate that is not changed to adapt to changing conditions; consequently, for example, a sudden change in weather can disable the free-space optical link, causing loss of data.
- Free-space optical communications are not entirely secure because laser beams can propagate beyond intended receivers and therefore can be intercepted by unintended parties.

In addition to wavelength-division and code-division multiplexing, LAWDM-CDM would involve the use of multiple transmitting apertures, adaptive control of the data-transmission rate and the transmitter power, and other advanced techniques as described below.

- Eavesdropping would be reduced by using adaptive optics to reduce atmosphere-induced beam spreading and by

tailoring the transmitter power to be low enough to minimize propagation beyond the intended receiver yet high enough to reach the intended receiver with an acceptably high SNR. One could choose wavelengths with limited atmospheric transmission to reduce the range of the optical signal.

- Wavelength hopping and code-division multiplexing would make it difficult for an unintended recipient to decode a signal.
- Under adverse atmospheric conditions, the bit rate would be reduced to keep the bit-error rate below a specified maximum acceptable level.
- At the transmitter, laser light back-scattered by the atmosphere would be detected in a lidarlike subsystem, the output of which would be utilized in an algorithm that would select the optimum bit rate and power level.
- Multiple apertures at a transmitter would help to reduce the effect of the scintillation.
- Time-spread code-division multiplexing would enhance reception.

The figure illustrates an example of a simple system that would utilize a combination of wavelength-division multiplexing and time-spread code-division multiplexing to increase security. In the transmitter, a code sequence comprising five parallel bits during each bit period would control the simultaneous generation (for "1") or nongeneration (for "0") of pulses by five laser diodes, each operating at a different one of five


wavelengths (λ_1 through λ_5). Before being launched for propagation to the receiver, the signal in the i th wavelength channel would be delayed by an amount τ_i , which would be a unique integer multiple of the bit period, τ . The longest delay would be 4τ for λ_4 .

In order to be able to decode the signal properly, the receiver would have to be equipped with delay lines complementary to those in the transmitter: In the receiver, the incoming signal would be demultiplexed into the five wavelength channels and the signal in the i th channel would be delayed by $4\tau - \tau_i$, so that the total of transmitter and receiver delays in each channel would be 4τ and, hence, the five signals would come out of the receiver simultaneously, just as the original five bits went into the transmitter simultaneously.

Provided that the differences among the five wavelengths were sufficiently large and the transmitter power were properly adjusted, this system would offer a security advantage in that it would be difficult for an unintended recipient to detect its operation. Moreover, eavesdropping on any single wavelength would not enable one to decode the message.

This work was done by Sir B. Rafol and Keith Wilson of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category.

NPO-20890



This Free-Space Optical Communication System would implement a combination of wavelength-division and time-spread code-division multiplexing.

See the Possibilities.

Imagine. Some of the most brilliant ideas in photonics, assembled for your review. R&D by the world's leading companies in fiberoptics, imaging, transmission, and optical devices, to name a few.

Now imagine the ability to search out and obtain licensable technologies that could help your photonics project see the light of day. Save

your searches and have new technologies pushed out to you as they become available.

Got some brilliant ideas of your own? Then post the results of your own R&D labor for a chance to shine and catch the eye of someone looking to license. **Who knows the possibilities?**

$(R+D)^\infty$



yet2.com

You can also view yet2.com's Tech of the Week by logging onto nasatechbriefs.com

Magnetically Suspended Optical Chopper Wheel

Magnetic bearings offer long life at high speed, without lubrication or wear problems.

Goddard Space Flight Center, Greenbelt, Maryland

A magnetically suspended, motor-driven light-chopping wheel has been developed as an alternative to a traditional light-chopping wheel suspended on ball bearings. This chopper (see figure) is designed to satisfy application-specific requirements to fit into a small volume, dissipate relatively little power, modulate light with only small errors, and have a long operational life (at least 5 years) at a speed of 5,000 rpm. Relative to ball bearings, the magnetic bearings in this chopper are subject to no wear, and unlike ball bearings, magnetic bearings present no need for lubrication.

This chopper satisfies additional stringent requirements for full redundancy of magnetic-bearing coils, motor coils, and sensors. The magnetic bearings are controlled, in all six degrees of freedom of the chopper wheel, by use of a digital signal processor (DSP) operating in conjunction with sensor and driver electronic circuits. The DSP and the other circuitry are contained on a printed-circuit board with overall dimensions of 6 by 8 in. (≈ 15 by 20 cm).

Unique features of the design and its implementation include the following:

- Homopolar magnetic bearings are made in a novel (patent pending) configuration to minimize rotational losses;
- High-resolution, highly linear optical position

sensors with feedback (patent pending) provide automatic gain and off-set control;

- An ironless stator motor assembly, optimized to minimize eddy-current losses, is fabricated by use of a modified printed-circuit-board manufacturing technique;
- The DSP is used to compute 6-axis classical and adaptive control algorithms; and
- At the time of reporting the information for this article, this chopper is the smallest known mechanism that incorporates fully active magnetic bearings with full redundancy of electrical components.

This specific application for which this

chopper has been developed is an infrared-sensing instrument aboard an Earth-observing satellite. Magnetic-bearing systems like those of this chopper, but larger, are under consideration for use in diverse outer-space and terrestrial applications in which rotating wheels would be used to store angular momentum and/or kinetic energy.

This work was done by Ken Blumenstock, Carlos Bernabe, Carlos Hernandez, Ken Lee, Joe Schepis, Clarence Johnson, Maurice Lewis, and Paul Haney of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Machinery category. GSC-14323



This **Optical Chopper Wheel** is magnetically suspended, offering certain advantages over traditional light-chopping wheels, which are suspended on ball bearings.

Fiber-Optic Rotary Joint for Passing High-Definition Video

Fiber-optic transmission overcomes the bandwidth limitation of slip rings.

Dryden Flight Research Center, Edwards, California

A video camera has been integrated with a tracking pedestal (see figure) for tracking of aircraft and spacecraft. The camera is of a high-definition ($1,280 \times 720$ pixels), progressive-scan, 60-frame-per-second digital type that conforms to NASA Standard 2818 (Digital Television Standards for NASA, a copy of which can be obtained via the Internet at <http://www.hq.nasa.gov/office/cio/>

standards/2818.pdf). The camera is mated to a 13.5-to-1,755-mm zoom lens, making it possible to track vehicles at distances up to 100 miles (≈ 160 km).

The digital video signal, at a data rate of 1.5 Gb/s, is transmitted from the camera via an optical fiber. The signal passes through a fiber-optic rotary joint (FORJ) through the horizontal axis of rotation of the pedestal. The


FORJ contains two fiber-optic conductors, each capable of a data rate of 3 Gb/s, that are used to pass high-definition video and camera-control signals. All other power and control signals pass through standard copper slip rings in the pedestal.

The FORJ and the pedestal are commercial products. The pedestal was modified to accept the FORJ. The mod-

ification included the fabrication of a yoke assembly to enable rotation of the upper half of the FORJ with the rotation of the upper half of the pedestal. The FORJ was originally produced for use in submersible remotely operated vehicles with rotating manipulator arms. The high-bandwidth digital video signal cannot pass through conventional copper slip rings of the unmodi-

fied tracking pedestal. The modification of the tracking pedestal to work with the FORJ makes it possible to use high-definition video for tracking experimental aircraft and spacecraft.

This work was done by Tony Trent of Dryden Flight Research Center. For more information, contact Dryden's Commercial Technology at (661) 276-3689. DRC-01-28



Camera Integrated With Tracking Pedestal



Fiber-Optic Rotary Joint

The Integration of the Camera With the Tracking Pedestal was made possible by modification of the pedestal and development of the FORJ.

Mesoscopic Steerable Mirror

This mirror could be slewed rapidly or rotated in small angular increments.

NASA's Jet Propulsion Laboratory, Pasadena, California

A proposed lightweight, micromachined, multi-axis-steerable mirror would have mesoscopic dimensions. Its steering function would involve mesoscopic positional excursions of its support points and would be characterized by rapid slewing and moderate angular precision.


The mirror, its supporting structures, and its steering mechanisms would be fabricated in a four-layer polycrystalline-silicon surface-micromachining process. The mirror would be triangular and would be supported at its corners. The steering mechanisms and supporting structures connected to two of the corners would include electrostatic comb drives, reduction gear trains, gear-driven translation racks, hinged beams, and flexures (see figure).

In one example design, the electrostatic comb drives would operate in four-

phase cycles. For each such cycle, a 19-tooth pinion gear would undergo one revolution. The thrust of each comb drive would be $\approx 1 \mu\text{N}$ and could be applied rapidly enough to sustain rotational speeds up about 4,000 revolutions per second. Two tandem gear trains would reduce the translation to $1.66 \mu\text{m}$ per pinion rotation or, equivalently, $0.415 \mu\text{m}$ per phase step of an electrostatic comb drive, and would increase the torque proportionally.

The triangular mirror would have sides 1.3 mm long. Translation of one corner of the mirror in a $0.415\text{-}\mu\text{m}$ increment as described above would result in a mirror rotation of ≈ 0.3 milliradian. The flexures would serve as smooth (free of stiction) means of bending and rotational coupling be-

Accelerate Your Vision Development



Quickly develop machine vision and scientific imaging solutions with the latest IMAQ™ Vision Builder.

- Integration of your vision application with motion and data acquisition
- Easy-to-use, configurable development environment
- Ability to create LabVIEW™ VIs and Measurement Studio™ code recipes
- Complete set of machine vision and imaging functions
- Vision Solution Wizard

ni.com/info

To learn more about IMAQ Vision Builder, visit ni.com/info and enter na9n28.

NATIONAL INSTRUMENTS™

(800) 811-2046


Fax: (512) 683-9300 • info@ni.com

© Copyright 2001 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

tween the corners of the mirror and beams that hold the mirror on a substrate. The flexures could accommodate rotations and bends of at least half a radian. The maximum speed of translation, of a hinged beam would be 6 mm/s, corresponding to a rate of rotation of about a radian per second.

In principle, the mirror-aiming direction would be a known function of the number of phase steps from starting positions of the electrostatic comb drives. Inasmuch as the out-of-plane bending and torsion of the flexures would generate opposing forces on beams and all the way back to the pinion gears and comb drives, there would be no gear backlash and thus no need to account for backlash in calculating or controlling the mirror-aiming direction.

This work was done by Frank T. Hartley of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Machinery category.
NPO-20971



The Mirror Would Be Coupled to micromachined steering mechanisms and supporting structures.



The International Symposium on
**Optical Science
and Technology**

SPIE's 47th Annual Meeting


Conferences • Courses • Exhibition

7-11 July 2002

Washington State Convention Center, Seattle, Washington USA

Don't miss 80 conferences and 60 courses on cutting-edge topics.

www.spie.org/info/am

 **SPIE** The International Society
for Optical Engineering

annualmeeting@spie.org
Tel: +1 360 676 3290

Making Three-Dimensional Holograms Visible From All Sides

Three-dimensional virtual reality displays could be viewed without visual aids.

NASA's Jet Propulsion Laboratory, Pasadena, California

A technique for projecting holographic images to make both still and moving three-dimensional displays is undergoing development. Unlike older techniques based on stereoscopy to give the appearance of three-dimensionality, the developmental technique would not involve the use of polarizing goggles, goggles equipped with miniature video cameras, or other visual aids. Unlike in holographic display as practiced until now, visibility of the image would not be restricted to a narrow range of directions about a specified line of sight to a holographic projection plate. Instead, the image would be visible from any side or from the top; that is, from any position with a clear line of sight to the projection apparatus. In other words, the display could be viewed as though it were an ordinary three-dimensional object. The technique has obvious potential value for the entertainment industry, and for military uses like displaying battlefield scenes overlaid on three-dimensional terrain maps.


An essential element of the technique is the use of block of silica aerogel as the display medium. Silica aerogel is an open-cell glass foam with a chemical composition similar to that of quartz and a density as low as about one-tenth that of quartz. The sizes of cell features are of the order of 100 Å. Silica aerogel is a suitable display medium because it is nearly com-

pletely transparent, with just enough scattering and reflection to enable the generation of a real image.

The figure illustrates a conceptual application in which a three-dimensional topographical map would be displayed by fusing images projected into a block of silica aerogel from four separate holograms. One could use static holograms to project still images, either alone or in combination with computer-generated holograms to project moving or still images. A computer-generated hologram would be downloaded into a large liquid-crystal, which would be illuminated by a laser projection apparatus to display the holographic image in the aerogel block. For example, the terrain image could be projected from static holograms, while a computer-generated hologram would be used to depict a vehicle moving on the terrain.

This work was done by Frederick Mintz, Tien-Hsin Chao, Peter Tsou, and Nevin Bryant of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free online at www.nasatech.com/tsp under the Physical Sciences category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA Management Office-JPL (818)354-2240. Refer to NPO-20101.



A Three-Dimensional Topographical Map, projected from holograms for display in a block of aerogel, would be visible from any position above the projection table. One of the holograms could be generated by a computer to depict a vehicle moving on the terrain.



NEW Pigtailed Lasiris™ High Power Laser

CUSTOMIZED OEM VERSIONS AVAILABLE

For a structured light source that is ideal for high background noise or power-hungry applications, StockerYale now offers a choice: the Lasiris Magnum Laser or Lasiris HPTL fiber coupled laser. Both include built-in TE cooling and a rugged industrial design, including ESD protection.

HPTL LASER



- Up to 2.6 W collimated beam
- Projects a focusable spot or pattern from a length of optical fiber
- Fits into tight spaces
- Distances the laser diode from heat or radiation

MAGNUM LASER



- Uniform intensity patterns
- Visible red up to 1 W at 670 nm
- Infrared up to 5 W
- Full CDRH safety compliance
- Projects very thin lines; user adjustable
- Modulation built-in

Custom designing lasers for 10 years

Visit us at AeroSense, booth #821



StockerYale
Simply brilliant ideas™

StockerYale Canada Inc.
275 Kesmark, Montreal, Quebec
H9B 3J1 Canada
Tel.: (514) 685-1005 Fax: (514) 685-3307
1-800-814-9552
www.stockeryale.com/LASERS
lasers@stockeryale.com

Copyright © 2002 StockerYale, Inc.
All rights reserved.

New Products

Product of the Month



For Free Info Circle No. 734 or Enter No. 734 at www.nasatech.com/rs

Q-Switched CO₂ Laser

Coherent-DEOS, Coherent Photonics Group, Santa Clara, CA, has introduced the DIAMOND™ GEM Q-400 industrial Q-switched CO₂ laser that combines short, high-peak-power pulses with a rugged sealed package. The laser is designed for drilling and micromachining applications such as PCB microvia drilling, flex circuit machining, and plastics arocessing. It produces 15W average power at 50 kHz repetition rate, and 9.25 microns wavelength. The laser features 2.5 kW peak power with pulse widths controllable to less than 150 ns. Its RF-excited waveguide oscillator is sealed in an all-metal housing.



Miniature Laser Modulators

LINOS Photonics, Milford, MA, offers miniature electro-optic modulators that allow full analog modulation of lasers with

wavelengths in the range from 400 to 700 nm. A second device for the range of 300 to 400 nm also is available. The modular provides modulation frequencies up to 100 MHz, and the Gaussian beam profile of the laser is maintained by the electro-optic process. The unit is supplied as a complete system consisting of the electro-optic modulator, a driver unit, and the power supply.

For Free Info Circle No. 726 or Enter No. 726 at www.nasatech.com/rs



Analog Laser Sensor

Balluff, Florence, KY, offers the BOD-66M analog laser sensor for long-range measurement of parameters such as distance, height, and length in industrial applications. The sensor features 2m range, resolution of less than 5 mm, and analog and digital outputs for industrial automation. Applications include automated assembly, quality control, and dimensional measurement in packaging, material handling, automotive, and paper industries. The sensor uses laser triangulation to determine distance to objects. Target distance corresponds to the sensor's analog output voltage.


For Free Info Circle No. 729 or Enter No. 729 at www.nasatech.com/rs



Linear Light Source

The Opis LightRanger™ light source from Wintriss Engineering Corp., San Diego, CA, is based on high-pressure sodium vapor lamp technology, and provides high-intensity light of 100,000 lux at four feet with a uniform 2" illumination line across an entire web. The light source enables hard-to-detect flaws to be visible to machine vision detection systems. Because of the wide light band produced, the system can neutralize the effect of web bounce. Optical feedback directly from the high-pressure sodium lamp to the 60-kHz lamp power supply provides stability of incident light throughout the estimated 40,000-hour lamp life.

For Free Info Circle No. 732 or Enter No. 732 at www.nasatech.com/rs



PIN Photodiodes

The S6795 and S7747 six-element silicon PIN photodiodes from Hamamatsu Corp., Bridgewater, NJ, are designed with clear plastic packages and operate over the 320 to 1000 nm spectral response range. They achieve peak sensitivity at 800 nm and have a response speed of 400 MHz. The S7747 can be used in violet laser detection applications, including optical disc pickup applications. The S6795 is suited for position detection, laser beam alignment, and CD, DVD, and MO disc signal readout.

For Free Info Circle No. 727 or Enter No. 727 at www.nasatech.com/rs



Fiber-Optic Amplifier

The 7087 fiber-optic amplifier from Automatic Timing & Controls, Lancaster, PA, features a backlit digital LCD display and provides an eight-step automatic gain control that enables fine adjustments. Other features include pushbutton auto-teach, adjustable threshold, NPN or PNP outputs at 100mA, programmable modulation selection for crosstalk protection, red LED light source, light-on/dark-on selectable, and operating temperature from -25° to 55°C.


For Free Info Circle No. 730 or Enter No. 730 at www.nasatech.com/rs



CCD Video Camera

Sony Electronics, Park Ridge, NJ, offers the XCD-SX900UV black and white digital CCD video camera with near-ultraviolet sensitivity. The camera captures images of minute surface details in applications such as semiconductor and fiber-optic inspection. It incorporates a 1/2-type Interline Transfer progressive scan CCD sensor based on Sony's HAD technology. It also features an SXGA video format of 1280 x 960. The camera measures 44 x 33 x 116 mm and is housed in a rugged enclosure for integration into machine vision systems. It is equipped with a C lens mount and has a flexible electronic shutter.

For Free Info Circle No. 733 or Enter No. 733 at www.nasatech.com/rs



Optical Test System

The IQS-500 Intelligent Test System from EXFO, Vanier,

Quebec, Canada, is a modular optical test system that can run up to 100 modules. The scalable system features a Pentium III, 866-MHz processor, 256 MB of memory, four PCI slots, a CD-ROM, and remote control via GPIB, RS-232, or Ethernet. It also features LabVIEW™ drivers, LabWINDOWS™ libraries, and Windows-based IQS Manager software for configuration and status visualization. The system is based on standard PC architecture, and features two USB ports, and external VGA, parallel, and serial ports.

For Free Info Circle No. 725 or Enter No. 725 at www.nasatech.com/rs



Imaging Spectrographs

The Optical Spectroscopy Division of Jobin Yvon Horiba, Edison, NJ, has introduced the TRIAX322 and TRIAX552 imaging spectrographs with dual array capabilities and 320 or 550 mm focal length. The axial exit port offers either resolution or imaging correction, while the lateral exit port is optimized for the best resolution correction. They can switch between two detectors without the need for re-alignment. Suited for CCD/InGaAs array combinations, the spectrographs feature triple-on-axis interchangeable grating turrets, full automation, direct digital scanning drive, and built-in dual RS-232/IEEE-488 interface.

For Free Info Circle No. 728 or Enter No. 728 at www.nasatech.com/rs



Color LED Measurement System

Gamma Scientific, San Diego, CA, has released the DR-2000 LED; a color LED measurement system

that combines a radiometer/photometer with a photometric filter/detector. It performs photometric measurements of any color LED, and is designed for manufacturers of nearly any type of LED-based display. A built-in RS-232 interface allows users to control the system from a laptop or desktop computer. Control of all instrument functions is enabled through the computer interface, including manual and auto ranging modes, dark current suppression, and flux or energy modes.

For Free Info Circle No. 731 or Enter No. 731 at www.nasatech.com/rs



Diode-Pumped Laser

The Jasper™ diode-pumped Nd:YAG laser from New Wave Research, Fremont, CA, offers repetition rates from 100 Hz to 10 kHz with an output power greater than 2.5W at 10 kHz. Measuring 13.7" x 4.5" x 4.3", the unit features a control panel located on the power supply, providing control of all system variables. The laser can be triggered directly from the control panel or from a remote source through a rear-panel BNC. Most laser functions also can be controlled from a PC via an RS-232 port. A motorized optical attenuator provides energy control.

For Free Info Circle No. 735 or Enter No. 735 at www.nasatech.com/rs

Advanced Fatigue-Crack-Growth and Fracture-Mechanics Program

The NASGRO 3.0 computer program is an advanced version of a program used by NASA and the European Space Agency for fracture-control analysis of space-system structures and other hardware. The prior version, NASA/FLAGRO 2.0, was described in "Updated Fatigue-Crack-Growth and Fracture-Mechanics Software" (MSC-22550), *NASA Tech Briefs*, Vol. 19, No. 12 (December 1995), page 74. NASGRO 3.0 affords additional capability for durability and damage-tolerance analysis of aircraft structures and other mechanical systems. Because this code offers state-of-the-art and general capabilities in fracture mechanics and crack-propagation analysis, its usefulness extends beyond aerospace to numerous industrial applications: For example, it can provide guidance for prevention of catastrophic failures that originate in cracklike flaws in offshore oil structures, pressure vessels, pipes, diesel engines, and railroad tank cars. The program is also useful as an instructional device for courses in fatigue and fracture mechanics.

The objective in developing NASGRO 3.0 was to extend NASA/FLAGRO 2.0 (which was released in 1994) to accommodate more recent advancements in fracture mechanics and crack-propagation theory, to meet needs for damage-tolerance and durability analysis of aircraft, and to enable the program to function within the Windows 95/98, Windows NT, and Unix operating systems. The changes made in pursuit of this objective were the following:

- A graphical user interface (GUI) was developed to make input of data easier and more intuitive.
- Load-interactive or retardation routines were added to account for changes in crack-growth rates due to fatigue spectrum (nonconstant) loading. Five different mathematical models have been included: the generalized Willenborg, the modified generalized Willenborg, the Walker-Chang-Willenborg, the strip-yield, and the constant-closure models.
- New and improved crack solutions were added for cases of bolts, cracks from holes, and nonlinear stress distributions.
- Spectrum-input routines have been improved to provide more flexibility in the use of pre-existing spectrum files.
- A materials database has been added, along with a GUI that gives users access to the data from which the material-property curves are derived. A software module called "NASMAT" contains a base of experimental data that are available for easy access, viewing, and use in deriving crack-growth material constants required for safe-life analysis.
- The threshold equation has been improved by incorporation of a newer, more accurate mathematical model of fatigue-crack-growth thresholds.


This program was written by Royce G. Forman of Johnson Space Center; V. Shivakumar, Sami Mettu, Joachim Beek, and Feng Yeh of Lockheed Martin; and Leonard Williams of GB Tech, Inc., and is available at <http://mmpdtdpublic.jsc.nasa.gov/nasgro/nasgromain.html>. MSC-23082

Any Way You Measure 3CCD Performance The Choice Is Panasonic.



Only Panasonic offers 3CCD

cameras in three different chip configurations - 1/2", 1/3" and 1/4" -- to provide the best solution for your specific application. Panasonic 3CCD cameras also feature compatible CCU's that allow you to easily switch camera heads. And all three units accommodate long cable runs of up to 100 feet without the need for signal amplifiers. You'll also find Panasonic 3CCD cameras feature an advanced pixel correction circuit that virtually eliminates image dropouts. It's Panasonic engineering at its best --- any way you measure it.



888-880-VISION (888-880-8474)
www.panasonic.com/mv

Panasonic
 Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.

Software for Sequencing Spacecraft Actions

SEQ_GEN is a component of the Sequence Subsystem computer program, which assists in generating a sequence of commands to be executed by a control computer aboard a spacecraft to perform scientific observations and supporting engineering actions in response to requests by numerous users. SEQ_GEN assists a designer in devising a final, valid sequence. Using SEQ_GEN, the designer prepares a file of requested spacecraft actions. SEQ_GEN then processes this file plus a file of spacecraft- and mission-specific information prepared by another Sequence Subsystem software component to (1) generate the sequence of commands, (2) predict what the commands will cause to happen on the spacecraft, and (3) give warnings when the sequence violates rules or causes misuse of spacecraft systems. SEQ_GEN generates an interactive graphical time-line display of the predictions and warnings. The user can change the sequence by keyboard entry in a text file, or by use of a mouse to add or delete

an item or move an item to a new position on the display. SEQ_GEN then processes the revised input data, starting from a time earlier than the earliest time affected by the change(s). The process is repeated, if necessary, until a valid sequence is produced.

This program was written by Russell M. Brill, Dang Le, Imin Lin, Winthrop Lombard II, Robert Oliphant, Taifun O'Reilly, Jose J. Salcedo, and Thomas W. Starbird of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-20452.

Program Distributes and Tracks Organizational Memoranda

Closed Loop Accounting Management System (CLAMS) is a computer program for Web-based distribution and tracking of memoranda within an organization. An

item for distribution is entered by a user who has administrative access. The item is assigned to affected users, to whom e-mail messages are sent. Upon receipt of such an e-mail message, a user gains access to an "open items" page from a link within the message. From the "open items" page, the user can (1) link to the item, (2) select a "notes" button to leave a reminder about the item, or (3) select a "close" button to close the item, indicating that the user has received and understands the item. CLAMS can be used to effect the automated distribution of new and updated items to users on predetermined lists. CLAMS enables managers to track the statuses of users and distributed items: For a given item, CLAMS can tell (1) who has it open and for how long and (2) who closed it and when; regarding a given user, CLAMS can tell (1) which items the user has open and for how long and (2) which items the user closed and when.

This program was written by Mike Olejarski of United Space Alliance for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category.
KSC-12289

www.ansys.com/aerospace_engine_simulation



Materials



Flat Membrane Device for Dehumidification of Air

Water vapor is not condensed; instead, it is transported to vacuum.

Lyndon B. Johnson Space Center, Houston, Texas

A device based on the transport of water through a membrane to a vacuum has been developed for dehumidifying a stream of air in the life-support system of a spacecraft or space suit. The device could also be adapted to terrestrial use in dehumidification of air in an air-conditioning stream or drying of air or another gas in a chemical processing stream. The design of this device is an advance in that it decreases (relative to prior designs) the weight, power consumption, and volume of the dehumidifier in the life-support system or other gas-circulation system in which the device is used. In the case of a spacecraft or space suit, the design thereby also increases safety and health margins. Although the membranes in the device must be replaced periodically and a vacuum source is essential for its operation, no other dehumidifier works as well in a spacecraft or space suit.

Unless controlled, the concentrations of CO_2 and H_2O in respirable air in a spacecraft or space suit quickly reach unacceptably high levels. Heretofore, life-support systems in spacecraft and space suits have included solid metal hydroxides for depleting exhaled CO_2 , and condensers integrated with cooling sources for removing excess moisture. To enable the condensers to function, such systems must also include microgravitational phase separators and coolant/heat sink subsystems, all of which contribute to weight, volume, and consumption of power.

The present device operates without need for either a coolant/heat sink subsystem or a microgravitational phase separator. Moreover, in the original outer space application, the vacuum needed for operation is available naturally, so that it is not necessary to incur the cost, weight, and power penalty of a vacuum source. Hence, in comparison with breathing air systems of prior design, it is possible to simplify breathing loop interfaces, reduce weight and volume, and decrease the amount of power expended, thereby also saving on the cost of fuel.

The device contains one or more modules in which spaces in a vent-layer assembly alternate with spaces in a vacuum-layer assembly and the vent and vacuum spaces are separated by flat sheets of a polyelectric membrane material that is permeable by water (see figure). The vent-layer assembly includes a vent frame, a metal foam insert, and screens. The frame is rectangular and is sized to optimize the pressure drop characteristics of the vent-gas and water-vapor flows. The metal foam insert is bonded to the top and bottom of the frame and sandwiched between a pair of screens that provide additional support so that the membrane is not torn against the surface of the metal foam. Flow holes connect the central section of the frame to header slots and allow humid gas to enter the frame without leaking into the vacuum space. Dovetailed O rings grooved to fit the perimeter of the frame retain a gasket during assembly of the module. The

The Smallest Color Cameras In The World Are Backed By The Biggest Name In The Industry.



Panasonic color microcameras are big on performance and small in size. In fact, Panasonic offers a color super microcamera with a detachable camera head that measures only 6.7mm in diameter — the smallest in the world. It's ideal for use in various non-intrusive devices where space is limited. When color reproduction is the issue, Panasonic offers a 900,000 pixel CCD color microcamera. And for general applications, Panasonic's DSP color microcamera offers a versatile range of features. Plus, they're all supported by the biggest name in the industry — Panasonic.



888-880-VISION (888-880-8474)
www.panasonic.com/mv

Panasonic
Industrial Cameras


BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.

thickness of the vent layer is chosen to be the minimum thickness needed to maintain top and bottom gasket seals.

The vacuum-layer assembly is similar to the vent-layer assembly except that its flow holes are on the short ends and there is no header for a vacuum-layer, eliminating the need for another set of gaskets on each layer. Inasmuch as the flow of water vapor is a fraction (typically 4 percent by volume) of the flow of the gas to be dehumidified (hereafter called vent gas for short), the vacuum frame can be made thinner than the vent frame to minimize overall volume. This frame is so thin that a single gasket, held in place by a retaining ring, seals against layers above and below the vent layers. The number and size of vacuum holes satisfy two constraints: (1) the minimum equivalent area limits the back pressure of vapor; and (2) the maximum equivalent area restricts the vent flow if one or more membranes rupture. Top and bottom end plates, sized to provide sufficient stiffness, apply an even pressure to the gaskets to prevent leakage. These plates also include ports through which the vent gas flows into and out of the module, plus ports for testing the vent gas.

Modules like the one described above are stacked in alternating layers, beginning and ending with a vacuum frame. The modular nature of the device provides flexibility for changing the membrane area to satisfying requirements for the conditions of a particular application.

This work was done by Karen Murdoch and C. H. Miller of United Technologies for Johnson Space Center. For further information, contact the Johnson Commercial Technology Office at 281-483-3809 or commercialization@jsc.nasa.gov MSC-22878



Water Vapor Diffuses from flowing vent gas through water permeable membranes into a vacuum.

www.ansys.com/aerospace_engine_simulation
 0
www.ansys.com/electronics_packaging_simulation



Inverted Hindle Mount Reduces Sag of a Large, Precise Mirror

The mirror is suspended from above by multiple, equally loaded supports.

Goddard Space Flight Center, Greenbelt, Maryland

A mount has been devised to satisfy a requirement to suspend a highly precise, flat, circular, low-thermal-expansion glass mirror in a horizontal plane with its reflective side down while keeping the reflective mirror surface flat to within a peak-to-valley depth of less 50 nm. The difficulty of the suspension problem and the significance of the mount conceived as the solution of the problem arise from the large size and weight of the mirror (diameter 101.7 cm, thickness 18.8 cm, mass 385 kg).

The mount is an inverted version of the Hindle mount, which was first published in 1945 and is named after its inventor (Dr. J. H. Hindle). The Hindle mount supports a flat, circular mirror on multiple pads that are located so that all of the pads bear the same proportion of the total weight and the sag of the mirror under its own weight between the supports is minimized. The number of support pads in a Hindle mount is an integer multiple of three. The sag can be reduced by increasing the number of support pads. The present mount is based on a Hindle-mount geometry of nine support points grouped into three triangles (see Figure 1).

The original Hindle-mount concept applies to a mirror suspended from its lower face with its reflective side up; the weight of the mirror presses it against the support pads, and the resulting friction often suffices to hold the mirror in place on the pads. In the present inverted Hindle mount, the mirror is suspended





Figure 1. The Nine-Point Hindle Mount includes six supports on a circle with a radius of $0.408D$ and three supports on a circle with a radius of $0.204D$, where D is the outer diameter of the mirror. The supports in each group of three are connected to a triangular plate supported at its centroid, which lies on a circle with radius $0.309D$. When the three triangular plates are picked up at their centroids, equal weight is borne by all nine supports.

When Your Image Is On the Line Count On Panasonic.



Panasonic machine vision cameras deliver the highest levels of reliability to help assure your systems stay up and running. In addition, Panasonic offers industrial cameras for virtually every machine vision application. With features like progressive scanning for high-speed image capture that rivals expensive line scan cameras. And affordable $1/2''$ and $1/3''$ CCD cameras with versatile features and functions ideal for numerous manufacturing applications. When your image is on the line, Panasonic Industrial Cameras provide the reliability you want.



888-880-VISION (888-880-8474)
www.panasonic.com/mv

Panasonic

Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.




Figure 2. Parts of the Inverted Hindle Mount are attached to an aluminum disk of the same size as (and slightly heavier than) the glass mirror that the mount is intended to support. (The aluminum disk was used during development so as not to risk damage to the expensive glass mirror.)

from its upper face; consequently, the weight of the mirror tends to pull it away from its supports, making it necessary to fasten the mirror to the supports in some fashion.

Figure 2 depicts some parts of the present inverted Hindle mount. The nine supports are made of Invar — a low-thermal-expansion Fe/Ni alloy. To distinguish them from the compression-loaded support pads of a traditional Hindle mount, these tensile-loaded supports are called "anchors." The lower end of each

anchor has an area of 3 in.² ($\approx 19.4 \text{ cm}^2$) and is bonded to the face of the mirror by use of 3M's 2216 (or equivalent) clear high-performance epoxy. The upper end of each anchor is tapped to accept a bolt. The upper ends of the anchors in each group of three are bolted loosely, with spherical washers, to a triangular aluminum plate 1 in. (2.54 cm) thick. The loose bolting and spherical washers allow some limited rotation and translation, thereby helping to prevent the buildup of bending moments that could cause the anchors to peel away from the mirror surface at the epoxy joints.

Each plate is supported from above by means of a clevis/ball-joint coupling attached to the plate at the centroid of the triangle defined by the three support points. The clevis is, in turn, supported from above by a threaded rod that passes through a massive overhead frame and engages a nut on top of the frame. The freedom of rotation of the clevis/ball joints contributes to the relief of any bending moments that could, if allowed to build up, cause peeling at the epoxy joints.

Experience in the development of the inverted Hindle mount revealed that it can be difficult to form reliable epoxy bonds between the anchors and the top surface of the mirror. Therefore, the mount must be augmented by handling fixtures with safety features to prevent the mirror from falling in the event of failure of one or more epoxy bonds.

This work was done by David W. Robinson of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Mechanics category.
GSC-14316

HERE'S THE CLINCHER

for anyone

who designs

for assembly.

Less is more.

Less parts, less assembly steps, less assembly time — all yield more productivity and more cost reductions. To achieve this, designing for assembly (DFA) is critical.

PEM® products are made for DFA. Just punch or drill a hole and press a PEM fastener into place. PEM self-clinching fasteners install permanently into thin sheets. There are fewer parts and fewer total pieces to handle during assembly which translates into cost savings. We also offer threadless and multi-function fasteners to further meet your DFA needs.

These include SNAP-TOP® (shown in photo above) standoffs which eliminate the need for screws, locating pins for quick alignment of mating parts, P.C. board fasteners and many others.



For automated installation, our line of PEMserter® presses quickly install PEM fasteners, further reducing assembly time.

Clinch it with PEM
FASTENERS & PRESSES

PEM Fastening Systems
a PennEngineering® company

©2001 210

800-237-4736 • www.pemnet.com




Heart-Pump-Outlet/Cannula Coupling

This coupling is separable, free of leaks, and configured to minimize clotting.

Lyndon B. Johnson Space Center,
Houston, Texas

A fluid coupling has been developed for use in securing a vascular outflow graft (cannula) to the outlet of a surgically implanted NASA/DeBakey heart-assist pump. The design of the coupling can also be adapted to other applications in which it is necessary to



This **Heart-Pump-Outlet/Cannula Coupling** is superior to other couplings (e.g., simple hose-clamp couplings) that were not designed for coupling heart pumps.

join flexible tubes with rigid ones. A joint formed by use of this coupling is separable, yet free of leaks; this is advantageous in that (1) it is necessary to be able to install or remove a pump in accordance with requirements for surgery, sterilization, and pump maintenance, but (2) seepage of blood from an installed pump/cannula joint cannot be tolerated. Moreover, the coupling provides a smooth transition for flow from the pump outlet to the cannula; this feature helps to prevent clotting, which is triggered by flow-surface discontinuities.

The coupling (see figure) includes tapered and threaded surfaces on the pump outlet tube, a differentially tapered locking collet, a connector nut that mates with the thread on the pump outlet tube, and the affected end portion of the cannula. A volume is provided at the upstream end of the tapered outlet-tube surface to allow excess cannula material (including material extruded by the clamping described below) to expand to form a bulbous collar that helps to retain the cannula in place. This volume also facilitates manufacture and assembly, inasmuch as it desensitizes the joint to slight variations in cannula geometry.

The differential angle between the tapered surfaces of the pump outlet and the locking collet helps to clamp the cannula in place and to provide a seal when the connector nut is tightened. The radial clearance between the locking collet and the connector nut is sufficient to allow the collet to move slightly to align itself for uniform clamping of the cannula. The nut can be tightened to obtain the desired clamping and sealing force, or can be loosened to disconnect the pump from the cannula.

This work was done by Bernard J. Rosenbaum of Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Mechanics category.

This invention has been patented by NASA (U.S. Patent No. 6,050,987). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center, (650) 604-5104. Refer to MSC-22865.

Panasonic®

Search

Machine Vision ●

Medical Vision ●

3CCD Cameras ●

Recorders ○

Monitors ○

Engineering Support ○

Contact Us ○


For every detail...

www.panasonic.com/mv

Panasonic Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.

Beyond Image... Engineering





Externally Triggered Microcapsules Release Drugs *In Situ*

Drugs can be released, at designated times, within tumors or other targets.

Lyndon B. Johnson Space Center, Houston, Texas

In an advanced method of administering drugs to target sites in human bodies, the drugs in liquid form are contained in microcapsules that are injected, and then, by exposing the target sites to externally generated electromagnetic fields, the microcapsules are lysed to release the drugs. Such externally triggered microcapsules are intended primarily for use in combined-modality therapies of cancer. In a given application, the external electromagnetic field can be applied to cause the release of the encapsulated drug(s) at a prescribed time or when the microcapsules are confirmed to be located in a specific tissue.

The concept of microencapsulation of drugs was reported in "Microencapsulation of Multiple Drugs" (MSC-22489), *NASA Tech Briefs*, Vol. 20, No. 11 (November 1996), page 92. More recently, an external-triggering method related to the present method was reported in "In Situ Activation of Microencapsulated Drugs (MSC-22866)," *NASA Tech Briefs*, Vol. 24, No. 9 (September 2000), page 64. A microcapsule of the type used in the present method is a multilayer structure that contains a concentrated drug solution. The outer layer of the microcapsule is a polymeric membrane that is both transparent to electromagnetic radiation and insoluble in aqueous fluids. Also contained within the microcapsule, in a compartment next to the outer membrane, is a fluid-filled compartment that contains one or more ferromagnetic thermoparticles.


The microcapsules are designed to be injected into arteries that lead to vascularized tumors or other target tissues (see figure). The outer-membrane polymer and the thermoparticle material are chosen so that the Curie

temperature of the thermoparticles exceeds the melting temperature of the polymer. When the microcapsule-infused target region is exposed to an electromagnetic field of suitable frequency and power density for a specified short time (minutes), the electromagnetic field heats the thermoparticles. The localized heating of the thermoparticles melts a hole in the outer polymeric membrane, thus releasing the drug to the surrounding tissue.

Because the thermoparticles absorb the electromagnetic radiation much more strongly than do the surrounding microcapsule materials and tissues, an electromagnetic field of relatively low power can be used to effect drug release. Regulating the exposure to the electromagnetic field is not a major problem: Heating is automatically limited to the Curie temperature because

above that temperature, the thermoparticles lose their ferromagnetism and thereby become less absorbent to the electromagnetic field.


The ferromagnetic material of thermoparticles can be formulated to have Curie temperatures as high as 80 °C, but because the thermoparticles are typically smaller than 1 μm , heating can be localized well enough to prevent widespread thermal damage to the surrounding tissue. Of course, depending on the application, additional therapeutic advantage might be gained by changing the frequency and/or power of the electromagnetic field, after the microcapsules have been lysed, to obtain controlled hyperthermia to enhance the local effectiveness of the drugs that have been released. In some applications, it could be desirable to effect multiple releases of the same drug or different



Microcapsules Containing One or More Drug(s) are injected into an artery that feeds a tumor — in this case, in the spleen. The capsules are then lysed by applying an electromagnetic field.

INTRODUCING **UMAC** Products

Universal Motion and Automation Controller



Bring the power of Delta Tau's Turbo PMAC® and MACRO® ring technology to a compact, rugged, CE approved and flexible package with the new UMAC™ controllers. Delta Tau has ported these cutting-edge electronic technologies into a modular industrial form factor.

Choose from a variety of processor configurations, digital PWM, +/-10V. analog and stepper axis interfaces, and digital and analog I/O cards. Slide these cards right into the 3U "Euro-rack" in any order, bring your field wiring right to the rack, and you're ready to go!

You can configure the UMAC as a standalone Turbo PMAC, controlling up to 32 axes and thousands of I/O points, communicating by serial port, USB, Ethernet, or most of the popular Field Buses. Optionally, add an enclosed PC/104 embedded computer if you like. Alternately, you can configure the UMAC as a remote station on a MACRO ring, providing all of the local field interfacing and communicating back to the central controller at 125 Mbits/sec over a fiber-optic ring.

Whatever your control needs, easy or difficult, small or large, the UMAC can be quickly configured for your application!

Up to 32 Axes of Control

Full Turbo PMAC Software Capabilities

***Integrated Computation, Axis Interface,
I/O and Breakout Functions***

Master or Slave on MACRO Ring

Auto Addressing and Configuration



DELTA TAU
Data Systems, Inc.

NEW IDEAS IN MOTION...

21314 Lassen Street
Chatsworth, CA 91311

Tel: (818) 998-2095


Fax: (818) 998-7807

www.deltatau.com

e-mail: sales@deltatau.com

*For international sales,
contact our U.S. Headquarters*

INNOVATIVE



ACCURIDE. THE PIONEER IN PRECISION SLIDES AND SOLUTIONS.


Accuride is the largest company in the world dedicated to the design and manufacture of precision ball bearing slides. For more than 35 years, we've worked side-by-side with our customers to pioneer new applications and solve tough design challenges through sound engineering, expert tooling and innovative solutions.

MORE SLIDES

- ▶ 8" to 60" in length
- ▶ 35 to 500 lb. load capacity
- ▶ Standard and customized designs
- ▶ Range of brackets and accessories
- ▶ Network of stocking distributors

MORE SOLUTIONS

- ▶ Engineering and tooling expertise
- ▶ Expert technical assistance
- ▶ Worldwide sales and service
- ▶ Global manufacturing
- ▶ ISO 9001 certified facilities



drugs by use of injecting mixtures of microcapsules containing ferromagnetic particles with different Curie temperatures that could be triggered at different times, as determined by the strength of the electromagnetic field and the duration of exposure.

This work was done by Dennis R. Morrison and Benjamin Mosier of Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Bio-Medical category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Johnson Space Center, (281) 483-0837. Refer to MSC-22939.

Combinatorial Drug Design Augmented by Information Theory

**It may be possible to
suppress drug-resistant
viruses.**

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

A proposed method of designing antiviral drugs provides for the utilization of combinatorial-chemistry techniques that have been used previously for this purpose, in conjunction with applicable principles of information theory. In its information-theoretic aspect, the method can be characterized as one of maximizing the mutual information between (1) ensembles of drugs and (2) ensembles of viruses that one seeks to combat by use of the drugs (denoted in the art as targets). The method would entail increases in the time and cost of development of drugs, but these disadvantages could be offset by reduction or prevention of the emergence of drug-resistant viral populations.

Heretofore, it has been standard practice to design an antiviral drug to bind to a "consensus-sequence" protein of a viral species or target ensemble. However, consensus-sequence proteins are conceptual only; they do not occur in nature. In treatment-naïve patients (that is, patients who have not taken

the drug), many viral targets are polymorphic, such that the drug is not specific to many of the mutants in the target population. As a consequence, the drug-resistant mutants quickly become the dominant species in the viral population; in other words, the viral targets become drug-resistant.

The proposed method is based partly on recognition that the ensemble of proteins of a viral target forms a "quasispecies" of mutants characterized by a particular entropic profile. Hence, one should have a greater chance of suppressing the rise of drug-resistant mutants through combinatorial design of a drug to combat the quasispecies, rather than the consensus-sequence species. One would seek a drug that binds not only to the consensus target but also to its mutants. Depending on the viral target, the most effective drug might, itself, be a quasispecies in that it would be an ensemble of drugs.

An ensemble of drugs with substitution probabilities complementary to those of the entropic profile of the target could be even more effective. Such an ensemble of drugs could be designed in a procedure that minimizes the conditional target entropy. In such a procedure, combinatorial ensembles of drugs would be used on mixtures of targets prepared according to the treatment-naïve substitution probabilities. In a sequence of "passes," the target ensemble would be treated with a drug ensemble and then resequenced to measure the remaining entropy of the target ensemble, given the drug ensemble. By use of a suitable algorithm, the combinatorial drug ensemble could then be modified in further steps until the conditional target entropy was minimal, at which point the drug ensemble could be considered optimal.

This work was done by Christoph Adami of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Bio-Medical category.


*In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to Intellectual Property group
JPL*

*Mail Stop 202-233
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240*

E-mail: ipgroup@jpl.nasa.gov

Refer to NPO-30252, volume and number of this NASA Tech Briefs issue, and the page number.

INNOVATION



THE 2907. THE NARROWEST BALL BEARING SLIDE FOR 1U TO 4U CHASSIS.


Introducing the industry's narrowest, 100% ball bearing slide for 1U to 4U chassis. This versatile server slide offers superior movement and unparalleled mounting flexibility to work with an array of rail configurations. It's just another smart product innovation from Accuride.

MORE ACCESS

- ▶ .38" wide
- ▶ 1.62" high
- ▶ 2" of over travel for access to entire unit
- ▶ Lock-out feature holds chassis stable while servicing

MORE FLEXIBILITY

- ▶ 100 lb. load rating
- ▶ Lever disconnect provides easy chassis removal & reinsertion
- ▶ Adapts to a wide range of chassis sizes
- ▶ Even lengths: 12 to 30 inches



**CALL 562-903-0263
OR VISIT WWW.ACCURIDE.COM
FOR YOUR SOLUTION.**

Accuride®

The Leader In Precision Slide Solutions

This product is covered by U.S. patents issued and pending. ©2002 Accuride International Inc.



Multiple-Path-Length Optical Absorbance Cell

Wide dynamic range is provided for measuring widely different concentrations of CDOM.

Stennis Space Center, Mississippi

An optical absorbance cell that offers a selection of multiple optical path lengths has been developed as part of a portable spectrometric instrument that measures absorption spectra of small samples of water and that costs less than does a conventional, non-portable laboratory spectrometer. The instrument is intended, more specifically, for use in studying colored dissolved organic matter (CDOM) in seawater, especially in coastal regions. Accurate characterization of CDOM is necessary for building bio-optical mathematical models of seawater. The multiple path lengths of the absorption cell afford a wide range of sensitivity needed for measuring the optical absorbances associated with the

wide range of concentrations of CDOM observed in nature.

The instrument operates in the wavelength range of 370 to 725 nm. The major subsystems of the instrument (see figure) include a color-balanced light source; the absorption cell; a peristaltic pump; a high-precision, low-noise fiber-optic spectrometer; and a laptop or other personal computer. A fiber-optic cable transmits light from the source to the absorption cell. Other optical fibers transmit light from the absorption cell to the spectrometer, as described below.

The absorption cell is of a type known in the art as a liquid-core waveguide: the liquid to be characterized is

contained in a narrow tube. The material of the tube or a material coating the outside of the tube is chosen to be of an index of refraction less than that of the liquid so that light propagating inside the liquid remains confined by total internal reflection. Thus, the liquid and tube constitute an optical waveguide or optical fiber.

The tube has an inner diameter of 2 mm and is coiled for compactness. The peristaltic pump draws the sample water from a beaker into and along the tube and discharges the water into another beaker. Light that has propagated through the liquid in the tube is collected by an optical fiber at path lengths of 2, 10, 50, and 200 cm from

Driving with confidence

Instron's no-compromise technology is deep and flexible, with a product range designed to meet the needs of every budget at every level of manufacturing sophistication. Our instruments test all of the earth's man-made and natural materials. Tensile, tension, torsion, compression, fatigue, hardness, impact and service life machines with software developed for simple or advanced design standards combine with the industry's leading application engineering for optimum project success. Take the high road and standardize on Instron quality and reliability. We are the constant for critical applications throughout all industries. You can own the Instron difference. Visit www.instron.com. The difference is measurable.



INSTRON
www.instron.com



▲ 8800 Servohydraulic Testing Systems



▲ SF 1288 Spring Tester



▲ Universal Testers



▲ Rockwell 2000 Tester



▲ Hand-Held Tester



▲ Dynatup 9200 Series

Instron Corporation ■ 100 Royall Street ■ Canton, MA 02021 ■ Tel: 800-564-8378 ■ Fax: 781-575-5751 ■ Email: program_info@instron.com

Take a Closer Look...

- 100, 200, 300 amu models
- Sensitivity to 5×10^{-14} Torr
- Better than 1/2 amu resolution
- Dual ThO_2Ir filament
- Long-lasting electron multiplier
- 6 decades of dynamic range
- Windows software

RGA's starting at \$3750


Residual Gas Analyzers from SRS are designed to handle the toughest environments from basic research to semiconductor process monitoring. Thousands of SRS RGAs are in use worldwide, and have earned us a reputation for producing quality vacuum instrumentation at reasonable prices.

Our RGAs have greater dynamic range, higher resolution and better linearity than competitive models, and are easier to use. In addition, a dual ThO_2Ir filament and a unique four channel electron multiplier give SRS RGAs a longer lifetime than other designs.

Simply put, SRS RGAs offer better performance and value than any other system.



Stanford Research Systems
Phone (408) 744-9040
Fax (408) 744-9049
email: info@thinkSRS.com
www.thinkSRS.com



**Fast.
Reliable.
Safe.
Everything
automated
riveting
should be.**



Introducing POPmatic Point & Set™, the first reliable auto-feed rivet system.


POPmatic Point & Set, our new auto-feed rivet system, delivers what no riveting tool has before. Consistent riveting at a rate faster than any current hand tool. Designed with a safe, self loading hopper that holds up to 2500 rivets, Point & Set accelerates the riveting process to previously impossible speeds, meeting the requirements of any production line. It's reliability in an otherwise unreliable world. For more information, call us at 203-925-4424 or visit us on the web at www.emhart.com

Emhart®
POPMATIC

A BLACK & DECKER COMPANY

CERTIFIED
ISO 9001 • QS 9000

For Free Info Circle No. 411 or
Enter No. 411 at www.nasatech.com/rs



The **Optical Absorbance Cell** of this instrument is a liquid-core waveguide that includes fiber-optic taps for measuring absorption over several different path lengths.

the light-input end. By means of a fiber-optic switch, the light from one of these optical path lengths is selected for transmission to the spectrometer via a fiber-optic cable. The spectrometer readings are transmitted to the computer for analysis.

In tests using phenol red secondary standards, the instrument exhibited a baseline repeatability in absorbance of better than 1 mAU. During absorption measurements of natural CDOM samples, the instrument exhibited a sensitivity of about 0.002 m^{-1} at a wavelength of 370 nm. On the other hand, it was found that by using the 2-cm path length cell, one could measure CDOM absorbance as high as 200 m^{-1} at 370 nm. Hence, the

instrument has an exceptional dynamic range, as needed to measure a wide range of CDOM concentrations.

This work was done by Richard L. Miller of Stennis Space Center and Mathias Belz and Su Yi Liu of World Precision Instruments Inc.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to World Precision Instruments Inc.

*175 Sarasota Center Boulevard
Sarasota, FL 34240*

Refer to SSC-00143, volume and number of this NASA Tech Briefs issue, and the page number.

Model of a Fluidized Bed Containing a Mixture of Particles

Predictions thus far are in reasonable agreement with experimental data.

NASA's Jet Propulsion Laboratory, Pasadena, California

A mathematical model has been developed for use in analyzing the dynamics of an isothermal, non-chemically-reacting mixture of particles in a bubbling fluidized bed. Although the model has generic validity, it is intended, more specifically, to be applied to a fluidized bed that contains a mixture of sand and biomass particles, fluidized by steam. The model includes components in common with the mod-

els described in "Model of Pyrolysis of Biomass in a Fluidized-Bed Reactor" (NPO-20708), *NASA Tech Briefs*, Vol. 25, No. 6 (June 2001), page 59 and "Multiphase-Flow Model of Fluidized-Bed Pyrolysis of Biomass" (NPO-20789), *NASA Tech Briefs*, Vol. 26, No. 2 (February 2002), page 56.

The derivation of the model follows a multifluid approach according to which macroscopic transport equations



IF YOU CAN THINK IT, WE CAN DO IT.

Emhart is a world leader in the design and supply of innovative fastening and assembly technology. From concept through installation, whether you're manufacturing around the corner or around the globe, Emhart provides cost-effective solutions for assembly applications. Visit us at www.emhart.com

Emhart®

A BLACK & DECKER COMPANY

Yardley SHARPSERT® Inserts

Precision Engineered For Chip-free Installation & Superior Holding Power In Plastics, Particle Board & Wood



REGULAR/SHORT SERIES



FLANGED SERIES

- Precision engineered for pressed-in, thermal or ultrasonic installation.
- Specially designed curved hooks "lock" firmly into the base material providing strong resistance to pull-out & rotation.
- Flanged series is ideal for applications where pull-out and pull-through are a concern.
- Available from stock in a wide range of sizes from 2-56 to 5/16-18 (metric M2 to M8) in Brass.



ORDER ON-LINE at www.yardleyproducts.com

10 West College Avenue • P.O. Box 357 • Yardley, PA 19067-8357

Toll Free: 1-800-457-0154

Fax: 215-493-6796

E-mail: info@yardleyproducts.com

For Free Info Circle No. 572 or
Enter No. 572 at www.nasatech.com/rs

Fast Response RTD's for dynamic temperature tracking



Unique low mass sensing element responds quickly to changing temperatures

2 second time constant in flowing water • Stainless steel cases for direct immersion • Platinum, nickel, copper elements: 10 to 1000 Ω • Straight, threaded and cut-to-length styles • -269 to 260°C (-452 to 500°F) range

Process lines • Deep fryers • Commercial appliances and ovens • Hot melt glue machines
• Energy management • Cryogenic equipment
• Compressors • Oil and water baths

MINCO


Minco Products, Inc.

7300 Commerce Lane / Minneapolis, MN 55432-3177 U.S.A.

Tel: 1-763-571-3121 / Fax: 1-763-571-0927 / www.minco.com

For Free Info Circle No. 589 or
Enter No. 589 at www.nasatech.com/rs

Physical Sciences



The Time-Averaged Solids Pressure as a function of height along the wall of a bed of glass beads fluidized with air was computed by the model and measured at superficial gas speeds of 0.4, 0.6, and 0.8 m/s. (The beads had a diameter of 0.5 mm and a density of 2.5 g/cm³, the channel had a square cross section 12.7 × 12.7 cm, and the bed was initially filled with beads to a depth of 43 cm.)

are derived by taking suitable ensemble averages of the equations for the local dynamics of the gas and particle phases. A standard phasic ensemble average is selected for the gas phase. For the particles, transport equations for each particle species (e.g., a set of equations for sand and another for biomass) are derived, starting with concepts from kinetic theory. An important difference from classical kinetic theory occurs because inelasticity of collisions between macroscopic particles and the consequent dissipation of energy must be represented by appropriate models. Furthermore, the interstitial gas exerts drag on the particles, leading to interaction terms in the averaged transport equations. One especially notable component of the theory is the concept of granular temperature, which represents the mean kinetic energy associated with fluctuations in the velocities of the particles.

The resulting model equations describe the dynamics in terms of the conservation of mass, momentum, and granular temperature for each species of particles. These equations can describe the independent accelerations of, and the exchanges of momentum and energy among, the particle species. The equations for the particle species are closed by providing a separate Gaussian distribution of velocity for each particle species; this provision is valid as long as gradients of the mean variables are small and the particles behave approximately as nearly elastic hard spheres. In the regions of very high solids volume fractions, the stress tensor is augmented by a frictional-transfer submodel of stress vs. strain.

The model has been applied in several test cases: (1) predictions of the shear and normal stresses in homogeneous shear flows, (2) simulations of the particle pressure along the wall of a bubbling bed, and (3) a comparison between simulations of monodisperse and binary mixtures in a homogeneously aerated bed. For cases for which experimental data were available, the results of the simulations were found to approximate the data reasonably well (for example, see figure).

This work was done by Josette Bellan and Danny Lathouwers of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category.

NPO-20937



$(R+D)^{\infty}$

Imagine. 25% of the world's R&D expenditures at your fingertips. The ability to see the vision of some of the world's greatest scientists and engineers. To share their thinking.

Now imagine the ability to search out and obtain licensable technologies that could make your job easier and your own products better/faster/smaller/less expensive.

Or maybe post the fruits of your own R&D labor for all the world to see.


Think of the possibilities.

yet2.com

Thin-Film Force Measurement with Tekscan's ELF System

Features Include:

- Real-Time Display
- Movie Recording
- ASCII File Output
- Adjustable Sensitivity
- LabVIEW Capabilities
- Sample Rates to 5.7kHz



*FlexiForce™ sensor used here
for carseat belt-release forces*



*ELF System for steering wheel grip.
ELF electronics and sensors shown.*

Applications Include:

- Automotive R&D
- Ergonomic Studies
- Fitness Equipment
- Diagnostic Devices
- Consumer Products
- Industrial Machinery

www.Tekscan.com

Boston, MA ♦ USA ♦ Tel 800-248-3669 / 617-464-4500 ♦ flexiforce@tekscan.com

For Free Info Circle No. 575 or
Enter No. 575 at www.nasatech.com/rs

Globe Motors™
EXPERTS IN MOTION CONTROL



Fire with Maximum Control

Get maximum power and performance with Globe Motors' high-precision, miniature electric motors and motorized devices for MIL/AERO applications. They meet high-performance standards, tight tolerances, and stringent specifications.

AS9000
CERTIFIED

937.228.3171
Fax 937.229.8531

emotion
WWW.GLOBE-MOTORS.COM

Physical Sciences

Refractive Secondary Concentrators for Solar Thermal Systems

**Concentration ratios as high as 10^4 and
operating temperatures $>2,000$ K are
anticipated.**

John H. Glenn Research Center, Cleveland, Ohio

High-throughput, non-imaging, secondary concentrating optics that utilize refraction and total internal reflection are undergoing development for use in conjunction with advanced primary solar concentrators to provide solar thermal energy for space applications. This development is prompted by (1) a need to concentrate sunlight by factors of as much as 10^4 to satisfy design and operating requirements for some advanced solar thermal systems and (2) the impracticality of fabricating primary concentrators with sufficient precision to afford such high concentration ratios by themselves. Figure 1 illustrates the operation of a refractive secondary concentrator.

The innovative refractive secondary concentrator offers significant advantages over all other types of secondary concentrators. The refractive secondary offers the highest throughput efficiency, provides for flux tailoring, requires no active cooling, relaxes the pointing and tracking requirements of the primary concentrator, and enables very high system concentration ratios. This technology has broad applicability to any system that requires the conversion of solar energy to heat, including electric power generation, thermal propulsion and high temperature furnaces. NASA Glenn initiated the development of the refractive secondary concentrator in support of Shooting Star, a solar thermal propulsion flight experiment, and continued the development in support of Space Solar Power.

A prototype sapphire refractive secondary concentrator (see Figure 2), has completed solar vacuum performance testing using a liquid-cooled calorimeter in NASA Glenn's Tank 6 facility. The effort involved the design and fabrication of a sapphire refractive secondary concentrator, design and fabrication of a calorimeter and its support systems, calibration of the calorimeter, on-sun vacuum testing of the refractive secondary, and comparing the test results with modeling predictions.

The prototype refractive secondary concentrator, measuring 3.5 in. (8.9 cm) in diameter and 11.2 in. (28.5 cm) long, was designed for the Tank 6 facility and the existing primary concentrator/solar simulator system. Ray trace optics software was used to model the secondary concentrator resulting in predicted efficiency without an antireflective coating of 90 percent. The solar vacuum test results indicate an average throughput effi-




Figure 1. A **Refractive Secondary Concentrator** efficiently concentrates solar energy from a primary concentrator then allows the energy to escape onto a receiver cavity.




Figure 2. A Prototype Sapphire Refractive Secondary Concentrator is shown.

ciency of 87 percent, which agrees well with the modeling predictions. It is anticipated that reduction of a known reflection loss off of the inlet surface by applying an antireflective coating to that surface would result in a secondary concentrator throughput efficiency of approximately 93 percent. Potential future activities to further develop the technology include high temperature, high power throughput tests, antireflective coating tests, and additional material characterization and interaction tests.

This work was done by Wayne A. Wong and Steven M. Geng of Glenn Research Center and Robert P. Macosko and Charles H. Castle of the Analex Corporation. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17149.

Cold Flow Calorimeter

This apparatus can measure a rapidly varying heat-transfer coefficient.

*Marshall Space Flight Center,
Alabama*

The cold flow calorimeter is an apparatus for measuring a possibly rapidly varying heat-transfer coefficient on a surface. The cold flow calorimeter includes (1) a small strain gauge bonded to a small, thin steel shim that is placed on the surface of interest and (2) a circuit that controls the electric power supplied to the strain gauge to keep the strain-gauge grid at a constant temperature [e.g., 150 °F (≈66 °C)]. The instantaneous value of the heat-transfer coefficient is deduced from


the instantaneous power required to maintain the constant temperature. The heat-transfer coefficient measurable by use of this apparatus can range from values characteristic of natural convection to values as large as about 1,000 Btu/(ft·h·°R) [≈1.7 kW/(m·K)].

In the original application for which this apparatus was conceived, there is a need to measure heat-transfer coefficients along an O-ring surface in a nozzle joint in a solid-fuel rocket motor. In this application, there is a gas path to the sealing O ring. The cold flow calorimeter makes it possible to determine the coefficient of transfer of heat

from a confined gas jet to the sealing O ring. The measurement data obtained by use of the cold flow calorimeter can be used to verify solutions from computational fluid dynamics, determine spreading factors, and increase the accuracy of predictions of the transfer of heat to an O ring to which there is a confined gas path.

This work was done by Ed Mathias and John Shipley of Thiokol Corp. for Marshall Space Flight Center. For additional information, please contact Thiokol Corp. at (435) 863-2268.

MFS-31463



This is rocket science... So much rides on superior imaging.

True. EDT's data interface boards are exceptionally fast. But when years of planning and research are at stake – not to mention millions of dollars – speed is only half the equation. Scientific and technological breakthroughs demand dependable performance.

EDT masters the challenge with products featuring simple and practical designs. Built to tough military specifications, they handle the most advanced camera

specifications. And our latest models come complete with PCI/RCI fiber-optic interface for flawless image transfer and total flexibility in locating your computer.

It isn't rocket science when it comes to selecting the best interface cards. Contact EDT today and see how our products provide the extraordinary performance your work demands... with engineering customer-support that ensures seamless integration of your system.



Engineering Design Team, Inc.

1100 NW Compton Dr., Suite 306, Beaverton, Oregon 97006
Phone: 1-800-435-4320 • Fax: (503) 690-1243
email: info@edt.com • www.edt.com



Methodology for Tracking Hazards and Predicting Failures

This methodology can increase safety and reliability while reducing costs in all industries.

John F. Kennedy Space Center, Florida

The Continuous Hazard Tracking and Failure Prediction Methodology (CHTFPM) is a proactive methodology for gathering and analyzing information about a system in order to prevent accidents and system failures. The proactivity of the CHTFPM places it in contrast to conventional formal inductive and deductive hazard-analysis methodologies, which are limited in their effectiveness, in that they do not provide real-time information on whether the conditions in a system are becoming hazardous and could lead to a system malfunction: the conventional methodologies basically provide feedback on hazards after accidents have happened. The CHTFPM could be applied to advantage in almost all industries.

The CHTFPM involves the use of techniques from the arts of work sampling and control charting. With respect to a given system, random sampling is performed in order to detect and observe conditions, called "dendritics," that could result in accidents or unacceptable risks. The collected data are then used to generate an abstract data control chart. On the basis of the pattern of the control chart, the system is said to be "under control" (in essence, safe and thus not to be disturbed) or else "out of control," in which case it is investigated for the potential emergence of hazards from the observed conditions. The results of the investigation can provide guidance for steps to be taken to ameliorate the hazardous conditions to keep the system safe.

The steps in the evaluation and correction of a system according to the CHTFPM (see figure) are the following:

1. Define the dendritics by use of the established techniques of preliminary hazard analysis (PHA), fault-tree analysis (FTA), system safety analysis (SAA), system hazard analysis (SHA), failure mode and effects analysis/critical items list (FMEA/CIL), Pareto analysis, problem reporting and corrective action (PRACA), and/or safety checklists.
2. Develop the random-sampling scheme.

3. Construct the control chart from the samples.
4. Develop a mathematical model.
5. Test the control-chart observations for actual or potential "out of control" conditions.
6. Take appropriate action to prevent or eliminate any "out of control" condition.

Step 1 is the fundamental to everything else in the CHTFPM: the effectiveness of the CHTFPM depends on the identification of the dendritics for sampling in a given system. Regarding the techniques used in step 1:

- PHA can give the analyst both the necessary introduction of the system and an initial assessment of risk, identification of safety-critical areas, and evaluation of hazards.
- The emphasis on conditions, instead of events, is the single most compelling feature of the FMEA for dendritic construction.
- The CIL, derived from the FMEA, is useful for ensuring that the most


critical items are factored into dendritic construction.

- FTA can contribute to understanding of interactions among components in the system. The single most important tool for dendritic construction is the FMEA.

The sampling feature makes CHTFPM a cost-effective tool for dynamically analyzing and tracking a system for dendritics. The sampling can be performed in conjunction with other routine job functions. Sample data are used to design a control chart for use in ensuring that the system remains within an acceptable range (between the control limits); or, in other words, that it does not shift "out of control." The more representative the sample is of the process in the system, the easier it is to detect shifts.

A major problem in the CHTFPM is to choose the size and frequency of samples. In general terms, the solution must be a compromise among considerations of the cost of sampling, the loss associated with running the process out of control, and the occurrence of various system shifts attributable to natural variability (essentially, background noise) or to assignable causes (e.g., machinery malfunctions or operator errors). A process that is operating with only natural variability is said to be in statistical control. A system operating in the presence of assignable causes is said to be "out of control." The control chart provides an effective means of detecting assignable causes, identifying currently problematic areas, and predicting future problematic areas. By providing information regarding the tendency of the system, the control chart indicates when the system tends to become hazardous, facilitating the implementation of corrective steps.

This work was done by Rolando Quintana of the University of Texas for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Information Sciences category. KSC-12066



Information About a System is gathered by sampling in a prescribed manner, the information is analyzed to detect hazards, and corrective action is taken.

FREE SUBSCRIPTION REQUEST FORM

STAY ON THE CUTTING EDGE

Renew or get your own copy of *NASA Tech Briefs*. You can qualify at our website:
www.nasatech.com/subscribe or Fax this form to **856-786-0861**

Please print

Reader ID Number 000 | | | | | | | |

Name _____

Title _____

Company _____

Address _____

City/St/Zip _____

Check one of the following:

☐ New Subscription

☐ Renewal

☐ Change of address

For Change of Address and/or
Renewal you must provide the
11-digit Reader ID Number from
your mailing label.

You can also
mail this form to:

NASA Tech Briefs
P.O. Box 10523
Riverton, NJ 08076-9023

1 Do you wish to receive (continue to receive) *NASA Tech Briefs*? ☐ Yes ☐ No

Please check preferred format:

a. ☐ Print Version of *NASA Tech Briefs* only. **FREE**

b. ☐ Digital (PDF) Version of *NASA Tech Briefs* only. **FREE**

c. ☐ BOTH the Print AND Digital (PDF) Versions of *NASA Tech Briefs**

Signature _____ Date _____

Bus.Tel. No. _____ Bus.Fax No. _____

e-mail _____

*If you checked "c" above that you wish to receive BOTH the Print and Digital Versions of
NASA Tech Briefs, there is a small service fee of \$2.00 per month (\$24 annually).

☐ My check (for \$24) is enclosed ☐ Bill me

☐ Charge to my: ☐ American Express ☐ Discover Card ☐ Master Card ☐ Visa

Card # _____ Exp. Date _____

Signature _____

2 Which of the following best describes
your industry or service? (check one)

- E ☐ Electronics
- S ☐ Computers
- X ☐ Communications
- O ☐ Automotive
- T ☐ Transportation
- M ☐ Materials/Chemicals
- P ☐ Power/Energy
- B ☐ Bio/Medical
- J ☐ Consumer Product Manufacturing
- Q ☐ Industrial Machinery & Equip.
- A ☐ Aerospace
- G ☐ Government
- D ☐ Defense
- R ☐ Research Lab
- U ☐ University
- Z ☐ Other (specify): _____

3 Your engineering responsibility is:
(check one)

- A ☐ Manage Engineering Department
- B ☐ Manage a Project Team
- C ☐ Manage a Project
- D ☐ Member of a Project Team
- E ☐ Other (specify) _____

4 Your job functions are:

- (please check all that apply)
- 10 ☐ Design & Development Engineering (Inc. applied R&D)
- 12 ☐ Testing & Quality Control
- 13 ☐ Manufacturing & Production
- 14 ☐ Engineering Management
- 16 ☐ General & Corporate Management
- 17 ☐ Basic R&D
- 15 ☐ Other (specify) _____

Write in the number of your
principal job function _____

5 a. In which of the following categories do you
recommend, specify, or authorize the
purchase of products? (check all that apply)

- 01 ☐ Electronics
- 02 ☐ Photonics
- 03 ☐ Computers/Peripherals
- 04 ☐ Software
- 05 ☐ Mechanical Components
- 06 ☐ Materials
- 07 ☐ None of the above

5 b. Products you recommend, specify, or
authorize for purchase: (check all that apply)

- 32 ☐ ICs & semiconductors
- 33 ☐ Connectors/interconnections/
packaging/ enclosures
- 02 ☐ Board-level products
- 18 ☐ Sensors/transducers/detectors
- 16 ☐ Data acquisition
- 19 ☐ Test & measurement instruments
- 34 ☐ Power supplies & batteries
- 35 ☐ PCs & laptops
- 06 ☐ Workstations
- 36 ☐ EDA/CAE software
- 37 ☐ CAD/CAM software
- 17 ☐ Imaging/video/cameras
- 38 ☐ Lasers & laser systems
- 39 ☐ Optics/optical components
- 40 ☐ Fiber optics
- 41 ☐ Optical design software
- 20 ☐ Motion control/positioning equipment
- 30 ☐ Fluid power and fluid handling devices
- 31 ☐ Power transmission/motors & drives
- 42 ☐ Rapid prototyping and tooling
- 13 ☐ Metals
- 28 ☐ Plastics & ceramics
- 27 ☐ Composites
- 43 ☐ Coatings
- 80 ☐ None of the above

6 How many engineers and scientists work at
this address? (check one)

- A ☐ 1 F ☐ 100-249
- B ☐ 2-5 G ☐ 250-499
- C ☐ 6-19 H ☐ 500-999
- D ☐ 20-49 J ☐ over 1000
- E ☐ 50-99

7 To which of the following publications do you
subscribe? (check all that apply)

- 01 ☐ Cadalyst
- 02 ☐ Cadence
- 03 ☐ Computer-Aided Engineering
- 05 ☐ Designfax
- 06 ☐ Design News
- 07 ☐ Desktop Engineering
- 08 ☐ EDN
- 09 ☐ Electronic Design
- 10 ☐ Machine Design
- 11 ☐ Mechanical Engineering
- 12 ☐ Product Design & Development
- 13 ☐ Sensors
- 14 ☐ Test & Measurement World
- 15 ☐ Laser Focus World
- 16 ☐ Photonics Spectra
- 17 ☐ None of the above

8 Would you like to receive a free e-mail newsletter
from *NASA Tech Briefs*?

☐ Yes ☐ No

Your e-mail address _____

You may receive renewal reminders via e-mail.
Do you want to receive other business-to-business
third party e-mail offers from *NASA Tech Briefs*?

☐ Yes ☐ No

Estimating Heterodyne-Interferometer Polarization Leakage

Correction for the nonlinearity contributed by polarization leakage can be made in real time.

NASA's Jet Propulsion Laboratory, Pasadena, California

A method of estimating and correcting for the effect of polarization leakage on the response of a heterodyne optical interferometer has been devised. In a typical application in which a heterodyne interferometer is used as a displacement or length gauge, the effect of the polarization leakage is a nonlinearity that typically gives rise to an error of the order of 1 nm in the displacement or length. By use of the present method, it should eventually be possible, in principle, to reduce the error to the order of 10 pm or less. The technique is primarily computational and does not require any additional interferometer hardware. Moreover, the computations can be performed on almost any modern computer in real time.

The figure schematically depicts a typical heterodyne interferometer. The interferometer utilizes two laser beams with frequencies ν_1 and ν_2 that differ by a known small amount (typically, $|\nu_1 - \nu_2|$ is of the order of 1 to 100 kHz). Beams 1 and 2 are p- and s-polarized, respectively, in the reference frame of two polarizing beam splitters. Polarizers, polarization rotators, and a nonpolarizing beam splitter are used, along with the polarizing beam splitters, to separate and combine the beams at several junctions along the light path. The beams are made to interfere with each other at two photodetectors called the "reference" (R) and the "unknown" (U) photodetector, respectively. Ideally, all of the s-polarized light that arrives at the lower beam splitter makes

one and only one round trip along the lower horizontal interferometer arm between two corner-cube retroreflectors, and then impinges on the U photodiode.

The difference-frequency outputs of the two photodetectors are the desired heterodyne signals. Small variations in the distance between the two retroreflectors are what one usually seeks to measure. In the ideal case, one could compute these displacements precisely from variations in the difference between the phases of the heterodyne signals from the two photodetectors. In practice, the phase measurement is degraded by noise and by systematic effects caused by imperfections in the interferometer optics. The major systematic source of error in the phase measurement is polarization leakage; that is, impingement, on the U photodetector, of (1) a small portion of the s-polarized light that passes directly through the lower polarizing beam splitter without taking the round trip between the retroreflectors and (2) another small portion of the s-polarized light that takes two or more round trips.

This polarization-leakage phase error (ϵ) is what gives rise to the nonlinearity in the interferometer response. The present method of estimating ϵ is based partly on the fact the polarization leakage is small and that ϵ is much less than 1 radian (as it is in cases of practical interest). A mathematical analysis shows that ϵ is a periodic function of ideal single-round-trip phase (ψ), and that given the aforementioned as-




We're BIG on the little things.

No matter how complex your custom stamped components, you can count on us to provide you with exceptional quality and service from start to finish. We firmly believe that superior technology sets us apart... yet, we also know paying attention to the small details is just as important. From design to delivery, we're committed to you—and that makes cents for us both.

Meier
TOOL & ENGINEERING INC.

875 Lund Blvd., Anoka, MN 55303
763-427-6275 • Fax: 763-427-9242
www.meiertool.com



A Typical Heterodyne Optical Interferometer is subject to polarization leakage, which introduces a phase error and a corresponding nonlinearity into its response.

sumptions, it can be approximated by the following equation:

$$\varepsilon(\psi) = A\cos(\psi) + B\sin(\psi) + C\cos(2\psi) + D\sin(2\psi) + \dots,$$

where A , B , C , and D are parameters to be determined in a calibration procedure summarized in the next paragraph. In order to suppress the nonlinearity to the 10-pm level, the dominant parameter in this equation must be determined to one part in 100, while the other parameters may be determined to lesser accuracy, depending on their relative amplitudes.

One of the retroreflectors is mounted

on a piezoelectric transducer that can be driven by a suitable voltage to displace the retroreflector along the interferometer arm. The calibration procedure involves the use of a triangular waveform at a typical frequency of a few hertz to induce an oscillatory displacement that spans a useful number (typically ≈ 10) of phase cycles so that the periodic ε component of the uncorrected phase measurement becomes recognizable. The uncorrected phase measurements are sampled, filtered, and otherwise processed to extract A , B , C , and D . Then the instantaneous corrected

phase measurement (which should now be a closer approximation of the desired phase ψ) is given by

$$\psi_{\text{corrected}} = \psi_{\text{uncorrected}} - \varepsilon(\psi_{\text{uncorrected}}),$$
where $\varepsilon(\psi_{\text{uncorrected}})$ is calculated by substitution of the appropriate quantities in the above equation for $\varepsilon(\psi)$.

This work was done by Alex Abramovici and Randall Bartman of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Information Sciences category.
NPO-20906

An Efficient Algorithm for Propagation of Temporal-Constraint Networks


The computational cost is much less than in prior algorithms.

NASA's Jet Propulsion Laboratory, Pasadena, California

An efficient artificial-intelligence-type algorithm for the propagation of temporal constraints has been devised for incorporation into software that performs scheduling and planning of tasks in real

time. This algorithm checks for temporal consistency and computes time windows of time points within temporal-constraint networks, which are often used in scheduling and planning. A C++-language com-

puter program that implements the algorithm has been devised for incorporation into the control software of the Mission Data System of NASA's Jet Propulsion Laboratory. The algorithm and program



COMPUTER / RADAR / SONAR / VIDEO / FLIR / AUDIO

RECORD IT ALL!

CAPTURE every screen at up to 1280 X 1024 resolution.

RECORD multi inputs & different signal types simultaneously.

STORE inputs together on digital tape or disk.

PLAYBACK input signals individually or synchronously.

Plus . . . video and audio inputs to monitor who's there and what's said.

Designed for simulation, command-and-control, training, surveillance, and mission analysis, the DGx™ is a breakthrough in recording technology.

DGx
DIGITAL RECORDING SYSTEM

Call (510) 814-7000 for information
or visit our web site at www.rgb.com




SPECTRUM®
a visual communications company™

950 Marina Village Parkway Alameda CA
Tel: 510 814-7000 Fax: 510 814-7026
E-mail: sales@rgb.com

POSITIONING SLIDES AND X-Y TABLES

Modular linear and rotary stages for scanning and indexing



VELMEX, INC.

Call: 800 642-6446


or 585 657-6151 in NY state

For your free Catalog M

www.velmex.com
and www.bislide.com

For Free Info Circle No. 584 or
Enter No. 584 at www.nasatech.com/rs

Information Sciences



These Simple Temporal-Constraint Networks illustrate the basic principle of predecessor and successor time points joined by temporal constraints $[a,b]$ = [minimum interval, maximum interval].

could also be applied to industrial planning and scheduling problems.

For the purpose of this discussion, "time point" signifies the nominal or planned time of occurrence of a specified event in, or state of, the system (e.g., a spacecraft or a production line) that is the subject of the planning and scheduling

effort. A temporal-constraint network is equivalent to a graph, the nodes of which represent time points and the lines of which represent temporal constraints. The simplest such network (see figure) contains one predecessor and one successor time point that are required to be separated by a time interval of not less than a and not more than b . In forward propagation in this network, one would endeavor to update the time window of the successor point to be consistent with the time constraint and the time window of the predecessor point; similarly, in backward propagation in this network, one would endeavor

to update the time window of the predecessor point to be consistent with the time constraint and the time window of the successor point.

The present algorithm involves iterations of forward and backward propagation; each iteration consists of a forward sweep followed by a backward sweep. Each sweep starts the propagation of temporal constraints from a subset of time points. During the propagation, the algorithm updates the time window at each time point by use of all its incoming temporal constraints in a forward sweep or all of its outgoing temporal constraints in a backward sweep. A data structure denoted a propagation queue is used to store time points, the successors or predecessors of which are to be updated next in a forward or backward sweep, respectively. Once the time window of a time point has been updated and all its incoming (or outgoing) temporal constraints have been used, that time point is placed in the propagation queue.

A forward sweep starts from a set of time points that have no predecessors. These time points are put in the propagation queue, then the sweep proceeds until the queue is empty. The backward sweep starts from a set of time points that have no successors, and then proceeds similarly to the forward sweep. It is assumed that there are no cycles (time-constraint paths that begin and end at the same time point) so that the algorithm will not enter an infinite loop during a sweep. The algorithm performs as many iterations as are needed until either (1) there is no window left to be updated or (2) a window of negative length is created. In case (1), the

Don't Panic... Toro is your amigo!


Grab difficult data acquisition applications by the horns with Toro, our powerful new 64-bit PCI, TMS320C6711 DSP board with 16 A/Ds & 16 D/As.

Applications

- ▶ High Channel Count Servo Controller
- ▶ Vibro-Acoustic Monitoring & Control
- ▶ Sonar
- ▶ Noise Cancellation
- ▶ Beam Forming

Features

- ▶ Ultra-Flexible Triggering Modes
- ▶ Blazingly Fast 64-bit PCI Bus
- ▶ 150 MHz TMS320C6711 DSP (floating point) with 32MB onboard RAM
- ▶ 16 Independent Noise-Free 16-bit, 200 kHz Analog Input & Output Channels
- ▶ Multiboard Synchronization
- ▶ 64 Bits Digital I/O



Innovative Integration
... real time solutions!

805.520.3300 phone • www.innovative-dsp.com

final windows of all time points are considered to have been computed and the network is considered temporally consistent. In case (2), the algorithm returns the message to the effect that the network is temporally inconsistent.

The great advantage of this algorithm, relative to a prior temporal-constraint-propagation algorithm, is its computa-

tional efficiency and thus computational speed, and storage saving. The prior algorithm requires $O(N^3)$ number of arithmetic operations and $O(N^2)$ amount of memory [where $O(x)$ signifies proportionality to a quantity of the order of x and N is the number of time points in a temporal-constraint network]. In contrast, the present algorithm requires only $O(N)$

number of arithmetic operations and $O(N)$ amount of memory.

This work was done by John Z. Lou of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Information Sciences category. NPO-21098

2 Software for Continuous Replanning During Execution

Feedback from execution of a plan is used to update the plan continuously.

NASA's Jet Propulsion Laboratory, Pasadena, California

Continuous Activity Scheduling Planning Execution and Replanning (CASPER) is a computer program for automated planning of interdependent activities within a system subject to requirements, constraints, and limitations on resources. Now at the prototype stage of development, CASPER was conceived to enable a robotic exploratory spacecraft to perform on-board, autonomous planning and replanning of scientific observations and other functions in response to diverse

unanticipated phenomena that could include unknown or changing environmental conditions, equipment failures, and errors in mathematical models used in planning. On Earth, CASPER could be adapted to use in scheduling operations of production lines and other complex systems.

CASPER implements a concept of continuous planning integrated with execution, in contradistinction to the traditional concept of batch planning followed by execution. In traditional

batch planning, time in the planned system is divided up into a number of relatively long planning horizons. When one nears the end of the current horizon, one projects what the state of the system will be at the end of execution of the current plan. The planning algorithm is then invoked with (1) a new set of goals for the next time horizon and (2) the projected end-of-execution state as the initial state for the next horizon. In this batch approach, planning is usually considered an off-



Plug-and-Play Spectrometer

USB2000 Miniature Spectrometer Delivers Hassle-Free Instrument-to-PC Interfacing

Effortless Interface. Plugs directly into the USB port of desktop or notebook PCs, or the serial port of handheld PCs.

Simple Start-Up. Software recognizes the spectrometer and automatically enters wavelength calibration coefficients.

Modular Design. Choose from 2 detectors, 14 gratings, 6 slits and hundreds of accessories to optimize your system.

Portable Use. Options such as a battery pack and 470 nm LED (attached to the USB2000 in larger photo) make your spectrometer field-portable.

Starting at Just \$2,199!

Call Today!
727.733.2447

In Europe:
+31 (0) 26 319 05 00



Info@OceanOptics.com

For all your photonics needs, visit

OceanOptics.com

do you need more... speed

NE/Nastran V8.1 adds one of the **fastest iterative solvers** available today for linear and nonlinear solutions. The PCGLSS solver is 10-20 times faster than typical sparse direct solvers. It requires considerably less memory and can handle models with over **2 million** degrees of freedom using any combination of element types.



PLUS:

- True surface to surface contact
- A new NE/Nastran editor
- A new job queuing system allows the user to run multiple jobs in series or parallel
- A new line search algorithm reduces nonlinear analysis time up to 25%

do you need more... support




Already using **Hypermesh®** or **Patran®**? NE/Nastran can now power your results with speed and accuracy.

New **.OP2**
interface



Now go DIRECT from
Pro/E® to NE/Nastran
using the new .OP2
interface.



FEMAP® users get a true 3D surface-to-surface contact and non-linear cable element interface.

then you need... NE/Nastran v8.1 for Windows

Noran Engineering, Inc. announces the release of NE/Nastran V8.1, the latest upgrade of it's powerful, affordable, and easy-to-use finite element analysis (FEA) tool for engineers in practically all disciplines.



Noran Engineering, Inc.


www.NENastran.com

Toll-Free: 1.877.NENastran


Phone: 562.799.9911

2001 NE, Noran Engineering, Inc. NENE/ and NEI logo are Registered Trademarks of Noran Engineering, Inc. NASTRAN is a registered trademark of the National Aeronautics and Space Administration. Windows is a registered trademark of the Microsoft Corporation. All other trademarks and registered trademarks are the property of their respective owners.

For Free Info Circle No. 565 or
Enter No. 565 at www.nasatech.com/rs



Traditional Batch "Plan Then Execute" Cycle



Continuous Planning (Incremental Extension of Current Plan)

Batch-Planning and Continuous-Planning Algorithms differ in their ability to respond to unforeseen circumstances. In continuous planning, the plan is updated at relatively small increments of time to keep the plan as up to date as possible.

line process that entails considerable computation, and there is significant delay from the instant when the planning algorithm is invoked to the instant when the algorithm issues a new plan. In the event of a disruption (caused, for example, by an equipment failure or an inaccurate projection of the initial state) it could be necessary to stop execution of the current plan and put the system in a safe reduced operational mode for a considerable amount of time until a new batch plan is generated. On the other hand, if a fortuitous event occurs (e.g., a planned activity is completed ahead of schedule), it may not be possible to take advantage of the opportunity thus created because it would take too long to respond with a new batch plan.

In traditional batch planning (see figure), a planning algorithm is presented with goals and an initial state. In CASPER, the planning algorithm is presented with a current set of goals, a current plan, a current state, and a model of the expected future state. At any time, the planning algorithm can be called upon to update the goals, current state, or planning horizon (at increments of time much smaller than those of batch planning) in response to an unexpected event or simply in response to the passage of time. The replanning cycle comprises the following steps:

1. Changes to the goals and the initial state are posted to the plan.
2. The effects of the changes are propagated through the current plan projections, and resulting conflicts (if any) are identified.
3. Iterative plan-repair subalgorithms are invoked to eliminate conflicts and make the plan appropriate for the current state and goals. It is these subalgorithms that make it possible to update the plan incrementally (nearly continuously) during execution in response to changing conditions and unforeseen events.

This work was done by Russell Knight, Steve Chien, Robert Sherwood, Gregg Rabideau, Darren Mutz, Tara Estlin, Forest Fisher, and Barbara Engelhardt of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Information Sciences category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-20972.

W
W
W
•
N
E
N
a
s
t
r
a
n
•
c
o
m
1
•
8
7
7
•
N
E
N
a
s
t
r
a
n

Motion CONTROL Tech Briefs

Surface-Launched Explorers for Reconnaissance/Scouting

Efficiency of robotic exploration would be increased.

NASA's Jet Propulsion Laboratory, Pasadena, California

Small, instrumented, expendable robotic aircraft and projectiles have been proposed for use in scouting for targeted new sites by providing closeup images with ~10-cm resolution, covering large distances ~1 to 10 km quickly and allowing reconnaissance to enable sample return. Denoted microflyers or surface-launched explorers (SLEs), the proposed robotic aircraft and projectiles were conceived especially for use in the exploration of Mars and possibly other distant planets. SLEs could also be adapted to such terrestrial uses as military reconnaissance, exploration of hostile terrain (e.g., volca-

noes, steep cliffs, or glaciers), surveying hazardous-waste sites, and searching for victims of earthquakes.


This class of SLEs enables biomorphic missions — hybrid missions which utilize surface assets and aerial assets synergistically to achieve new scientific endeavors along with deploying biomorphic explorers. Biomorphic explorers and related concepts have been described in several previous articles in *NASA Tech Briefs*, the most relevant being "Biomorphic Explorers" (NPO-20142), Vol. 22, No. 9, (September 1998), page 71; "Earthwormlike Exploratory Robots" (NPO-20266), Vol. 22, No. 6, (June

1998), page 11b; "Insectile and Vermiform Exploratory Robots" (NPO-20381), Vol. 23, No. 11, (November 1999), page 61; "Biomorphic Gliders" (NPO-20677), Vol. 25, No. 4 (April, 2001); and "Seed-Wing Flyers for Exploration" (NPO-20676), Vol. 26, No. 1, (January, 2002), page 47.

SLEs could include guided projectiles, gliders, electrically powered airplanes and helicopters, and possibly other robotic flyers; specific types, designs, and combinations of SLEs would be tailored to specific applications. In a typical application, the SLEs would be launched from a lander/base station/mobile explorer

Biomorphic Mission: Surface-Launched Microflyers

Microflyers launch off the lander and fly preset flight plans based on the Sun position to the targeted site. At the site they obtain close-up imagery, and/or deploy surface instruments/explorers/ experiments to validate for Mars Sample Return. Surface-launched microflyers work in synergy with the surface/subsurface systems to enable new science endeavors. Lander provides a robust communication route for imagery down-link from the microglider.



Small Robotic Aircraft would transmit images of terrain and possibly sensory data to an exploratory robotic vehicle (lander).

(see figure) or from a spacecraft, aircraft, or other vehicle that delivered the lander to the exploration site. The means of launching could be as diverse as the SLEs themselves: they could include rockets, balloons, pneumatic devices, or spring mechanisms, for example.

An SLE could carry a small video camera, sensors, and a radio transmitter to send images of the terrain to the lander. The images could help in quickly identifying sites of scientific interest to be explored in more detail and allow identifying hazards and slopes and access the area for its potential for sample return.


The images could also be helpful in planning the path of other surface/ sub-surface explorers across the terrain.

An SLE could be designed to safely land after following a ballistic trajectory in the low gravity of Mars. After landing, the SLE could continue to function as a scientific instrument: For example, it could analyze surface and/or subsurface soil and use its remaining energy to transmit the analytical data to the lander/mobile explorer. One or more SLEs designed to survive impact would resemble javelins and would be launched in such a way that, like javelins, they would

embed themselves in the ground at the far ends of their trajectories; these SLEs would serve as radio beacons to aid navigation by the other SLEs as secondary communication ports in addition to the primary port on the lander. The lander serves as the local relay to send the data back to Earth via the orbit.

This work was done by Sarita Thakoor and Terry Martin of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Machinery category. NPO-20871

TRANTEKDRIVESYSTEMS.COM



GO FASTER. GO FURTHER. GO HEAVIER.

The new DriTran® Screw Drive System gives engineers the freedom to design machinery without the critical speed and length concerns associated with conventional screw drive systems.

Imagine being able to move a 10,000 lb. load 30 feet in 10 seconds with a 2.75" diameter screw delivering 6" of travel per revolution. This new system handles dynamic loads up to 30,000 lbs. and standoffs allow joining multiple sections up to 40 feet.

Cast epoxy-threads inside the nut make it all happen. The best part—the low friction, extended wear nut is easy to service, and it can be changed out in minutes instead of days.

To find out more,

**Call us today at 231-946-6270 or
visit www.trantekdrivesystems.com**

TRANTEK
DRIVE SYSTEMS INCORPORATED

2470 N. AERO PARK COURT TRAVERSE CITY, MICHIGAN 49686

Firmware for a Small Motion- Control Processor

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

A C-language computer program implemented as firmware controls the operations of a microprocessor on a 3-by-1-inch (approximately 76-by-25-mm) motion-control circuit board denoted a widget board. The firmware implements a serial communication interface according to the inter integrated circuit bus (I²C) standard by use of an interrupt-driven state machine to enable communication to occur during execution of commands. The firmware also controls the operation of a motion-control integrated-circuit chip, a serial analog-to-digital converter, a serial digital-to-analog converter, and the digital input/output lines of the microprocessor. The digital input/output control portion of the firmware offers a masking capability. The firmware includes a provision for dynamically downloading, to the widget board, of a small program (limited to 12 lines and to 256 bytes). A microexecutive program executes the downloaded program in a loop, with the option of continuous looping. The execution of the downloaded subprogram can be interrupted at the user's request. The widget firmware includes a set of more than 48 commands, 24 control operations, and 24 query operations.

This program was written by Issa Nesnas of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category. NPO-30243

The Company with Vision Is in Motion



Integrate your machine vision with motion and measurements

Increase production cycles and lower test costs using an integrated National Instruments platform with vision, motion control, and measurement solutions. Perform precision alignment, automated inspection, precision assembly, and more.

Easy integration

Integration is easier with a high-speed, synchronized bus; platform choices that include PCI, PXI™/CompactPCI, and IEEE 1394; and development tools such as LabVIEW™, Measurement Studio™, and TestStand™.

ni.com/info

For more information on leading manufacturers who increased production cycles, visit ni.com/info and enter nakr08



(800) 811-0742

Fax: (512) 683-9300 • info@ni.com

For Free Info Circle No. 653 or Enter No. 653 at www.nasatech.com/rs

Gear Bearings and Gear-Bearing Transmissions

Planetary transmissions could be simpler, cheaper, and more rigid.

Goddard Space Flight Center, Greenbelt, Maryland

Gear bearings are conceptual mechanical components so named because they function as gears and as roller and/or thrust bearings. Gear bearings will be essential components of the next generation of compact, large-mechanical-advantage gear drives.

Figure 1 shows a working gear-bearing transmission with 70/1 gain in a 1.25-in.-


diameter-by-0.75-in. (3.18-cm-diameter-by-1.91-cm) package. Gear bearings exist as spur- or helical-gear variants of two basic types: roller gear bearings and phase-shifted gear bearings. For the sake of brevity, only spur-gear variants are described here; suffice it to say that the principles of operation of the helical-gear variants are similar.

Figure 2(a) depicts selected aspects of roller spur-gear bearings and a partial planetary assembly containing roller spur-gear bearings. The diameter of the roller portion of each roller spur-gear bearing equals the pitch diameter of the spur-gear portion. The gear teeth are crowned at the roller end, such that the apogee of the crown on each tooth lies at the roller diameter/pitch diameter. This arrangement provides thrust-bearing strength as well as matching of speeds and, hence, efficiency.


The planetary assembly would inherently hold itself together, without bracing by other structures. For example, if a planetary roller gear bearing shown in the cross-sectional view were pushed down-

Motion Control Solutions

from here



to there



At SEPAC, our problem-solving capabilities are out of this world and leagues under the sea.

With world-class production and engineering standards, SEPAC has worked with the aerospace industry and the military to design and produce reliable and long lasting motion control products.

We're sure we can supply the right clutch or brake for your application – either standard model or special design. Just fax or e-mail us your requirements. We will work with you to provide the best solution possible.

Whether you want to stay afloat, fly away or just control unwanted movement, SEPAC is your answer.



2000 Lake Road, Elmira, NY 14903-1822
800-331-3207, www.sepac.com



Figure 1. A Working Gear-Bearing Transmission shown here has a 70/1 speed reduction in a 1.25-in.-diameter-by-0.75-in. (3.18-cm-diameter-by-1.91-cm) package.

ward, the axial sliding of its teeth with respect to the ring- and sun-gear teeth is stopped by the abutment of the planetary roller against the crowns of the ring-gear teeth. When the same planetary gear is pushed upward, its axial sliding is blocked by abutment of the planetary teeth against the ring roller. Similar interactions prevent axial sliding of the sun roller gear bearing beyond the limits imposed by tooth/roller contacts between the sun and planetary roller gear bearings.

An additional advantage is that by enforcing the desired relative locations of gears more precisely, the incorporation of the rollers increases (relative to simple spur gears) the accuracy of meshing of spur-gear teeth. At the same time, the gears act as highly efficient and precise cages and carriers for the rollers. The net result is a superior, simpler, and relatively inexpensive assembly.

Figure 2(b) presents a simple example of a phase-shifted spur-gear bearing. The



NEW, Harmonic Planetary® High Precision Planetary Gearhead

Exclusively from HD Systems, the Harmonic Planetary® HPG Series provides the motion control and design engineer with a planetary gearhead that reduces backlash to less than 1 arc-min. This level of backlash is maintained for the life of the gear.


This design is made possible by developing a ring gear that can flex in the radial direction, while maintaining high torsional stiffness. The result is a planetary gearhead that provides consistently low backlash, high efficiency, and high output speeds.

This planetary gearhead is available in 3 frame sizes from 60mm to 120mm. Rated torque ranges from 53 in-lb to 956 in-lb. Peak torque ranges from 496 in-lb to 5753 in-lb. Gear Ratios 5:1 to 45:1. Flange or shaft output available.

HD Systems, Inc.

(800)231-HDSI (631)231-6630

For Free Info Circle No. 649 or
Enter No. 649 at www.nasatech.com/rs



NEW, Hollow Shaft Actuators

The FHA Series of actuators features a through-bore up to 45mm in diameter and provides high torque and exceptional positioning accuracy. This performance is achieved in a compact design using a patented "S" tooth harmonic drive gear coupled to a DC brushless pancake motor with integral electronic commutation and a high resolution encoder. Rated torque up to 1730 in-lb and positional accuracy better than 1 arc-minute can be achieved. The FHA Series is available in five frame sizes, ranging from 128 to 300mm in diameter, and 116 to 248mm in length.

HD Systems, Inc.

(800)231-HDSI (631)231-6630

For Free Info Circle No. 648 or
Enter No. 648 at www.nasatech.com/rs


NEW, Harmonic Drive Gearhead, Zero Backlash

The CSF-2UH series high torque gearheads use HD Systems' patented "S" tooth that delivers more than twice the torque, twice the life, and twice the torsional stiffness when compared to conventional Harmonic Drive Gearing. Positional Accuracy is better than 1 arc-min. The CSF-2UH series is available in 10 frame sizes with rated torque ranging from 48 in-lb to 8400 in-lb and peak torque ranging from 310 in-lb to 42,000 in-lb. Gear Ratios 50:1 to 160:1.

The CSF series uses a rigid cross roller bearing to support its output flange. This combination allows the gearhead to be extremely compact while providing high axial, radial, and moment load capacities. Easily interfaced with a servo motor, these zero backlash, high accuracy gear systems are ideal for indexing tables, robots, and factory automation equipment. Flange or shaft output available.

HD Systems, Inc. (800)231-HDSI (631)231-6630

For Free Info Circle No. 650 or Enter No. 650 at www.nasatech.com/rs



ULTRA FLAT HARMONIC DRIVE GEARING

- Zero Backlash
- 1 Arc-Min Accuracy
- Gear Ratios to 160:1

New CSD Series



Call for Technical Brochure
800.231.HDSI
631.231.6630
or visit www.HDSI.net



Conventional
Harmonic Drive Gearing



New CSD Series
Ultra Flat Design

World Leader in Ultra-Precision Motion

89 Cabot Court. Hauppauge, NY 11788 T: 631.231.6630 F: 631.231.6803 800.231.HDSI www.HDSI.net

For Free Info Circle No. 647 or Enter No. 647 at www.nasatech.com/rs

NO EARS TO INTERFERE™ SPIRAL RETAINING RINGS

COMPATIBLE WITH STANDARD SNAP RING GROOVES

- Uniform cross section does not interfere with assembly
- Allows for tight radial applications
- Easy to assemble and remove

STAINLESS STEEL OFF THE SHELF

- Over 5,000 stock sizes in carbon and stainless steel (1/2" to 16")
- Special designs available from 9/32" to 84"
- No-Tooling-Charges™


CALL FOR:

- ✓ FREE SAMPLES
- ✓ FREE CATALOG




555 Oakwood Road • Lake Zurich, IL 60047
(847) 719-5900 • Fax: (847) 719-5999
www.smalley.com • info@smalley.com

For Free Info Circle No. 656 or
Enter No. 656 at www.nasatech.com/rs



ROTARY UNION
Uniform cross section of the spiral retaining ring allows the ring to be installed without interfering with the mating component.



A HYDRAULIC SHOCK ABSORBER THAT WON'T LEAK



It's true!
Cushioneer® industrial shock absorbers operate millions of cycles without leaking even one drop of fluid. They have a patented leakproof diaphragm seal and combine high capacity with miniature size. Infinitely adjustable, the Cushioneer® stops gently-moving 5 lb. loads or crashing 500 lb. loads with equal smoothness. A companion unit, the leakproof adjustable Kinechek®, holds speed of moving devices constant month after month, without periodic re-setting. Contact us today.

DESCHNER CORPORATION
www.deschner.com
3211 W. Harvard Street, Santa Ana, CA 92704
(800) 457-6666 e-mail: deschnorp@aol.com



For Free Info Circle No. 657 or
Enter No. 657 at www.nasatech.com/rs

Motion Control Tech Briefs

teeth in the upper and lower halves are shifted angularly, relative to each other, by precisely a half-tooth interval. This gear bearing meshes with a copy of itself. The upper and lower teeth are beveled and partly interdigitated where they meet. The contact between the beveled surfaces of the upper and lower teeth provide a thrust-bearing capability in a manner similar to that of the contact between the crowns and rollers of the roller gear bearings. Moreover, a planetary assembly containing phase-shifted gears holds itself together in a manner similar to that of an assembly containing roller gear bearings as described above.

This work was done by John M. Vranish of **Goddard Space Flight Center**. For further information, access the *Technical Support Package (TSP)* free on-line at www.nasatech.com/tsp under the *Mechanics* category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Goddard Space Flight Center; (301) 286-7351. Refer to GSC-14207.




Figure 2. Gear-Bearing Configurations: (a) roller spur-gear bearings would offer advantages, relative to simple spur gears and bearings, for the operation of planetary gear assemblies. (b) A phase-shifted gear bearing could mesh with an identical twin and would offer advantages similar to that of the roller spur-gear bearing depicted in (a).

Linear Dynamometer With Variable Stroke and Frequency

Stroke length and frequency can be adjusted continuously during operation.

John H. Glenn Research Center, Cleveland, Ohio

An improved linear dynamometer has been developed for testing linear alternators that are to be used to convert mechanical power to electrical power in free-piston Stirling-cycle engines. Both the frequency and the length of the stroke of this dynamometer can be varied continuously, even during operation; consequently, the dynamometer can be used to fully map the capabilities of a linear alternator throughout its service envelope (its operational range as defined on a plot of limiting stroke length versus frequency) in a single test.

The dynamometer includes a balanced twin-throw eccentric crank mechanism that converts the rotary motion of a drive motor to the desired linear motion of a plunger that consti-

tutes the moving part of the linear alternator under test. To eliminate vibration on the alternator stator, the crank mechanism also imparts an equal and opposite linear motion to a balance mass that is equal to the mass of the plunger. The position of the drive-motor-and-crank assembly along a line perpendicular to the linear-stroke axis can be adjusted hydraulically to vary the eccentricity of the crank and thereby vary the length of the stroke. A compensating mechanism maintains the center of the plunger stroke with the center position of the stator. The frequency of the stroke is controlled simply by controlling the speed of the drive motor.

The dynamometer comprises four main interconnected modules: the crankcase with drive mechanism (see figure), the power pack, the operator console, and the load bank. The crankcase is an assembly of steel plates formed into a closed box enclosing the drive mechanism described above. A scavenging pump maintains a negative gauge pressure in the crankcase to minimize leakage of oil at the joints. The power pack contains a 125-horsepower (93-kW) motor that drives a compound pump that provides (1) pressurized oil for controlling the stroke and driving the hydraulic motor and (2) pressurized oil from a separate supply for lubrication.


A magnetostrictive sensor measures the displacement of the plunger. An encoder on the shaft of the hydraulic motor

measures the speed. A programmable logic controller compares the displacement and speed readings with set-point values of speed and stroke commanded via the operator console and actuates solenoid-operated servovalves to adjust the flows of oil accordingly.

The power generated by the linear alternator is dissipated in the load bank, which is a commercially available unit that presents a purely resistive load of 3 ohms and up, with selectable resistance to absorb up to 30 kW at up to 300 V. The load resistors in the load module are cooled by a fan. The load module is equipped with meters that read potential, current, frequency, and power, and with fault indicators and lockouts for fan failure, overtemperature, and overvoltage. The potential and current readings from the load bank are displayed on the operator console along with the frequency, the stroke length, the stroke-control position, and the reaction force of the stator in the alternator under test.

This work was done by George Yarr of Clever Fellows Innovation Consortium, Inc., for Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Machinery category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16951.



The Length of the Stroke of This Dynamometer is adjusted by adjusting the vertical position (and thus the eccentricity) of the balanced twin-throw eccentric crank mechanism.

ADVERTISEMENTS

Precision Linear Motion Assembly




PRECISION LINEAR MOTION

"Rolling ring" linear actuator with integrated linear scale. Resolution up to 0.0004 inches (0.01 mm). Offset quadrature output signal to the controller derives both linear position and rotational direction (travel direction).

Assembly built to customer specifications; arrives ready to install in production machinery and connect to drive motor. Virtually zero backlash. Amacoil, Inc.; Tel: (800) 252-2645; Fax: (610) 485-2357; e-mail: amacoil@amacoil.com; <http://www.amacoil.com>.

Amacoil, Inc.

For Free Info Circle No. 690 or Enter No. 690 at www.nasatech.com/rs



MICRO-DRIVES

Is an international group of micromotor and gearbox manufacturers dedicated to providing quality products and services with timely delivery at a reasonable price.

For over 40 years we have supplied OEMs with fractional horsepower motors and gearmotors for pumps, ventilation equipment, security and access control, printing machinery, motorized window treatments and gaming equipment, medical equipment and instruments and almost any other miniature actuator applications you can imagine.

- Product sizes 12 to 80 mm
- Power ratings .5 to 25 watts
- Torque range up to 347.2 oz-in
- Visit our website for pricing

www.micro-drives.com



COMPANY PROFILE

Micro Mo Electronics is an OEM supplier of fractional horsepower DC motors, precision gearheads, tachometers, encoders, brakes, and complete servo systems. Gearmotors from 1.9 mm in diameter. Power outputs to 1,000 watts. Over 1,000 matching gearhead types are available in ratios up to 1,000,000:1. Custom motion systems and special modifications. ISO 9001 certified. Micro Mo Electronics, Inc., 14881 Evergreen Ave., Clearwater, FL 33762-3008; Phone (800) 807-9166 (US or Canada) or (727) 572-0131; fax (727) 573-5918; web site: <http://www.micromo.com>; e-mail: info@micromo.com.

Micro Mo Electronics

For Free Info Circle No. 651 or Visit www.nasatech.com/651



MVP®2001 MOTION CONTROL SYSTEMS

The MVP® provides motion, velocity, position, and torque control with an integrated PWM or linear amplifier in one 2" X 4" X 3.7" extruded metal case. It provides DeviceNet™ compliant, RS-232, or RS-485 multidrop control of brush and/or brushless DC motors. Up to 64 axes can be networked. Under US\$600 in single piece quantities. Micro Mo Electronics, Inc., 14881 Evergreen Ave., Clearwater, FL 33762-3008; Phone: (800) 807-9166 (US or Canada) or (727) 572-0131; fax: (727) 573-5918; web site: <http://www.micromo.com>; e-mail: info@micromo.com.

Micro Mo Electronics

For Free Info Circle No. 652 or Visit www.nasatech.com/652

Why use a "Machined" Spring?



Because it's elasticity at its best!

The versatile HELI-CAL® Flexure, utilized as a spring, provides desired elastic performance in compression, extension, torsion, lateral bending and lateral displacement modes. Ideal for integrating multiple features and functions into a single component.

Visit our website, call or write for more info!




901 W. McCoy Lane • P.O. Box 1069 • Santa Maria, CA 93456-1069
Phone (805) 928-3851 • FAX (805) 928-2369 • www.Heli-Cal.com

For Free Info Circle No. 659 or
Enter No. 659 at www.nasatech.com/rs

Join the Digital Revolution

Download a FREE sample of
NASA Tech Briefs' NEW electronic
edition at www.qmags.com/ntb

- Search and archive PDF issues
- Link seamlessly from articles/ads to Web resources
- Get earlier delivery, and special technology supplements



Start or renew
your subscription at:
www.nasatech.com/subscribe

NEW PRODUCTS



Tachometers and Encoders


Phoenix America, Fort Wayne, IN, has introduced a line of tachometers and encoders for determining average or instantaneous speed and direction in industrial applications. The units also can be used as incremental encoders for determining rotational position.

The tachometer/encoders feature permanent magnet target wheels with mounting options such as press fit hubs and set-screw hubs. They also include two solid-state digital output switches mounted in quadrature. The two output channels can be used to determine speed and direction.

For Free Info Circle No. 740 or Enter No. 740 at www.nasatech.com/rs

Ball Bearing Slide

The Model 2907 ball bearing slide from Accuride International, Santa Fe Springs, CA, measures 0.38" wide and can be mounted in 1U to 4U racks. It carries loads up to 100 pounds, and full extension plus two inches of over-travel allow ensure access to the front, back, and sides of the chassis. A lever disconnect provides chassis removal and reinsertion. The slide is available in even lengths from 12" to 30". A bracket kit adapts to a range of EIA rail configurations including square, tapped, and through holes.




For Free Info Circle No. 741 or Enter No. 741 at www.nasatech.com/rs



Motor Drives

Anacon Systems, Mountain View, CA, offers the EagleDrive™ Series of variable frequency drives (VFDs) that connect to world-wide electrical supplies for variable speed control of single-phase AC induction motors (EagleDrive1™ Series) and three-phase AC induction motors (EagleDrive3™ Series). All models feature a pushbutton keypad, variable or constant torque, selectable inverter switching frequencies, three digital and one analog programmable inputs, and galvanically isolated control terminal inputs. EagleDrive1 has a speed range of 0-100 Hz; EagleDrive3 has a speed range of 0 to 30,000 RPM.

For Free Info Circle No. 742 or Enter No. 742 at www.nasatech.com/rs




Parallel Shaft Gearmotor

The M4000 GIL200 Series permanent magnet DC parallel shaft gearmotor from RAE Corp., McHenry, IL, is rated to 300 in./lbs with speeds up to 350 RPM and voltages ranging from 12 to 180 VDC. The units feature TENV design, reversible design, double shield ball bearing construction, class F insulation, hardened steel gears, and an oil-filled gearbox. Applications include conveyor drives, packaging equipment, robotics, and material handling.

For Free Info Circle No. 743 or Enter No. 743 at www.nasatech.com/rs

Direct Drive Linear Actuators

IntelliDrives, Philadelphia, PA, has introduced the BB series of linear motors that eliminate friction, backlash, and wear problems of lead screws, racks, and pinions. The two-piece system consists of a passive, magnet-free, stationary platen that serves as a linear guideway, and a movingforcer with built-in roller bearings. All bearings are magnetically preloaded. Forces range from 5 to 15 pounds, and travel length ranges to 80". The forcers are capable of velocities of 60 in./sec and can be supplied with the company's I-Drives microstepping indexers and drivers.



For Free Info Circle No. 744 or Enter No. 744 at www.nasatech.com/rs

New on the MARKET

Thermometer/Transmitter

The OS1592 infrared fiber optic thermometer/transmitter from OMEGA Engineering, Stamford, CT, measures temperature ranges to 4500°F and provides dual analog outputs electrically isolated from the DC power supply input. The main electronics are in a NEMA-4 rated aluminum housing with a local backlit LCD, built-in relay, and a four-position programmable keypad. The system has accuracy of 1% of reading and 25 msec response time. **For Free Info Circle No. 711 or Enter No. 711 at www.nasatech.com/rs**




Rugged Portable PC

The DEWE-4000-IPC Industrial Portable Computer from Dewetron, Charlestown, RI, features an ATX motherboard, allowing up to eight full-size, full-length PCI cards to be added to the system. The standard display is 18.1" TFT, is available with a touch screen, and runs at resolutions up to 1280 x 1024. The video interface is an AGP card with up to 128 MB of VRAM for moving video. **For Free Info Circle No. 716 or Enter No. 716 at www.nasatech.com/rs**

Mold Design Software

Manusoft Corp., Waconia, MN, has introduced IMOLD for SolidWorks that enables design of plastic injection molds. It performs core/cavity separation, mold layout, gating and slide/lifter design, and runner, cooling, and ejection system design. It provides an Intelligent Fastener System feature that fastens all the mold plates, inserts, and components together, and generates assembly drawings. Using the SolidWorks environment, the software creates 3D, solids-based mold bases. **For Free Info Circle No. 712 or Enter No. 712 at www.nasatech.com/rs**



FEA Software

Noran Engineering, Los Alamitos, CA, has added a nonlinear, tension-only shell element to its NE/Nastran V8.1 solver. The element acts as a normal shell in tension and reduces to a shear panel in compression. The interface works with existing models using standard quadrilateral and triangular plate elements and properties. **For Free Info Circle No. 714 or Enter No. 714 at www.nasatech.com/rs**



Measurement and Control

National Instruments, Austin, TX, has released LabVIEW 6.1 graphical development software for test, monitoring, and control applications. Users can control their measurement and automation applications from any location using LabVIEW 6.1 via a standard Web browser. Users can import and export XML-formatted data to integrate virtual instruments with other Web or database applications in their enterprise. **For Free Info Circle No. 713 or Enter No. 713 at www.nasatech.com/rs**



ASME International

In Business Problems? In-Company Solutions

Identify your training needs and save time, while cutting costs with ASME In-Company Programs!

- ASME has the engineering courses and industry experts that enable your company to stay ahead in today's competitive marketplace.
- We will work closely with you to ensure that objectives are met and examples are incorporated specific to your company's needs.

Call or e-mail to find out more information about ASME In-Company Programs today!

ASME International

Tel: 212-591-7752

Web: www.asme.org/pro_dev


Email: rubine@asme.org

**For Free Info Circle No. 580 or
Enter No. 580 at www.nasatech.com/rs**

ELECTRICALLY CONDUCTIVE ADHESIVE HAS HIGH FLEXIBILITY

MASTER BOND POLYMER SYSTEM EP21TDCSFL

- Excellent electrical conductivity - high purity silver filled compound
- Cures readily at room or elevated temperatures
- Non-critical mix ratio
- Easy application
- Superior physical strength properties
- Wide service temperature range
- Outstanding adhesion to a diverse range of substrates
- Dimensional stability
- Remarkable environmental resistance
- Convenient packaging



Master Bond Inc.
Adhesives, Sealants & Coatings


154 Hobart St., Hackensack, NJ 07601
TEL: 201-343-8983 ■ FAX: 201-343-2132

main@masterbond.com ■ www.MasterBond.com

**For Free Info Circle No. 581 or
Enter No. 581 at www.nasatech.com/rs**

QuickField™

FEA software for Electromagnetic,
Electrostatic, Stress and Thermal field simulations
in Windows® environment



- Automatic mesh generator. •DXF import/export •Multi-field coupling. •Comprehensive post-processor: fluxes, forces, stresses, torques, inductances, capacitances.
- No limitation on model size or number of elements.

Get your free Student's version at
www.quickfield.com



Tera Analysis Ltd.

USA: toll-free Tel / Fax (877) 215 8688
Europe: Tel +(45) 6354 0080 Fax +(45) 6254 2331
[http:// www.tera-analysis.com](http://www.tera-analysis.com)

For Free Info Circle No. 582 or
Enter No. 582 at www.nasatech.com/rs

New LITERATURE



Measurement Reference

Endevco Corp., San Juan Capistrano, CA, has published a measurement handbook for dynamic force, pressure, and acceleration. The handbook covers measurement topics such as conceptual and dynamic models for transducers, the properties of silicon and piezoelectrics, the characteristics of time-varying signals, measurement system design, calibration, and data interpretation. **For Free Info Circle No. 705 or Enter No. 705 at www.nasatech.com/rs**



Data Converters

Signal Processing Technologies, Colorado Springs, CO, has updated its product selection guide to include analog-to-digital converters, digital-to-analog converters, video line drivers, track-and-hold amplifiers, and comparators. Product charts can be referenced to specifications including resolution, sample rate, power dissipation, linearity, and package information for each product. **For Free Info Circle No. 706 or Enter No. 706 at www.nasatech.com/rs**

Electronic Enclosures

A 67-page catalog from Bud Industries, Willoughby, OH, highlights electronic enclosures, including accessories, brackets, cabinets, card racks, chassis, communication products, die-cast aluminum boxes, large cabinet racks, open racks, plastic boxes, and small metal enclosures. The catalog helps users select the proper enclosure, accessories, and components needed to package their product. **For Free Info Circle No. 707 or Enter No. 707 at www.nasatech.com/rs**



Magnet Design

A handbook from Magnet Applications, Horsham, PA, offers information on magnet design including shaping/forming processes such as injection molding and compression bonding, the use of Finite Element Analysis (FEA) modeling as an aid in design, and magnet material characteristics and their impact on manufacturing applications. **For Free Info Circle No. 708 or Enter No. 708 at www.nasatech.com/rs**

Fastening Inserts

Yardley Products Corp., Yardley, PA, has released a 21-page catalog detailing Molded-In, Pressed-In, Sharp-Sert®, Trisert®, Intro-Sert®, Fiber-Sert®, Quick-Sert®, and Bi-Sert® inserts. The catalog features product specifications including applications, base materials, metric thread size, length, and tolerance. **For Free Info Circle No. 709 or Enter No. 709 at www.nasatech.com/rs**



Ball Bearing Slides

Accuride International, Santa Fe Springs, CA, has released a brochure of solutions for industrial and electronic design problems using ball bearing slides. The brochure includes ball bearing and friction slides for a range of industries and applications. **For Free Info Circle No. 710 or Enter No. 710 at www.nasatech.com/rs**

Your best solutions come from flexible thinking.

For closed-cell foam solutions, our design team is ready to help you formulate a solution that fits your needs. Whether an Automotive, Medical, or Industrial Design application, our product line of Volara®, Volextra®, and Minicel® all provide dependable, high-quality, cost-effective ways to enhance your ideas. To find out more, or to receive a free "Thought Starter," call: (800) 225-0668 today.



Ideas Formed in Foam

NAS

100 Shepard Street, Lawrence, MA 01843 • Web Site: www.voltek.com

For Free Info Circle No. 573 or
Enter No. 573 at www.nasatech.com/rs

FREE INFORMATION REQUEST FORM

For quickest service:

Fax this form to (413) 637-4343

Use the online reader service center at www.nasatech.com/rs

Or mail your completed form to
NASA Tech Briefs,
PO Box 5077, Pittsfield, MA 01203-9109.

Name: _____

Company: _____

Address: _____

City/St/Zip: _____

Phone: _____

Fax: _____

e-mail: _____

Please tell us below how *NASA Tech Briefs* has helped you solve a problem or been applied to your business/product line.

Do you currently receive *NASA Tech Briefs*? ☐ Yes ☐ No

If no, would you like to receive *NASA Tech Briefs*? ☐ Yes ☐ No

Circle the numbers below to receive more information about products and services featured in this issue.

401	402	403	404	405	406	407	408	409	410
411	412	413	414	415	416	417	418	419	420
421	422	423	424	425	426	427	428	429	430
431	432	433	434	435	436	437	438	439	440
441	442	443	444	445	446	447	448	449	450
451	452	453	454	455	456	457	458	459	460
461	462	463	464	465	466	467	468	469	470
471	472	473	474	475	476	477	478	479	480
481	482	483	484	485	486	487	488	489	490
491	492	493	494	495	496	497	498	499	500
501	502	503	504	505	506	507	508	509	510
511	512	513	514	515	516	517	518	519	520
521	522	523	524	525	526	527	528	529	530
531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550
551	552	553	554	555	556	557	558	559	560
561	562	563	564	565	566	567	568	569	570
571	572	573	574	575	576	577	578	579	580
581	582	583	584	585	586	587	588	589	590
591	592	593	594	595	596	597	598	599	600
601	602	603	604	605	606	607	608	609	610
611	612	613	614	615	616	617	618	619	620
621	622	623	624	625	626	627	628	629	630
631	632	633	634	635	636	637	638	639	640
641	642	643	644	645	646	647	648	649	650
651	652	653	654	655	656	657	658	659	660
661	662	663	664	665	666	667	668	669	670
671	672	673	674	675	676	677	678	679	680
681	682	683	684	685	686	687	688	689	690
691	692	693	694	695	696	697	698	699	700
701	702	703	704	705	706	707	708	709	710
711	712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729	730
731	732	733	734	735	736	737	738	739	740
741	742	743	744	745	746	747	748	749	750
751	752	753	754	755	756	757	758	759	760
761	762	763	764	765	766	767	768	769	770
771	772	773	774	775	776	777	778	779	780
781	782	783	784	785	786	787	788	789	790
791	792	793	794	795	796	797	798	799	800
801	802	803	804	805	806	807	808	809	810
811	812	813	814	815	816	817	818	819	820
821	822	823	824	825	826	827	828	829	830
831	832	833	834	835	836	837	838	839	840

ARE YOU AN INSIDER?

Subscribe today to receive the INSIDER, a FREE e-mail newsletter from *NASA Tech Briefs*. The INSIDER features exclusive previews of upcoming articles...late-breaking NASA and industry news...hot products and design ideas...links to online resources...and much more.

☐ I want to be an INSIDER. Send my newsletter to the following e-mail address:

Name _____

Company _____

I also want to receive special-focus e-newsletters on the following technology topics: (check all that apply)

- | | |
|----------------------------------|--|
| <input type="checkbox"/> CAD/CAE | <input type="checkbox"/> Fiber Optics/Communications |
| <input type="checkbox"/> Lasers | <input type="checkbox"/> Test & Measurement |
| <input type="checkbox"/> Optics | <input type="checkbox"/> Imaging/Cameras |
| <input type="checkbox"/> Sensors | |

**For fastest service, sign up online
 at www.nasatech.com/insider**



INSTRUMENTATION & APPLICATION GUIDE ON CD-ROM VOL II

Action Instruments' second edition of their FREE CD-ROM is available. It provides Application Notes to help users understand how signal conditioning and isolation can improve control system reliability and lower costs. Specifying instrumentation to convert sensors signals (RTD, TC, DC, AC, Pot, Bridge, Frequency) to control signals (4-20mA, 1-5V etc.) is now easier than ever, especially with Action's product selector guide. Action Instruments; Tel: 800-767-5726; e-mail: literature@actionio.com; www.eurothermaction.com

Action Instruments

For Free Info Circle No. 617 or Visit www.nasatech.com/617




2002 GOODFELLOW CATALOG OF METALS & MATERIALS

The new and expanded 2002 Goodfellow Catalog of Metals & Materials contains about 40,000 items, along with physical, electrical, thermal, and mechanical properties and comparative data tables. Additions to this year's Catalog include a wider selection of alloy rods and wires, significantly more straight wires, and a greater range of single crystals. Goodfellow; Tel: 800-821-2870; Fax: 800-283-2020; e-mail: info@goodfellow.com; www.goodfellow.com

Goodfellow

For Free Info Circle No. 662 or Enter No. 662 at www.nasatech.com/rs




NEW DATA ACQUISITION HANDBOOK

Keithley's new Data Acquisition and Control Handbook is a comprehensive overview of issues that influence the selection and use of equipment for computerized data acquisition and control. The handbook is a guide to building test and measurement systems that use a personal computer as a controller and a variety of plug-in cards and external instruments to gather data and control external processes. Keithley Instruments, Inc., 28775 Aurora Rd., Cleveland, OH 44139; Tel: 888-534-8453; Fax: 440-248-6168; www.keithley.com

Keithley Instruments, Inc.

For Free Info Circle No. 674 or Enter No. 674 at www.nasatech.com/rs




PRESSURE INDICATING SENSOR FILMS

Pressure force indicating sensor films enable you to quickly, accurately and inexpensively measure pressure distribution and magnitude between any two contacting surfaces. Ideal QC and R&D applications include evaluation of bolted joints and gasketed surfaces, lamination presses, nip impressions, heat seals, composite material tests and machine calibration. FREE samples. Sensor Products Inc. USA; Tel: 973-884-1755; Fax: 973-884-1699; e-mail: sales@sensorprod.com; www.sensorprod.com

Sensor Products Inc. USA

For Free Info Circle No. 670 or Enter No. 670 at www.nasatech.com/rs



PRECISION ENCODERS

New 98-page catalog gives in-depth specifications and descriptions of Accu-Coder™ brand encoders by Encoder Products Company. Catalog features a full line of Cube™, industry-standard size 15, size 20, size 25, size 58mm, C-face, NEMA mount and hollow shaft encoders, with a wide selection of configuration options, suitable for a wide variety of industrial counting, motion, and motor control applications. Encoder Products Company; Tel: 800-366-5412; Fax: 208-263-0541; www.encoderproducts.com

Encoder Products Company

For Free Info Circle No. 680 or Visit www.nasatech.com/680



HIGH PERFORMANCE BRUSHLESS D.C. MOTORS

ARC Systems, Inc. offers custom BLDC motors. ARC Systems, Inc. uses high energy materials to meet the rigid performance requirements of our customers. ARC Systems, Inc. is committed to producing highly technical designs at unbeatable prices. We specialize in 2 Wire Brushless D.C. Motors with the Controller built in. ARC Systems, Inc., 2090 Joshuas Path, Hauppauge, NY 11788; Tel: 631-582-8020, 800-893-3649; Fax: 631-582-8038; email: ARCSERVE@aol.com; website: www.arcsystemsinc.com

ARC Systems Inc.

For Free Info Circle No. 660 or Enter No. 660 at www.nasatech.com/rs



WE'VE GOT IT ALL

From 2-piece Commercial to MS Approved Aerospace Rod Ends & Spherical Bearings. All types of material available - Inch sizes from 1/8" to 2" - Metric from 3mm to 30mm. Let us design your specials for you. Aurora Bearing Company, 970 S. Lake St., Aurora, IL 60506; Tel: 630-859-2030; Fax: 630-859-0971; e-mail: aurora_rodends@aurorabearing.com; www.aurorabearing.com

Aurora Bearing Company

For Free Info Circle No. 661 or Visit www.nasatech.com/661



CUSTOM ELECTROFORMS

Rugged, precision, light weight electroforms can be used at cryogenic temperatures or up to 1000° F. Diameters can range from 0.030" to 8 inches. Wall thicknesses from 0.0003" to 0.025 inches can be supplied. Can be made an integral unit with a bellows to produce a "dynamic" component. Servometer® Precision Manufacturing Group, LLC, 501 Little Falls Rd., Cedar Grove, NJ 07009-1291; Tel: 973-785-4630; Fax: 973-785-0756; www.servometer.com

Servometer® Precision Manufacturing Group, LLC

For Free Info Circle No. 671 or Enter No. 671 at www.nasatech.com/rs



TILT SENSOR

Kavlico's tilt sensor has a molded housing and cable assembly providing excellent humidity resistance for outdoor installations. Rugged design is ideal for high vibration situations such as road construction equipment, agricultural vehicles, cranes & booms, scissor lifts, truck rollover, and more. Quick response time 0.5 to 3 seconds, operates on 5 Vdc and provides a .5 to 4.5 Vdc output. Features EMI, RFI, ESD, and reverse polarity protection. Kavlico Corp.; Tel: 805-523-2000; www.kavlico.com

Kavlico Corporation

For Free Info Circle No. 663 or Enter No. 663 at www.nasatech.com/rs



SOURCE CALIBRATOR

Krohn-Hite Corp. introduces the NEW Model 511 precision dc voltage source/calibrator covering the range from $\pm 100n$ Vdc to ± 10 Vdc over 3 ranges with ± 10 ppm accuracy and ± 2 ppm stability guaranteed for a full year. Resolution is 1 ppm of range. Applications include 16/18 bit DAC testing, strip chart recorders, calibration of data logging systems, and more. For more information visit our Web site at www.krohn-hite.com/Model511.htm or call 508-580-1660.

Krohn-Hite Corporation

For Free Info Circle No. 664 or Enter No. 664 at www.nasatech.com/rs



PAPERLESS RECORDERS WITH COLOR TOUCH SCREEN

Data-Chart Paperless Recorders accept up to 12 direct universal inputs including thermocouples, RTDs, DC voltage, current and dry contact. Information is displayed on brilliant LCD displays and recorded to 3.5" disk, 100 MB Zip disk or PCMCIA cards. Windows compatible software communicates over RS232, RS485 or Ethernet. Monarch Instrument is an ISO 9001 registered company. Monarch Instrument; Tel: 603-883-3390; Fax: 603-886-3300; e-mail: sales@monarchinstrument.com; www.monarchinstrument.com

Monarch Instrument

For Free Info Circle No. 665 or Visit www.nasatech.com/665



POROUS CERAMIC VACUUM CHUCK

PhotoMachining offers a porous ceramic vacuum chuck for use with thin films and other flat samples. Pore sizes under 25 microns assure uniform suction and holding power for even the smallest parts. PhotoMachining also provides contract laser-manufacturing services, and designs and builds custom laser-based manufacturing equipment. PhotoMachining, Inc., 4 Industrial Dr., Unit 40, Pelham, NH 03076; Tel: 603-882-9944; Fax: 603-886-8844; rschaeffer@photomachining.com; www.photomachining.com

PhotoMachining, Inc.

For Free Info Circle No. 669 or Enter No. 669 at www.nasatech.com/rs




STOCK AND CUSTOM SPRINGS

Over 6,000,000 coil springs in stock (compression, extension and torsion). For custom springs a Free on-line spring calculator and instant on-line quotations are available at www.msdspring.com. The on-line spring calculator can also locate potential stock springs substitutes for your custom design. For a FREE printed catalog use the reader service card, call 800-633-7734, or visit www.msdspring.com. Custom spring designs can also be faxed to 845-344-2175 for prompt pricing and design review.

MSDivisions (MSDSpring)

For Free Info Circle No. 666 or
Visit www.nasatech.com/666



SPIRAL RETAINING RINGS

The new Smalley Steel Ring Company Retaining Ring Catalog is now available. Smalley has over 4100 rings in stock, sizes from 1/2" to 16". Special designs are available with No-Tooling-Charges™ with sizes from 9/32" to 84"; available in carbon and stainless steel. Smalley engineers are always available for FREE design assistance. Smalley rings have No Ears to Interfere™. Smalley Steel Ring Company, 555 Oakwood Road, Lake Zurich, IL 60047; Tel: 847-719-5900; Fax: 847-719-5999; e-mail: info@smalley.com; www.smalley.com

Smalley Steel Ring Company

For Free Info Circle No. 672 or
Enter No. 672 at www.nasatech.com/rs



SUPERIOR LINEAR SLIDES ON-LINE

AG Slides from Optical Gaging Products, Inc. can now be purchased at our website www.agslides.com. Select a slide by entering the parameters you need. The AG Slides family of linear motion components come in a wide range of sizes, in ball and roller styles. Innovations include "wedge" pre-load of all bearings, simultaneously. Optical Gaging Products, Inc., 850 Hudson Ave., Rochester, NY 14621; Tel: 800-922-0329; Fax: 716-544-4998; www.agslides.com

AG Slides

For Free Info Circle No. 668 or
Visit www.nasatech.com/668



Venture Capital: The Definitive Guide

Based on in-depth interviews with major players in the VC arena – including money managers as well as successful entrepreneurs – this new book provides powerful pointers on how to make a business attractive to VCs, how to negotiate agreements, and much more.

336 pages • \$34.95

Order online:
www.nasatech.com/store



AUTOMATED TEST AND MEASUREMENT SOLUTIONS BROCHURE

Automated Test and Measurement Solutions, a free brochure from National Instruments, describes how scientists and engineers can increase productivity and lower costs by using the latest PC technologies with National Instruments software and hardware to create high-performance, computer-based measurement and automation systems. Call today for a free brochure. National Instruments; Tel: 800-894-0885 (U.S. and Canada), 512-794-0100; Fax: 512-683-9300; e-mail: info@ni.com; www.ni.com/info/test

National Instruments

For Free Info Circle No. 667 or
Enter No. 667 at www.nasatech.com/rs



TUSK DIRECT'S IN-STOCK LINEAR MOTION PRODUCTS

Free linear motion catalog in print, CD-ROM and on the Web is a resource for design engineers working with linear motion and needing linear bearings of many types quickly. Included are dimensions, specifications and CAD drawings for ball slides, roller slides, heavy duty crossed roller tables, multi-axis positioning tables, recirculating slide guides, pillow blocks, shafts, hangers, supports, and linear bearing and automation components. Tusk Direct; Tel: 800-447-2042; Fax: 203-748-5147; e-mail: sales@tuskdirect.com; www.tuskdirect.com

Tusk Direct

For Free Info Circle No. 673 or
Enter No. 673 at www.nasatech.com/rs




FMEA SOFTWARE

Failure Modes and Effects Analysis using FMEA-Pro™ 5 empowers automotive, consumer, electronic, aerospace, defense and general manufacturing industries to improve the quality, reliability and safety of their products. This fully customizable software helps companies comply with QS 9000, ISO 9000, SAE J1739, MIL-STD-1629, ISO/TS 16949 and other regulations. FMEA-Pro™ 5 contains extensive libraries and data protection features. The report generation tools support a variety of file formats, including HTML and PDF. Download a free trial: www.fmeasoftware.com.

Dyadem International Ltd.

For Free Info Circle No. 678 or
Visit www.nasatech.com/678



Directory of Venture Capital (2nd Edition)

This comprehensive, easy-to-use resource for both new and experienced entrepreneurs covers more than 600 venture capital firms with their addresses, phone numbers, types and sizes of investments, geographic preference, etc.

385 pages • \$39.95

Order online:
www.nasatech.com/store

High-Temp Tubing & Hose

- Silicone for air, liquids, gases
- Platinum or peroxide cured
- Temps from -100°F to 500°F
- USP Class VI, FDA, NSF
- Clean room manufactured in-house under strict GMP



NEWAGE INDUSTRIES


800-50-NEWAGE
Fax 800-837-1856
psales@newageind.com
Southampton, PA

www.newageindustries.com

For Free Info Circle No. 586 or
Enter No. 586 at www.nasatech.com/rs

DATA LOGGING SOLUTIONS FROM ACR SYSTEMS

An ISO 9001 Registered Company



Temperature, Relative Humidity,
Pressure, Pulse, Process Signal,
Electric Current and more . . .




ACR Systems Inc.
Phone 1-800-663-7845 (Toll-Free in North America)
Or: 604-591-1128; Fax: 604-591-2252
Email: enquiry@acrsystems.com

The Industry Leader Since 1985 & The Best Warranty in the Business

www.acrsystems.com

For Free Info Circle No. 591 or
Enter No. 591 at www.nasatech.com/rs

New!



Mechanical Engineer's Handbook

An essential companion for the mechanical engineer. With over 1,000 pages, 550 illustrations, and 26 tables, the Mechanical Engineer's Handbook is comprehensive yet affordable and portable. It covers all major areas of mechanical engineering & design with succinct definitions, formulas, and examples.

Hardcover • 1,100 pages
Introductory price: \$67.95

Order online:
www.nasatech.com/store

Advertisers Index

For free product literature from these advertisers, enter their reader service numbers at www.nasatech.com/rs

Advertisers listed in bold-face type have banner ads on the NASA Tech Briefs Web site — www.nasatech.com

Company	Reader Service Number	Page	Company	Reader Service Number	Page
Accuride	571	52, 53	Meier Tool & Engineering Inc.....	658	64
ACR Systems Inc.....	591	81	Micro Mo Electronics	651, 652	75
Action Instruments	617	80	Minco Products, Inc.	589	58
Algor, Inc.	513	5	Monarch Instrument	665	80
Amacoil, Inc.	690	75	MSC Software.....	539, 590	8,9,COV III
Ansoft Corporation	566	41	MSDivisions	666	81
ANSYS, Inc.....	561, 503	44, 46	National Instruments Corp	502, 551, 653, 667, 436	COVII,37,71,81,11a
ARC Systems Inc.	660	80	New Age Industries	586	81
ASME International.....	580	77	Noran Engineering, Inc.	565	68
ATI Industrial Automation	570	19	NuSil Technology.....	558	42
Aurora Bearing Co.	661	80	Ocean Optics Inc.	577	67
Autodesk.....	507	15	Omega Engineering, Inc.	500, 501	1
BSI/Broadax Systems	529	10	Optical Gaging Products Inc	668	81
California Linear Devices	541	34	Panasonic Vision Systems Group	43, 45, 47, 49	
Carpenter Technology.....	542	21	PTC	530	11
Comsol Inc.	25-26		PEM Fastening Systems		
Crossbow Technology	553	38	A PennEngineering Company	563	48
CUI Stack	535	16	PhotoMachining, Inc.	669	80
Delta Tau Data Systems, Inc.....	568	51	Presray Corporation.....	547	36
Deschner Corporation	657	74	RGB Spectrum.....	520	65
Dewetron	544	23	Research Systems.....	512	30
Digi-Key Corporation.....	509	3	Sensor Products, Inc.	670	80
Dyadem International	678	81	SEPAAC, Inc.....	655	72
Emhart, a Black & Decker Company.....	411, 534	56, 57	Servometer®	671	80
Encoder Products	680	80	Smalley Steel Ring Company	656, 672	74, 81
Endevco	516	6	Solid Edge-EDS PLM Solutions	525	7
Engineering Design Team	414	61	SolidWorks	533	COV IV
FJW Optical Systems, Inc.	452	6a	Sonic-Mill	518	31
Gage Applied, Inc.	403	20	SPIE.....		12a
Globe Motors	450	60	Stanford Research Systems	515	55
Goodfellow Corp.....	662	80	StockerYale Canada, Inc.	511	13a
HD Systems, Inc.	647-650	73	Synrad, Inc.....	504	2
Helical Products Company, Inc.	659	76	TEAC America, Inc.....	506	17
IEEE	517	13	Tekscan, Inc.....	575	60
Indigo Systems	485	1a	Tera Analysis Ltd.	582	78
Innovative Integration	579	66	TranTek Drive Systems Inc.	654	70
Instron Corporation	560	54	TSI Incorporated	554	39
Kaman Sensors.....	404	18	Tusk Direct	673	81
Kavlico.....	663	80	VX Corporation	592	33
Keithley Instruments	674	80	Velmex	584	66
Kontron Mobile Computing	555	40	Voltek	573	78
Krohn-Hite	664	80	Yamacraw	438	7a
Lake Shore Cryotronics.....	545	28	Yardley Products Corp.	572	58
Master Bond Inc.	581	77	yet2.com.....	585, 489	24, 59, 6a, 9a
The MathWorks, Inc.	550	29	ZC & R	469	3a

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright ©2002 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$135 for 2 years. Single copies \$5.00. Foreign subscriptions one-year U.S. Funds \$195.00.

Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

POSTMASTER: Send address changes to NASA Tech Briefs, PO Box 10523, Riverton, NJ 08076-9023.

Need to improve your game?



Let MSC.Software be your caddy.

No matter where you play; aerospace, automotive, consumer products or other industries, MSC.Software can increase your chance of winning. We provide best-in-class solutions to help you succeed.

MSC.Software's turn-key Product Lifecycle Management (PLM) Solutions include:

PLM Software:

Dassault Systemes/IBM PLM Software

- CATIA
- ENOVIA
- SmarTeam

MSC.Software Simulation and Collaboration Tools

- MSC.Fatigue
- MSC.CATCMM
- MSC.Mvision
- MSC.visualCollaboration
- MSC.Nastran
- MSC.visualNastran 4D
- MSC.Patran
- MSC.visualNastran for Windows
- MSC.Dytran
- MSC.FlightLoads

PLM Services:

- Analysis Services
- Design Services (Out-Source or On-Site)
- Data Migration/CAD Interoperability
- Manufacturing and Inspection Services
- MSC.Software Analysis Training
- CATIA Training
- On-Site CATIA Support
- Custom CATIA API Development
- CAD/CAE/PDM Integration
- CATIA Process Optimization
- R&D Lab for Tools and Process Validation
- PDM Implementation and Cost Optimization

PLM e-Services:

- onDemand Licensing
- Simulation Center
- Engineering Exchange
- MSC.Institute of Technology

PLM Hardware Systems:

- Complete UNIX, Linux or Windows® Based Enterprise Infrastructure Solutions
- Disaster Recovery
- High Performance Computing (HPC)
- Storage Solutions

Increase your profitability with IBM Product Lifecycle Management solutions. Contact us today to take advantage of our limited time special offerings based upon the newly released CATIA Version 5 Release 8 Portfolio. 800-642-7437 x 2500




www.mscsoftware.com/golf

MSC SOFTWARE
SOFTWARE • SYSTEMS • SERVICES

They believe you'll automatically install their 3D software because you already have their 2D software.

We believe you're smarter than that.



We understand that you need the best design tools available. Why? Because SolidWorks was founded by people like you. People who know what it takes to design a product and see it through production. Our 3D software gets the job done. And gets it done easily. We're **100% Focused** on product design. We're **Proven** in production. Our **Innovative** capabilities lead the CAD industry. When it comes to performance

and compatibility, SolidWorks sets **The Standard**. Maybe that's why more than 175,000 designers and engineers worldwide will spend more than 50 million hours this year using SolidWorks® software. Don't be fooled by imitators. There's only one standard in 3D. SolidWorks. **For a free demo CD, visit us at www.solidworks.com/thestandard or call 1-800-693-9000.**

The Standard in 3D

©2002 SolidWorks Corporation. SolidWorks is a registered trademark of SolidWorks Corporation. SolidWorks Corporation is a Dassault Systèmes company.

For Free Info Circle No. 533 or Enter No. 533 at www.nasatech.com/rs

